

AUKEY

User Manual
Wireless Gaming Mouse

Thank you for purchasing the AUKEY GM-F5 Wireless Gaming Mouse. Please read this manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Package Contents

Wireless Gaming Mouse
USB Receiver
Braided Nylon USB-A to C Cable
User Manual
Warranty Card


Specifications

Model	GM-F5
Number of Buttons	8
Switch for Left & Right Buttons	HUANO 60±65gf
Lifespan of Left & Right Buttons	20 million clicks
Interface	USB 2.0
Input (via cable)	DC 5V 25mA
Wireless Technology	2.4GHz
Wireless Operating Distance	Up to 10m / 33'
Sensor	PMW3335 optical sensor
Max Resolution	16000 DPI
Max Speed	400 IPS
Max Acceleration	40G
Polling Rates	125 / 250 / 500 / 1000Hz
System Requirements	Windows XP / Vista / 7 / 8 / 10, Mac OS
Material	ABS, braided nylon
Cable Length	1.8m / 5.9'

- 1 -

Dimensions	125 x 64 x 40mm / 4.92" x 2.51" x 1.57"
Weight (cable excluded)	110g / 3.88oz
USB Receiver Dimensions	18 x 14 x 6mm / 0.7" x 0.5" x 0.2"
USB Receiver Weight	1g / 0.03oz

Product Diagram



- 2 -

Model: GM-F5

Aukey Technology Co.,Ltd
www.aukey.com | support@aukey.com
Room 102, Building P09, South China City
Electronic trading center, Longgang District,
Shenzhen, Guangdong, 518111, CN



Getting Started

1. Turn on your computer.
2. Plug the USB receiver into a USB port on your computer.
3. Turn on the mouse with the on/off switch on the bottom.
4. Wait for a few seconds until your computer recognizes the mouse before use.
5. To use it as a wired mouse and also to charge the mouse battery, connect the mouse to your computer with the included cable.

Notes

- With the on/off switch in the middle position, the mouse is on but the logo light is off.
- You can use the mouse in wired mode even if the on/off switch is in the off position.

Battery Level & Charging Indicator

Charging	4 LED lights turn on in sequence
Shutdown (less than 10% battery level)	1 LED flashes quickly
Low battery (less than 20% battery level)	1 LED flashes slowly
Battery level: 25%	1 LED light on
Battery level: 50%	2 LED lights on
Battery level: 75%	3 LED lights on
Battery level: 100%	4 LED lights on

FAQ

Why doesn't the mouse respond after I connect it to my computer?
When you connect this mouse to your computer for the first time, allow a moment for the computer to recognize it. If you have any issues getting it working with your computer, just contact our customer support.

- 3 -

Warranty & Customer Support

For questions, support, or warranty claims, contact us at the address below that corresponds with your region. Please include your Amazon order number and product model number.

Amazon US orders: support.us@aukey.com

Amazon EU orders: support.eu@aukey.com

Amazon CA orders: support.ca@aukey.com

Amazon JP orders: support.jp@aukey.com

*Please note, AUKEY can only provide after sales service for products purchased directly from AUKEY. If you have purchased from a different seller, please contact them directly for service or warranty issues.



Size : 16 x 12 mm

- 4 -

FCC Warning

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2ATIH-GMFS
FCC ID: 2ATIH-GMFS5A

- 5 -

尺寸：70x90mm
材质：105g铜版纸
颜色：单黑(双面印刷)