





Model: Cami

01/POINTS FOR ATTENTION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including inter-ference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for

01

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Before using, please read this user manual carefully and keep it for future reference.

Danger Warning

- 1. To avoid electric shock and fire, do not allow water, liquid or
- any flammable detergent to get into or to clean the product.

 2. Do not spray any flammable material such as pesticides or perfumes around the product.

Using Warning

- 1. This product can not replace normal ventilation, daily dust collection or oil pumping when cooking.

 2. Ensure the product socket is well connected with plug. If
- not, the plug will be hot.
- 3. Do not place any items above the product.
- 4. Be sure to place and use the product on a firm, flat and horizontal surface.
- Leave at least 30cm of space on the back and sides of the product, and at least 50cm of space above the product
- 6. Do not place the product under air conditioner to prevent condensation water dropping into the product.
- 7. Ensure both the filter and the back cover are properly installed before connected power.
- Please use the filter specially designed for this product.
- 9. Do not take the filter as fuel or similar purposes to avoid irreversible harm. 10. Do not use hard objects to strike the products, especially
- the air outlet and air inlet. Do not insert finger or other things into the air outlet/inlet to prevent physical damage or trouble.
- 12. Do not use this product when you are using an indoor spray
- repellent, or in a place filled with grease, flammable gas or chemical fumes. 13. Ensure the product is unplugged before moving, cleaning,
- maintaining and replacing filter.

 14. Unplug the power connecting before moving the product.
- Do not pull the wire to move the product.

- 1. Before connecting the power supply, please check whether the voltage of the product is consistent with the local power
- 2. If power cord is damaged, in order to avoid danger, it must be replaced by professional staffs.
- 3. Please stop using if the plug, power cord or product is dam-
- Keep the air inlet/outlet free from being blocked.
- 5. Do not insert foreign things into the machine.
- 6. Person with physical or mental disability, or without relevant experiences and skills(including children) should use it under guiding and instructing.

02 / Product overview

Components





Function Button

Wind/WiFi Button

Power Button

(P)

(1) Timer Button

03 / Specifications

Model	Cami
Size	245x247x366mm
Weight	3.15kg
Power	30W
Adapter	Input: AC100-240V 50/60Hz Output: DC24V 2A
Noise	55dB
Coverage Area	≤36m²

04

Thank you very much for using our products. Please read the user manual carefully before use, and keep it for future reference.

04 / Instructions

Steps of Installing Filter

Before using, please remove the package of the filter. Ensure the product is unplugged before removing or installing the filter.





4. Put the filter into the product

3. Remove the packing of the



5. Install the base, rotate and



05/ Using Instruction

When the product power on, the buzzer ring. All indicator light will be on and off after 1s and enter standby mode.

Power Button

In the standby mode, press this button and the product defaults to Auto mode. Press it again, the product enter standby mode. The leaf sign indicator will display the relevant colors according the air quality. There are four

Blue represents good air quality. The product is in low wind Yellow represents average air quality. The product is in

middle wind speed. Red represents poor air quality. The product is in high wind speed.

Function Button

In the condition of working, this button can control Anion and UV function on or off. When the filter life expires, the indicator light of filter fishes red. Press this button 7s to eliminate filter replacement remind

Wind Speed/WiFi Button

In the condition of working, press this button can control wind speed, and press the Sleep-Mid-High-Auto mode to cycle. Press the button 5s, the product enter WIFI configura-tion mode. The indicator light of WIFI will be on after connecting network.

Timer Button

In the condition of working, press the timer button, press once to set one hour, twice to set two hours, and so on, you can set 24 hours. No operation timing for 5 seconds succeeds. Press this button for 5s to cancel the timing.

05

06/Wifi operation

Download & Registration

1. Scan the QR code to download "Smart Life" APP. You can also search "Smart Life*' in either APP store or Google Play to install the APP.



- 2. Open the "Smart Life" APP, tap "Register" to register a Smart Life account with your phone number or E-mail. Then sign in the APP.
- 3. Open the "Smart Life" APP, click "add device" or tap "+" on the top right corner of the APP homepage. There are two methods to enter the page of "add device" -Add WiFi manually or search for the devices automatically.

In the homepage of add device manually, choose your type of product to enter a new homepage and ensure the indicator light of the product flashes quickly.

Add Devices in Easy Mode(Recommend):

Make sure your smart device is energized and your mobile phone is connected to your WiFi network. If the WiFi indicator of smart device does not flash, please press the Timer/WiFi Button for more than 7 seconds until the indicator light keeps flashing quickly (about 2 times per second), it means the devices is ready for configuration. Tap "+" on the top right corner of the APP, choose and click the type of your device. When appearing "Add 1 device successfully", it means the connection is completed and your device will be listed in

06

Add Devices in AP Mode:

If failed in Easy Mode, users could also add devices in AP Mode. Press the Timer/WiFi Button for more than 5 seconds until the WiFi indicator light begins to flash slowly, it means flash slowly, it means the device is already for configuration in the AP Mode. Tap "+" on the top right of corner the APP. Choose and tap AP mode, then tap "Ensure the indicator flash slowly" . Then tap "Connect now" to go to the WLAN Settings interface in your mobile phone and choose the WiFi network named "Smart Life_XXXXH" to connect it. Return to the "Smart Life" APP, the connection will start automatically. When appears "Add 1 device successfully", it means the connection is completed and your device will be listed in your APP list. Now you can control your smart device via your mobile phone APP anytime and anywhere (Make sure your mobile phone and smart device are all connected to the network, and to change the router name into Smart Life

07 / Filter replacement

When the light ring is always in red gradient state, it means the filter needs to be replaced. Please use the original filter.

- . Clean the filter regularly. Do not wash or reuse the filter. Ensure the product is unplugged before replacing the
- . Do not use a vacuum cleaner to clean the filter or wash it directly.
- Please sterilize the filter under sunlight regularly.

In the condition of working, the filter icon flashes in red after product works 2200 hours. Press Wind Button 7 seconds to cancel filter remind. The red light of filter icon will be turned off. The product will start counting from zero.

08 / Maintenance

- Ensure the product is unplugged before maintenance. . Do not immerse the air purifier into water or any liquid.
- . Do not use abrasive.corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the unit.
- . Do not wash the filter
- Do not use a vacuum cleaner to clean the filter.

Cleaning:

- Ensure the product is power-off and unplugged.
- . Take out the filter to clean any dust from the surface of it. . Use a soft cloth with neutral cleanser to clean away any dust or debris from the surface of the product.
- . After the air purifier is dried, install it into the air purifier to

- . Ensure the product is power-off and tie up the power line.
- . Take out the filter and clean the dust from the surface of it · Use a soft cloth with neutral cleanser to clean the air inlet/outlet.
- · After the product is completely dried put on the dust cover/bag and store in a ventilated area away from direct sunlight.
- To ensure a good performance of the product, please turn on the product for a few minutes from time to time.

09/ FAQ

SITUATION	REASON
No working	B it plugged into a power socket? Is there a power outage? Is the home leakage switch or fuse cut off? Is the indicator light of filter replacement remind flashing?
Poor	Is there any dust in the surface of primary filter? Is there anything in the air outlet/inlet?
Significant noise	Is there anything stuck on the fan in the air outlet? Is the machine tilted? Please set a lower grade of wind speed if the noise is too loud or open low wind speed in the bedroom at night.
Coming out nasty smell	It is the normal phenomenon that the product emits the smell of plastic for the first time. The product ville mitn says smell, if the filter is dusty, in this situation, please clean or replace the filter. If the air punifier emits a burning smell, turn it off and unplug it from the power outlet. Then contact the supplier or Customer Service.
The reminder of replacing filter is still flashing after user	Please press the Wind Speed/Filter Button \odot for 7 seconds to reset the product. The red indicator light will be turned off and the life counter of the filter

Notice: If the above FAO can not solve your problems and you need maintenance, please contact the supplier or Customer Service.

Please do not disassemble the product to maintain by yourself

07

07

08