

I. INTRODUCTION

The device brings you much convenience for your business designed, it brings you wonderful user experience, designed to give more functions and friendly user interface to work with our Sammic machines. This guide serves to enable users to get to know and familiar with the product as soon as possible. Here we have made a brief introduction in figures and words. Before beginning, please refer to this user manual carefully.

**Software not included*

This manual describes the installation, operation and maintenance of the SmartVide Box. The model reference and its characteristics appear on the name plate attached to the machine. This device has been designed and manufactured in accordance with the following standards:

- FCC part 15 subpart C	FCC part 15.247
- <i>Electromagnetic Compatibility of Multimedia Equipment</i>	<i>EN 55032</i>
- <i>Electromagnetic Compatibility, Immunity requirements</i>	<i>EN 55035</i>
- <i>EMC limits for harmonic current emissions</i>	<i>EN 61000-3-2</i>
- <i>EMC limitation of voltage changes, fluctuations and flickers</i>	<i>EN 61000-3-3</i>
- Electromagnetic compatibility (EMC) standard	ETSI EN 301489-1
- Electromagnetic compatibility (EMC) standard	ETSI EN 301489-17
- Wideband transmission systems Bluetooth 4.0	EN 300328
- Wideband transmission systems Bluetooth 2.1	EN 300328
- Wideband transmission systems IEEE 802.11b/g/n	EN 300328
- EMF assessment	EN 62479:2010
- Degrees of protection provided by enclosure (IP65):	IEC 60529:2013
- Information technology equipment – Safety:	IEC 60950-1
- RoHS	EU Directive 2011/65/EU

II. SAFETY AND PRECAUTIONS BEFORE USE

To reduce the possibility of accidents and ensure the best functioning and the proper maintenance of the machine, it is necessary to carefully read and follow these instructions. Keep these instructions and ensure that all users of the machine read them before use. Also keep the warranty and the declaration of conformity.

1. Prevent this product from falling to the ground in could be strongly damaged.
2. Keep the device away from rain, moisture, direct sunlight and heat source.
3. Avoid liquid getting inside the device and never submerge it in water or any kind of liquid.
4. Once any water or other liquid splashed onto this product, close it immediately and do not use it until it dries out.
5. Avoid using it in the strong magnetic and strong static environment as much as possible.
6. Clean the device with the power cord unplugged.

SAMMIC SMARTVIDE BOX MANUAL

7. Do not clean this product with any detergent containing chemical element or other liquid to avoid causing damage due to corrosion and becoming damp. If cleaning is necessary, clean it with dry soft cloth tissue paper.
8. Handle the screen gently. To clear fingerprints or dust on the screen, use soft cloth dedicated for camera lens instead of gauze.
9. Please do not disassemble this product by yourself; otherwise you will lose the right to warranty.
10. This appliance is not to be used by people (including children of 8 years and over) with limited physical, sensorial or mental capabilities, or that lack the experience or knowledge, unless they have been supervised or instructed in the use of appliance by a person responsible for their safety and understand the danger it entails. Do not allow children to play with the appliance. The cleaning and maintenance to be performed by the user must not be performed by unsupervised children.
11. This machine is for supervised use. Never leave the machine running unsupervised.
12. Comfort or familiarity with the product (based on its repeated use) should not replace strict compliance with the safety regulations. Be alert, pay attention to what you are doing and use common sense when operating the appliance.
13. Do not disconnect the device from power suddenly, when uploading and downloading, which can lead to program errors.
14. Please use the original AC adapter. Nonconforming chargers may cause harms.
15. Protect the power cord. When connect the power cord. Do not step onto it or place any object on it. Which may cause extrusion. Protect the connector of the power cord connected devices specially.
16. The device cited in the manual have been designed for use in hotels, restaurants, catering and commercial applications.
17. Do not use the appliance while you are tired or under the influence of drugs, alcohol or medication. If you use the machine incorrectly or in an unsafe manner, you may suffer personal or material damages.
18. Location:
 - a. Use this device in a ventilated environment at an ambient temperature no higher than 40 °C.
 - b. Do not place the device next to or near sources of heat.
19. Pictures in this manual are for demonstration purpose only and may differ from the real product.
20. Any accessories used must be designed for the specific model and the SAMMIC brand. Any accident caused by non-SAMMIC accessories will be the responsibility of the user.
21. The manufacturer is not responsible when the product is used incorrectly or differently than the use mentioned above. Such as sanitary use, chemical use, use in explosive atmospheres, etc.

III. HARDWARE DESCRIPTION

Our device SmartVide Box is designed to empower our Sammic machines with friendly design.


The device has a 10" touch display with an aluminium alloy case **(1)**. It must screw the antenna **(2)** for wireless connection as Bluetooth and Wifi to connect to our machines and for our online services. It must be powered with the power supply **(3)** to use SmartVide Box, our device does not have an internal battery.



With the power supply plug in and connected to the power entry in the device **(5)** hold the main button **(4)** until the screen turns on.


Our device has an NFC sensor **(6)** in the front side and two loudspeakers **(7)** in the back side.

It has four holes **(8)** for screw to a support.




IV. BASIC OPERATIONS

1. Set language and date.



2. Wireless connectivity: Bluetooth, Cast, Wifi


Enable or disable the connectivity.



SAMMIC SMARTVIDE BOX MANUAL


3. Main applications

Touch the application to access it




4. Software version

Connect the devices to Wifi, it will automatically check the latest stable software version.



V. ERASE ALL DATA TO DEFAULT CONFIGURATION

Touch and hold down the SMARTVIDE logo for ten seconds and release. A window will appear to guide you.



FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-

Consult the dealer or an experienced radio/TV technician for help important announcement

Important Note:

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.