


TWS-S8 PLUS

User Manual


Illustration



Fit the headphone to your ear

For optimal audio performance ,it's important to choose the correct size earplug that gives you the best comfort and fit in each ear.

Remove the earbuds from the charging case. Insert the earbuds in your ear to test the fit for comfort and stability .The original size of earplug is M ,please try each of the earplug sizes and the fit should feel tight and secure in your ear.



Instructions

Use the earbuds for the first time

Step one: pairing the earbuds
Move the earbuds from the charging case, they will be turned on and pair with each other automatically.

Step two: pairing with the smartphone
Turn on the Bluetooth function of the smartphone, search the available Bluetooth devices until see "S8 PLUS" on the list, select it to establish connection.



Next time onwards
Move the earbuds from the charging case and insert them in your ears, they will link to the smartphone witch was connected last time automatically.

Mono earbud using

Each one earbud could be used separately to connect the smartphone for playback or call function.

Power on/off
Move the earbud from the charging case to power on and put it in the charging case to power off.
You can also power it on/off manually by tap and hold on the touching control area for several seconds.

Indicator light status:
Charging:Red light will be on until full charged
Power on:Blue light flashes
Power off:Red light flashes until off
Pairing:Blue and red lights flashes alternately
Under using:No flashes




Activate Siri

Press MFB button around 1.5s untill the voice prompts "du" to active Siri; short press to end Siri.

Headphone control

Playback/Pause: single tap
Skip forward: Double click the R earbud
Skip backward: Double click the L earbud
Answer/End a call: single tap
Reject a call: tap and hold
Volume up: Triple-click the R headset MFB button
Volume down: Triple-click the L headset MFB button



Charging the earbud

Put the earbuds in the charging case until they magnetically snap into the place to start charging and the indicator on the earbud grows red.
The indicator will extinguish when fully charged.

Do not press the charging pins hard to avoid damage.



Close the lid firmly while charging

Charging the charging case

Plus the charging case into a USB power supply (5V1A) with the attached cable.
Highly recommend you to use the USB charger that is manufactured by regular producer.

Check the battery level

The indicators glow according to the battery level as follows:
• If three indicators glow solid, the battery is fully charged.
• If only one indicator glows solid, the battery is low. Charge the case battery.
When the battery fully charged, pull out the USB cable from the charging case.

Specification

Bluetooth version : 5.0
Support protocol : A2DP/AVRCP/HFP/HSP
Frequency range : 2.402GHz-2.480GHz
Transmission distance : ≤ 10m
Audio playback time : about 3 hours

Earbud charge time : within 60 minutes

Charging case charge time: about 3-4 hours

Supported system : all Bluetooth devices and smartphones

WARNINGS/CAUTIONS

Don't disassemble the earbuds and charging case or the warranty will lose effectiveness.

The earbuds and charging case contain a lithium-ion battery, do not expose them to the fire or excessive temperature.

The earbud has a certain waterproof ability, but not suitable for swimming and do not let it touch hot water.

Q&A

Q: Why is the headphone sound intermittent?
A: It's maybe affected by the environment, charge to another place to check. If this situation is sustained, pls contact us.

Q: Why can not play music after reset?
A: You must pair the earbud with smartphone again. Delete the "S8 PLUS" from the connectd device list and search again for new paring.

Q: What is "one link two"?
A: The earbud can link to 2 smartphones at the same time. Steps: link to the first smartphone and then switch off the Bluetooth of this smartphone. Link to the second smartphone and then switch on the Bluetooth of the first smartphone.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction