

### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FUNCTION MANUAL

#### INPUT/ST-BY

Press this button on the panel, the unit will turn on. Short press to select input mode. Hold for 2 seconds the unit will turn off.

#### PLAY/PAUSE

1. When playing USB/SD/Bluetooth, press this button once to play & pause.
2. In FM mode, hold for 2 seconds the device will enter into automatic scan and then save program; short press this button again to stop.

#### PREV/FM-

1. When playing USB/SD/Bluetooth, press this button once to select previous song.
2. In FM mode, press this button once to change the frequency modulation. Hold for 2 seconds the device will enter into automatic scan for previous channel and then save it.

#### NEXT/FM+

1. When playing USB/SD/Bluetooth, press this button once to select next song.
2. In FM mode, press this button once to change the frequency modulation. Hold for 2 seconds the device will enter into automatic scan for next channel and then save it.

#### VOL-/VOL+

Total Volume decrease/Total Volume increase

#### TREBLE-/TREBLE+

Treble volume decrease/Treble volume increase

#### BASS-/BASS+


Bass volume decrease/Bass volume increase

#### VOLUME

Microphone volume control

#### ECHO

Microphone reverb adjustment



### REMOTE



### REMOTE CONTROL FUNCTION

- ⏻ Press it once to enter into standby state. Press it again the unit will switch on.
- ⏸ Press it to mute the unit
- AUX Press it to enter into AUX mode
- U/SD Press it to enter into USB/SD mode
- 3D Press it the 3D button to cycle through six sound modes
- ↺ When playing USB/SD/TF card, press this button into ALL/RAN/DEU/FOD four modes, one press one modes
- FM Press it to enter into FM mode
- SEARCH When playing FM, press it to enter into automatic scan and then save program
- SEEK\* In order to get the best receiving effect, manual search for next FM channel
- SEEK\* In order to get the best receiving effect, manual search for previous FM channel
- INPUT Press it to change the modes between AUX/SD/CARD/USB/ FM/Bluetooth orderly
- LED Press once LED bottom, flash light, cycle through red light/ green light/ blue light/ light turn off four modes, one press one modes
- VOL- Press it to decrease the volume
- VOL+ Press it to increase the volume
- ⏸ 1. When playing USB/SD, press this button once to pause, press again to continue playing.
- 2. When playing Bluetooth, this is play/pause button, simultaneously open the Bluetooth setting on your device
- ⏮ 1. When playing USB/SD, press this button to select previous song, simultaneously open the Bluetooth setting on your device
- 2. When playing Bluetooth, press this button to select previous song, simultaneously open the Bluetooth setting on your device
- ⏭ 1. When playing USB/SD, press this button to select next song.
- 2. When playing Bluetooth, press this button to select next song, simultaneously open the Bluetooth setting on your device
- 0-9 When playing USB/SD/FM, select the song and play directly
- 📶 Press it to enter into bluetooth mode and wait for the match and connection
- 🔄 press it to rematch the Bluetooth

### SPECIFICATIONS

- (1) Built OCL amplifier, Compatible for Computer, VCD, CD, LD, Walkman and so on
- (2) Magnetic shielded treatment designed, able to be configured with TV sets or computers.
- (3) Creating a larger dynamic range in the low frequency, a smoother middle frequency, and a pure and harmonious high frequency.

### OPERATION

- (1) Please connect the sound sources and powers in accordance with the sketch map.
- (2) When all of the units are connected correctly, turn on the power switch.
- (3) Open your sound sources, then adjust the volume knobs of the different channels for a satisfied personalized effect.
- (4) After your use, please turn off the power supply switches.


### ATTENTION

- (1) Please turn the volume knob to the minimum position before your operation to prevent any damage to the speakers due to the instant impact.
- (2) Please avoid being exposed or put in humid environment.
- (3) Please do not open the back cover of the main speaker in case of getting an electric shock or breaking the warranty regulations.
- (4) Please turn off the power switch and release the plugs if you probably do not use it within a long period.

### COMPOSITION

- Subwoofer 1pc
- Signal input cable 1pc
- Satellite speaker 2pcs
- Operation manual 1pc
- Remote 1pc

### THE SKETCH MAP



**WINGS**  
HI-FI SYSTEM TECH

USER MANUAL  
2.1 CH SPEAKER



www.wingsmobile.com

