


2. After open the phone Bluetooth, Click the <**N19>** to Pairing

In the power-on state, quickly press the MFB button 5 times
 Turn off the headset after hearing the "Power off".
 The reset will be successful after rebooting.
 (If the above operation does not work, please try again)



Switch Song Adjust Volume X1: Click Once (2) 2S: Press and hold for 2 seconds X2: Click 2 times 3S: Press and hold for 3 seconds

Problem handling

① Can be connected but there is no sound: Click the headset to increase the volume.

② Headset cannot be charge: Clean the charging contact of the headset and the

charging case.

③ Headset cannot be connected: Reset the headset.

Activation & Warranty Permanent replacement of damaged, defective item or missing

components. Please activate via email below within 15 days.

Please clean the charging contacts of the earbuds and charging case frequently to avoid charging failures.

Safety Instructions

1. Keep the product away from extremely hot and cold environments, it will damage the battery and circuit.
2. Avoid liquid immersion into the product.
3. Do not disassemble the product.
4. Do not use concentrated chemical products or detergents to clean the product.
5. Use only SV/1A power supply. Connecting the power supply voltage too high may cause serious damage.
6. Do not randomly discard or place the product near fire or high temperature to avoid the danger of explosion.

Made in China
RoHS F© (€ 🗵 🔮 🖏 📳