

Thank you for choosing our dog training products. You and your pet deserve a companionship that include memorable moments and shared understanding together. Our mission is to ensure your pet's safety by providing you with the tools and techniques to successfully train your pet. If you have any questions, please, contact our customer service:

📞 www.tbi-pro.com

✉️ support@tbi-pro.com



CUSTOMER SERVICE:

Scan me to Email us:



Email us: support@tbi-pro.com

Scan me to Text us:



Text us: +1 800-674-9229

**JUST SCAN THE QR CODE WITH YOUR
IPHONE OR ANDROID CAMERA TO GET IN TOUCH WITH US**



IMPORTANT SAFETY INFORMATION

WARNING:

Not for aggressive dogs. DO NOT USE this product if your dog is aggressive or prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, consult your veterinarian or certified trainer. The Remote Training Collar MUST be used on healthy dogs only. We recommend you to take your dog to a veterinarian before using the collar if he is not in good health.

CAUTION:

RISK OF INJURY. Please, read the following instructions carefully in this guide. Proper collar fit is important. Because a loose collar may cause inconsistent performance. A collar worn for too long or made too tight on the pet's neck may cause skin damage ranging from redness to pressure ulcers (commonly known as bedsores).

- ⚠ Avoid leaving the collar on the dog for more than 12 hours per day
- ⚠ Try to reposition the collar on the pet's neck every 1 to 2 hours
- ⚠ Check the fit to prevent excessive pressure. Follow the instructions in this manual
- ⚠ Never contact a lead to the electronic collar. It will cause excessive pressure on the contacts
- ⚠ Wash the dog's neck area and the contacts of the collar weekly with a damp cloth
- ⚠ Examine the contact area daily for signs of rash or sores
- ⚠ If a rash or sore is found, stop using the collar until the skin has healed
- ⚠ If the condition persists beyond 48 hours, see your veterinarian

These steps will help keeping your pet safe and comfortable. Millions of pets are comfortable while they wear stainless steel contacts. Some pets are sensitive to contact pressure. You may find after some time that your pet is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, stop using until the skin has fully healed.

REMOTE



Tips:

- Press Channel button for 3 seconds to turn on the remote
- Press Channel button for 3 seconds to turn off the remote
- It will turn off the LCD display in 2 minutes automatically if there is no pressing

Power ON/OFF Button:

Press the button for 2 seconds to turn on the receiver with a vibration and press and hold for 3s to turn off the receiver with a beep.



Charging Port:

Fully charge will take around 2-3 hours.

LED Indicator:

LED Solid	LED Blinking
System Running / Fully Charged	Pairing Mode / Charging / Low Battery

Tips:

- When the receiver is low power, the LED Indicator will fast blink
- When the system is working or fully charged, the LED Indicator will be solid
- The receiver will go to Power Saving mode after 30 seconds if no movement or transmitted signal is detected

SETUP PROCEDURE:**1. Charge the remote and receiver**

- Please, fully charge the Remote and Receiver before you use the products
- Remote: Fully charged, The Red LED will become solid
- Receiver: Fully charged, the Red LED will become solid (The LED will be blinking if Low Power)
- The charging time takes around 2 to 3 hours. LED indicator on the Remote will be solid and LED indicator on receiver will be blinking when charging

DOG TRAINING COLLAR MANUAL

2. Pairing and Test the remote and Receiver (important)

1. Turn on the Remote Control, and turn off the Receiver.
2. Press and Hold the receiver Power On/Off Button  at least 5 seconds, then you will hear a Beep and the Red LED is flashing. (You will have 5 seconds to pair the device).
3. Press the Vibration button within 5 seconds to finish the pairing then you will hear a Beep.



To test if the Remote and Receiver are paired, press the Beep button,  the Receiver will beep every time you press the beep button. If there is no Beep, then repeat the pairing process.

Tips:

You can choose Channel 1 or Channel 2 to pair the Remote and Device. The system can pair 2 Receivers at the same time. If you can not pair the device successfully, it may be caused by signal interference. Please, change to another location. The Remote will go to Sleep Mode if you don't use it for 2 minutes or more, and the Receiver will go to Power Saving Mode if there is no movement for 30 seconds and the LED will be turned off. Any movement on the Receiver will activate the collar and any button you press on the Remote will activate the Remote.

Static Shock Test:

- Secure the included test Bulb Kit on the Receiver Collar's Contact Points
- Press the Shock button  to test the Shock Function
- The test Bulb will light up indicating that the Static Shock Stimulation works
- The higher the Static Shock Level is the brighter the light should be

**Vibration Test:**

- Press the Vibration button  to test the Vibration Function
- The Receiver Collar will vibrate indicating that the Vibration Function works

DOG TRAINING COLLAR MANUAL

Tips:

- When the receiver is low power, the LED Indicator will fast blink
- When the system is working or fully charged, the LED Indicator will be solid
- The receiver will go to Power Saving mode after 30 seconds if no movement or transmitted signal is detected

SETUP PROCEDURE:**1. Charge the remote and receiver**

- Please, fully charge the Remote and Receiver before you use the products
- Remote: Fully charged, The Red LED will become solid
- Receiver: Fully charged, the Red LED will become solid (The LED will be blinking if Low Power)
- The charging time takes around 2 to 3 hours. LED indicator on the Remote will be solid and LED indicator on receiver will be blinking when charging

2. Pairing and Test the remote and Receiver (important)

1. Turn on the Remote Control, and turn off the Receiver.
2. Press and Hold the receiver Power On/Off Button  at least 5 seconds, then you will hear a Beep and the Red LED is flashing. (You will have 5 seconds to pair the device).
3. Press the Vibration button within 5 seconds to finish the pairing then you will hear a Beep.

To test if the Remote and Receiver are paired, press the Beep button,  the Receiver will beep every time you press the beep button. If there is no Beep, then repeat the pairing process.

Tips:

You can choose Channel 1 or Channel 2 to pair the Remote and Device. The system can pair 2 Receivers at the same time. If you can not pair the device successfully, it may be caused by signal interference. Please, change to another location. The Remote will go to Sleep Mode if you don't use it for 2 minutes or more, and the Receiver will go to Power Saving Mode if there is no movement for 30 seconds and the LED will be turned off. Any movement on the Receiver will activate the collar and any button you press on the Remote will activate the Remote.

Static Shock Test:

- Secure the included test Bulb Kit on the Receiver Collar's Contact Points
- Press the Shock button  to test the Shock Function
- The test Bulb will light up indicating that the Static Shock Stimulation works
- The higher the Static Shock Level is the brighter the light should be

**Vibration Test:**

- Press the Vibration button  to test the Vibration Function
- The Receiver Collar will vibrate indicating that the Vibration Function works

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.