

Label and location

64 mm

Caution:

Please read the following warnings before using this product:

- **This product should not be used by children under 5 years of age.**
- **CHOKING HAZARD:** Keep product away from infants, children, and pets.
- Do NOT place in crib or bassinet with infants or an area where an infant may sleep.
- Do NOT expose this product to flame, cigarettes or excessive heat.
- Do NOT immerse product in liquids.
- Do NOT expose product or its internal components to liquids.
- Do NOT mix old and new batteries.
- Do NOT mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do NOT disassemble, modify, or attempt to short battery terminals or compartment.
- Do NOT leave product on or use product after batteries have lost their charge.
- Do NOT overtighten screws as it may cause the screws to strip and battery compartment will be difficult to open.
- Non rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- The supply terminals are not to be short-circuited.

Washing Instructions: SPOT CLEAN ONLY.

Mise en garde:


Veuillez lire les avertissements suivants avant d'utiliser ce produit:

- **Ce produit ne devrait pas être utilisé par des enfants âgés de moins de cinq (5) ans.**
- **RISQUE D'ÉTOUFFEMENT:** Garder le produit hors de portée des bébés, des enfants et des animaux.
- Ne PAS placer le produit dans un lit ou un berceau avec un bébé ou dans un espace où un enfant pourrait dormir.
- Ne PAS exposer ce produit aux flammes, aux cigarettes ou à une chaleur excessive.
- Ne PAS immerger le produit dans un liquide.
- Ne PAS exposer le produit ou ses composants internes aux liquides.
- Ne PAS mélanger des piles neuves et usagées.
- Ne PAS combiner les piles alcalines, standard (carbone-zinc) ou rechargeables (nickel-cadmium).
- Ne PAS désassembler, modifier ou tenter de mettre en court-circuit des bornes des piles ou le compartiment.
- Ne PAS laisser le produit allumé ou l'utiliser après que les piles ont perdu leur charge.
- Ne PAS trop serrer les vis. Cela peut les endommager, rendant difficile l'ouverture du compartiment de piles.
- Les piles non rechargeables ne doivent pas être rechargées.
- Les piles rechargeables doivent être retirées du jouet avant d'être chargées.
- Les piles rechargeables ne doivent être chargées que sous la supervision d'un adulte.
- Les bornes d'alimentation ne doivent pas être mises en court-circuit.

Instructions de lavage:

NETTOYAGE DE TÂCHES À LA MAIN UNIQUEMENT.

FCC ID:2ATXKEB780204 75867 0421



SWIFT
A

HAN
HAI

HA

1.7

ALL TAGS PLACED HERE
Manufacturing Tag
ON TOP
(See order below)

UNDER PENALTY OF LAW
 THIS TAG NOT TO BE REMOVED
 EXCEPT BY THE CONSUMER
 ALL NEW MATERIAL
 Consisting of
POLYESTER FIBER 100%
 REG. NO. UFB171C18
 Manufactured by the
 for the purpose of the
 and
 MADE FOR
 Issue Address of the Manufacturer
 251 Cortroy Avenue
 Cortland Manor, NY 13827
 Date of Delivery: _____
 Filling (in Number) 112828
 SHELL: POLYESTER FIBER 100%
MADE IN CHINA

FCC Label

○
 This pr
 you to c
 Di(2-ethyl
 which is
 of Ce