



**Interior Speaker System**



WIRELESS INTERIOR SPEAKER FOR SMARTPHONE, TABLET, PC OR MAC WITH BLUETOOTH

- This device is a household electromagnetic compatibility device.  
It is intended to be used in all regions.
- The radio equipment may have radio interference.
- Life safety related services are not available.

■ Table of Contents

**Starting**

Check Configuration ..... 04

Product Features ..... 05

Part Names & Functions ..... 06

**Using**

Get Ready ..... 07

Connecting ..... 08

**Other information**

Safety Instructions ..... 09

FAQ ..... 12

Copyright ..... 13

AS. .... 14

Product Specifications ..... 15

Product warranty ..... 16

## ■ Product Features

### Bluetooth

#### ■ Interior Wireless Speaker-Frame Type

- Frame your favorite image and use it as an interior accessory.


#### ■ Bluetooth 5.0

- Wirelessly play music with Bluetooth 5.0 enabled interior speaker
- Not available for external devices that do not support Bluetooth or NFC.

#### ■ Reference.

- You need to check if the device you want to connect to supports Bluetooth 5.0.
- If you connect with a device that is not approved by the Bluetooth SIG, it may not be compatible.

## ■ Check Configuration.




- Actual components may differ from the illustration, and accessories are subject to change without notice.
- The appearance and specifications of this product may change without prior notice for performance improvement.

## ■ Part Names & Functions

### ■ Front Side.



### ■ Under Side.



- ① Power cable connection terminal: You can connect the power cable.
- ② Bluetooth Pairing Button: You can play / pause Bluetooth pairing and music.
  - If power is turned on without an external device connected, the device enters the Bluetooth connection standby mode.
  - To replace the connected device, press the button for 3~5 seconds to switch to connection standby mode.
  - When playing music, press the button lightly to stop. Press the button again to play.
  - \* Press any button for 3~5 seconds to switch to connection standby mode.
- ③ Power Button: Press the button to turn the power on or off.

## ■ Get Ready

### Bluetooth

#### ■ Connecting the power

1. Connect the plug of the power cable to the power cable connector on the product.
2. Connect the other end of the cable to the power terminal.

#### ■ Power on

1. Press the power button on the bottom of the product.

#### [Reference]

When the power is turned on, the Bluetooth pairing standby sound will be heard and the connection standby mode will be entered.

## ■ CONNECTING

### ■ Bluetooth connecting

1. Turn on the Bluetooth function on the device (smartphone, tablet, PC, etc.) where you want to play music.
2. Select "NAPAL-Frame." From the Bluetooth connection list to pair.  
(Within 1m distance)
3. When pairing is complete, you will hear a connection completion sound and can play music.

#### [Reference]

Press and hold the Bluetooth pairing button while the Bluetooth is connected or in standby (3 to 5 seconds)

The Bluetooth connection will be disconnected and the device will resume to standby mode.



## ■ Safety Instructions.

### ▪ Warnings and Cautions During Installation.

- Install in a place without heat such as a heater. Overheating may cause fire and electric shock.
  - Use the rated voltage. It may cause product damage or electric shock.
  - Install in a dry place. It may cause product damage and electric shock by moisture.
  - Install in a large enough space in a well-ventilated place.
  - An increase in internal temperature may deform the product or cause a fire.
  - Install the product where there is no electromagnetic interference, which may cause product damage or electric shock.
  - Install in a dust free location. If there is a lot of dust, the product may malfunction.
  - Install in a place out of direct sunlight. The product is damaged.
  - Install in a place free of magnetic materials. Product malfunction and damage will occur.
- Do not leave the power cable in a traffic place. This could cause you to trip over, resulting in electric shock, fire, damage to the product and personal injury.

## ■ Safety Instructions.

### ■ Power Warnings and Cautions.

- To disconnect the power cable, grasp it by the plug. Pulling on the power cable may damage the wires, resulting in electric shock or fire.
- Remove the power cable and peripheral cables connected to the product during thunder and lightning, which may cause electric shock.
- When connecting the power cable, make sure that it is fully inserted. Incomplete connection may cause fire.
- Use a power outlet that is designed for computers with a grounding terminal, and do not use it at the same time as other electronic devices or heaters. Doing so may cause fire or damage to the product.
- Do not touch the power plug with wet hands. In addition, if there is moisture or dirt on the cord pins, dry them thoroughly or wipe them before use. There is a risk of electric shock from water.
- If you do not use the product for a long time, disconnect the power cable from the product. Dust may accumulate and ignite. There is a danger of electric leakage, electric shock or fire due to insulation deterioration.

## ■ Safety Instructions.

### ■ Warnings and Cautions When Moving

- Be sure to turn off the power before moving, as there is a risk of product damage and electric shock. Be sure to disconnect all cables before moving. There is a risk of product damage and electric shock.
- Do not impact the product while moving. It may cause product damage and personal injury.
- Do not throw away the product box for safe transportation of the product, and use it when moving it.

### ■ Warnings and precautions for care, use.

- Do not insert foreign objects into the product, such as the groove of the product or the power cable connection terminal. It may cause product damage or personal injury.
- When using Bluetooth, abnormal operation or noise may occur depending on radio wave interference or other environment.
- When connecting the amplifier to an ungrounded outlet, abnormal operation or noise may occur depending on the environment.
- When connecting the power to the amplifier, connect the adapter cord to the adapter jack on the rear of the amplifier and then plug it into an outlet.

■ FAQ

Bluetooth

Problem	solution
There is no sound.	Check that the power cable is connected correctly.
	Adjust the volume of the connected device.
Noise is heard.	Make sure there are no devices causing frequency interference nearby.
	Slowly move the connecting device to find the best location.
With a Bluetooth device No connection	Install the product within 1 m of the Bluetooth device.
	Unregister the device name registered in the connected device and connect again.
	Turn off the product, and turn it on again to connect.
Compatibility information Protection policy.	Wireless performance depends on Bluetooth wireless device technology, so refer to the manual of your Bluetooth device for details. NAPAL is not responsible for data loss or loss caused by using the device.

## ■ Copyright

NAPAL has the rights of patent, trademark, copyright, and other intellectual property rights related to this manual.

In other words, all contents of this manual may not be copied or reproduced in any form or by any means without prior approval from Trump.

Penalties may apply if you use all or part of the document.

Copyrighted content, such as software, sound recordings, and visuals, is protected in accordance with applicable laws, such as copyright law.

If you use this product to copy or distribute copyrighted contents without permission, you are legally responsible. The companies, institutions, products, people and events used in the application are not actual data.

We have no intention of associating any company, organization, product, person or event with this manual and should not infer it.

Complying with all applicable copyright laws is the responsibility of the user.

©2018 NAPAL Limited. All rights reserved.

## ■ AS

### ▪ How to get AS

If a problem occurs during the use of the product, please check the manual again and contact the NAPAL Service Center for an e-mail or telephone call.

### ▪ AS Information

TEL. 82-2-2318-5053

E-mail. [cs@thenapal.com](mailto:cs@thenapal.com)

31, Hasangok-ro, Hanam-si, Gyeonggi-do, Republic of Korea

operating time. 09: 00 ~ 18: 00 (Monday-Friday)

## ■ Product Specifications

▪ **Product Name : NAPAL - Frame**

▪ **Model Name : NL002**

▪ **SPEC**

- OUTPUT POWER : 20W
- AMP : D-CLASS Digital Amplifier
- SIZE : 750 X 500 X 53 mm
- I/O Port .
  - Power in : Power Connector (Max. Input current 12V, 2 A)
  - Wireless in : Bluetooth 5.0

▪ **RF**

- Frequency : 2402MHz~2480MHz
- RF POWER : under 3 mW.

■ Product warranty

- 1. This product is manufactured through strict quality control and inspection.
- 2. We will repair free of charge any failures that occur within the warranty period under normal use by the consumer. Even within the warranty period, a service fee will be charged if the warranty is covered by the warranty.
- 3. The warranty is valid only in Korea.
- 4. Please present this warranty when requesting repair.
- 5. The warranty period is as follows.

NAPAL-Frame	1year	
Accessories	1year	Power adapter
	Out of warranty	Manual

The warranty period is from the date of purchase.

Please refer to our website for details.

The accessories cannot be repaired.

The accessory will be replaced after the warranty period and is not included in the reason for the replacement.



### **FCC Warning Statement**

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

### **FCC RF Radiation Exposure Statement**

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

### **IC Warning Statement**

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage, et (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## ■ **Product warranty**

### ■ **Free Service Information**

If any abnormality occurs under normal use within the warranty period from the date of purchase, we will repair it free of charge.

### ■ **Paid Service Information**

Even if the warranty period has passed or is within the warranty period, the following cases are applicable to paid repair.

Failure due to natural disasters (fire, lightning, wind and flood damage) / Failure due to careless use (falling, flooding, shock, damage, excessive operation) Changes and repairs outside of an authorized service center / Loss of warranty, no seal from the store where you purchased, or altered items listed.



Interior Speaker System