



Dealyze


Tablet Manual

Table of Contents


Table of Contents	1
What's Included	2
Setting Up the Device	3
Using the Device	4
Service Information	5
Contact Information	6
FCC Warning	7

What's Included


(1) Tablet



Front



Front



Side



Bottom

1. I/O Port
2. Micro USB Port
3. Power Button
4. Lock Notch

(1) Locking Mechanism

(1) Micro USB Cable

(1) Power Brick

(1) Power Cable

Setting Up the Device

Powering On

1. Plug the Micro USB cable in the Micro USB port on the tablet and connect the other end directly into a computer USB port.
2. Connect the power cable to the tablet and power brick. Then plug it into the wall.
3. Press the Power button on the back of the tablet.

Connecting to WiFi

1. Once powered on, select 'WiFi Settings'
2. Choose the WiFi of your choice and connect.
3. Once connected, select the circle or square at the bottom to return to the main menu.

Logging In

1. Select 'Login'
2. Enter the store code '456123' and select 'Enter'
3. Select 'Confirm' and then leave the register code showing on the tablet before completing the steps on how to connect to a PC Register.

Connecting to a PC Register

1. On a PC Register, follow the directions displayed on the tablet to download the Register App.
2. Once downloaded, open and run.
3. Select 'Get Started'
4. If the tablet does not automatically connect in 10 seconds then enter the register code displayed on the tablet into the Register App and select 'Connect'

Create an Employee Code

1. Select 'Create an Account'
2. Fill the required fields and select 'Sign Up'.
3. Upon signing up, an email will be sent with training videos and material.

Secure the Tablet

1. Place one tablet next to one PC Register station. Make sure each tablet is facing the customers not the employee.
2. Locate an area to tether the locking mechanism around. Wrap the lock around secure area, thread through the loop, then attach the node to center slit on the base of the tablet stand. Keep the key in a safe place so you do not lose it.

Using the Device

Signing Up to the Program

- Enter a phone number into the tablet and select 'Enter'
- Read the Terms and Conditions and select 'Agree'
- Once signed up, a welcome text will be sent to the phone number.

Checking in to the Program

- Enter a phone number into the tablet and select 'Enter'

Browsing Through Rewards

- Sign up or check in.
- Swipe left or right to browse the available rewards and view point balance.

Adding Points

- Sign up or check in.
- Once a bill pay transaction is completed, select 'Pay Bill +100 Points' in the Register App.
- Confirm your identity.
- A message on the tablet will display the points awarded. Select done.

Redeeming a Reward

- Check in.
- Swipe to the desired reward and if eligible select 'Redeem'
- Enter the correct SKU into the Register App to complete.

Service Information

Accessing the Main Menu

- Starting with four fingers on the tablet screen, swipe down. This will reveal the following options:
 - Home
 - WiFi Settings
 - Pair Register
 - Applications
 - Check For Updates
 - Send Logs
 - Logout

Rebooting the Tablet

- Hold the power button for approximately 3 seconds.
- Select the option 'Reboot'.

Reconnecting to Wifi

- Access the main menu.
- Select the option 'WiFi Settings'.
- If connected to a network, tap it and select 'Forget Network'
- In the upper right corner, toggle the WiFi off then toggle back on.
- Reboot the tablet.
- Select 'WiFi Settings'
- Choose a WiFi network and connect.

Updating the Tablet

- Access the main menu.
- Select the option 'Check For Updates'
- If an update is available, it will begin to download.
- Once downloaded, select 'Install'

Logging Out

- Access the main menu.
- Select 'Logout'
- Enter the code '456123' and confirm the logout.

Powering Off

1. Hold down the Power Button on the tablet for ~5 seconds
2. Select the option 'Power Off'

Contact Information

If you have any questions or need any additional information please visit support.dealyze.com or email support@dealyze.com.

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Dealyze Inc. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.