




LED Floor Lamp

SKU: HLFL02M
[Instruction Manual]




Thank you for your purchase.
Please contact us if you have any questions.
We will get back to you within 24 hours.
Please attach your Order ID so that
we can serve you better.

CAUTION

1. Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue to assemble. Please send an email to our Customer Service immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keep children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.


Packing List



Part	Description	Quantity
A	Column Floor Lamp	1
B	Base	1
C	Screw	2
D	Screwdriver	1
E	Adapter Connector	1
F	Adapter	1
G	Remote Control	1
H	Instruction Manual	1


Assembly Instruction

Before assembly, please compare the accessories with the packing list to make sure all parts are present; install the adapter first to check if the product functions as intended.



1. Align the screw holes of the Base (B) with the screw holes at the bottom of the Column Floor Lamp (A) and fix them with Screws (C).
2. Connect the Adapter Connector (E) to the Adapter (F) and then spin the lock of the Adapter.
3. Place the floor lamp where you need it and plug it in the power supply.

Function



REMOTE CONTROL INSTRUCTIONS

1. ON/OFF Switch
2. Speed+/Speed-: Adjust the speed of the light change
3. Mode+/Mode-: Press +/- on Modes to get 358 lighting effects
4. Brightness-/Brightness+: Adjust the lamp's brightness
5. Auto: Short press to play 358 lights effects automatically; long press for 5 seconds to enter RGB colorful jump mode for lamp test;
6. Lock key: Remote control ID match, press 5 seconds for one-to-one match (green light flash 3 times), and press 5 seconds again to unmatched (white light flash three 3 times) ;
7. Set key: Adjust the RGB order, press 5 seconds and enter the setting menu, then press RGB buttons to adjust the RGB order, press R until lamp bar shows red, G until green, B until light bar shows blue, and exit after mediation.
8. RGBW static monochrome mode.

Cycle play effect: In automatic play mode, press "Setup" key once, and then press "Lock" key once, to grasp the current effect and then cycle play

Memory function: The floor lamp can remember the brightness and mode of the last adjustment.

Note

- There must be a direct line of sight between the Remote Control and the Signal Receiver (1).
- The Remote Control works within 26ft without obstacles, and the IR signal cannot pierce through glasses or walls.

Specifications

- Product Height: 44.9 IN.
- Diameter: Φ 2 IN
- Base Diameter: 6.9 IN.
- Line Length: 5.9 FT
- Materials: Plastic & Metal
- Input Voltage: 100-240VAC 60Hz
- Max. Wattage: 9W
- Operating Distance: 26FT

One Year Limited Warranty

EDISHINE warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation. Our dedicated customer service team will get back to you within 24 hours.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.