




| Time Zone               | America/Los_Angeles   |               | 18:02<br>00% 🕞 🗢              |
|-------------------------|---|---------------|-------------------------------|
| America/<br>Los_Angeles | America/Tijuana   |               | tb/s<br>12.00 V               |
|                         | America/Phoenix   |               |                               |
|                         | America/Chihuahua   |               |                               |
|                         | America/Bogota  |               | 5                             |
| Wi-Fi                   | Supports 2.4G WI-FI and mobile 2.4G hotspor<br>SMN                          | <b>?</b> 1    | 0521 PM                       |
| ( / с                   | onnect Wi-Fi  |               |                               |
|                         | SMN<br>ChinaNet-LEdV  | 0             | ⊌ 🕞 🛸<br>do/s<br>■ 0.00 V     |
|                         | THINKCAR-KEFU6  |               |                               |
|                         | H3C_3818A0  | -             |                               |
|                         | Add Clear Data System WiFi  | Next          | 5                             |
| e the Wi-Fi n           | tomatically search all available W<br>teeded. Tap "Next".It will automation | cally jump to |                               |
| SN SN                   | MOG HIS FUE CCM CAT HCAT EVAP   |               | 12:20 AM<br>00% 🔂 🗢           |
|                         |   |               | 12.00 V To be expanded Expand |
| Code/Freeze<br>Frame    | Erase Live Data Stream DTG  | Lookup        |                               |


\_\_\_\_\_












The SAR test distance is 0mm.




- Q: Communication error with vehicle ECU? A: Please confirm the following cases:
  Whether diagnostic connector is correctly connected.
  Whether ignition switch is ON.
  Or,send your vehicle's year, make, model and VIN number to us using
  End back for them for them to the induct of them. Feedback feature for timely technical assistance.
- Q: Why does the screen flash when the engine ignition starts? A: It is normal and caused by electromagnetic interference. Q: How to upgrade the system software? : 1. Power on the tool and ensure a stable Internet connection. 2. Go to "Settings"  $\rightarrow$  "Update"  $\rightarrow$  "App" ,tap "OTA" and then tap "check
- step. It may take a few minutes depending on the status of your network. After the upgrade is finished,the tool will automatically restart and display the main interface. Q: How to capture the screenshot?
  A: Pull down the taskbar and click on the screenshot icon to capture the current screen, it will be saved in the Photo Album module.

## network.

5

CDE900 Pro products through normal procedures. Provide free warranty within one year. MUCAR warranty including electronic products for damages caused by defects in materials or workmanship. Damages to the equipment or components caused by abusing, unauthorized modification, using for non-designed purposes, operation in a manner not specified in the instructions, etc are not covered by this warranty. The compensation for dashboard damage caused by the defect of this equipment is limited to repair or replacement. MUCAR does not bear any indirect and incidental losses. MUCAR will judge the nature of the equipment damage according to its prescribed inspection methods. Please contact Online Customers Service via the order interface. Service Line: 1-909-757-1959



Customer Service Email: service@mucarco.com Official Website: www.mucarco.com Products tutorial, videos, FAQ and coverage list are available on MUCAR

official website.

Q: What should I do when it prompts that the network is unavailable? A: Pull down the task bar, click the WIFI icon to connect to the available 13/ Warranty Terms This warranty applies only to users and distributors who purchase MUCAR

version" to enter the system upgrade interface. 3. Complete the process by following the instructions on the screen step by

\_\_\_\_\_