

折叠尺寸70\*80mm

前

后

<p><b>User's Guide</b> Binaural Wireless Bluetooth Earbuds Model:W9</p> <p>If the operation mode of the product has been changed, please refer to the actual product</p>	<p><b>Packing List</b></p> <ul style="list-style-type: none"> <li>Charging Case</li> <li>Bluetooth Earbuds*2</li> <li>User's Guide</li> <li>Ear tips*3</li> <li>Micro USB Cable</li> </ul> <p><b>Instruction</b></p> <ul style="list-style-type: none"> <li>Multi-function key</li> <li>LED Indicator</li> <li>Charging case</li> </ul>	<p><b>Product Parameter</b></p> <ol style="list-style-type: none"> <li>BT Version: BT5.0</li> <li>Stand-by Time: About 100 hours</li> <li>Call Time: About 240 mins</li> <li>Play Time: About 240 mins</li> <li>Earbuds Charging Time: About 60 mins</li> </ol> <p><b>Using Earbuds</b> Turn them on</p> <p>The earbuds will automatically turn on after taking out the charging case.</p> <p><b>Pair them with your device</b></p> <p><b>Wear your Earbuds</b></p> <p>Ear tips can be replace</p>	<p><b>Charge</b></p> <p>The case cover must be closed</p> <p>Use a charger under 5V/2A to charge charging case</p> <p><b>How to charge</b></p> <p>L: put left earbud in it: Red light: charging or no power need charging Blue light: full power, after 1 min turn off</p> <p>R: put right earbud in it: Red light: charging or no power need charging Blue light: full power, after 1 min turn off</p> <p>M: Light shows Blue: 30% - 100% power Light shows red: less than 30% power Fast flash red for 5 min: only left 1% power M turn off: The charging case will stop work in 15s</p>	<p><b>Instruction</b></p> <p><b>LED Indicator</b></p> <p><b>Charge</b></p> <ul style="list-style-type: none"> <li>Charging: Flashing Red</li> <li>Fully Charged: Steady Blue</li> <li>Light turn off after about 60s</li> </ul> <p><b>LED Indicator</b></p> <ul style="list-style-type: none"> <li>Charging: Flashing Red</li> <li>Fully Charged: Indicator turn off</li> </ul>	<p><b>TWS mode multi-function key</b></p> <p>Long press the earbud for about 3 seconds until the voice prompts "du" to switch songs(left is the previous song, right is the next song) Long press the left earbud or the right earbud casually for 1 second then release, you can open the function of voice trigger</p> <p>Press multi-function key (left or right): play/pause Double-click the left earbud: volume + Three-click the left earbud: volume -- Double-click the right earbud: volume + Three-click the right earbud: volume --</p>	<p><b>Charging case without led light on</b></p> <ol style="list-style-type: none"> <li>Take out the earbuds from charging case</li> <li>Press and hold 2s when earbuds indicator LED with red light release them</li> </ol> <p>When the earbuds and the charging case are in the shut down state, take out the earbuds from the charging case, press and hold 2S until the earbuds light is red, then release and it will start work about pairing mode.</p> <p>No light flashing</p> <p>Flashing blue and red</p>	<p><b>Pairing instructions (binaural mode) charging case to charge the earbuds</b></p> <p>Step 1: Open the charging case</p> <p>Step 2: Take out them from charging case, one of the earbuds (L) will flash red and blue within 5 seconds, and the other earbuds (R) will not flash. Notice: If you take out the left earbud in first, then must be take out the right earbud in 20 seconds.</p> <p>Flashing blue and red</p>	<p><b>Monaural Mode</b></p> <p>Step 1: Delete Bluetooth history record ("W wireless earphones") on your phone.</p> <p>Step 3: Turn on the cellphone Bluetooth, search for "W wireless earphones", clicking it, the left channel will prompt the "connected".</p> <p>connected</p>	<p>Step 2: Turn off Bluetooth on your phone.</p> <p>Step 3: Put earbuds into the charging case and close the charging case cover</p> <p>Step 4: Take out the one you want to use.</p> <p>Flash red</p>	<p>If take "L" out from charging case: Earbuds indicator flash red and blue within 3s. If take "R" out from the charging case: Earbuds indicator flash red and blue within 30s.</p> <p>Flash blue and red</p> <p>Step 5: Turn on Bluetooth on your phone, "L" search "W wireless earphones", "R"search "W wireless earphones R"</p> <p><b>Attention</b></p> <p>* When the three indicators of the charging case are light on, taking two earbuds out from the charging case, the left and right earbuds will be turn on automatically and go to the interconnection mode. After 1-2 seconds, the earbuds will pair successfully. Turn on the phone Bluetooth and start normal pairing.</p>	<p>If it has been paired before, it will be automatically paired successfully</p> <p>* When using dual earbuds, the effective distance between the left earbuds and the right earbuds is within 10 meters; when the two earbuds are separated by this distance, the playback of earbuds will be intermittent.</p> <p>* When the two earbuds are connected, only one has sound or (The solution is as follows):</p> <ol style="list-style-type: none"> <li>Turn off the earbuds;</li> <li>Then wear one to your ear, press and hold the multi-funton key for 12-13 seconds, you will hear the voice prompts "deng deng", then release. ( the other do the same operating mode)</li> <li>Hold and long press the right and left earbuds for 2 seconds at the same time, the indicator of left one will flash red and blue and the right no light flash. Then connect Bluetooth on yourmobile phone to Binaural TWS playback mode.</li> </ol> <p><b>Important Tips</b></p> <ol style="list-style-type: none"> <li>Please full charge the wireless eabuds at the first time.</li> <li>The earbuds underwater more than 5 minutes, you must be dry it first when you use it again. Otherwise, maybe sometimes the earbuds sound will be loud or small. Do not charge it with water directly.</li> <li>If the earbuds have water, you must be dry it first and then use it again.</li> <li>Waterproof performance is only for fresh water, tap water, sweat, swimming pool water and salt water. Under certain circumstances in the above five types of environment, the waterproof performance may not be applicable. Waterproof performance is not applicable in other liquid environments except the above five types.</li> <li>The earbuds is IPX7 waterproof, the charging case is not waterproof, please do not seep into the interior when using.</li> </ol> <p>FC CE RoHS</p>
--	---	--	--	---	--	---	---	---	--	--	---

**FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.