





USER MANUAL 使用手册 用户手册

Beans Pro 2

True Wireless Earphones

真無線藍牙耳機 真无线蓝牙耳机





INDEX

English	2
繁體中文	8
简体中文	14

CONTENTS




Charging Case



Erbuds



Type-C Cable



Eartips x 6 Pairs



Genuine Leather Strap

PICK THE RIGHT TIPS

i) Bass Eartips



The enhanced bass frequencies penetrate deeper into the ear canal, reducing the length of the sound waves' path, for an exceptional listening experience and maximum comfort. Lessens the hissing sounds for a more moderate, heavier sound and that enhances the sound of the music.

ii) Balance Eartips



The tight fit to the shape of the ear canal gives a super airtight effect, providing powerful noise cancellation and delivering the most realistic, high-resolution music without external interference.

OVERVIEW

A	Magnetic Closure	F	Charging Interface
B	Strap Holder	G	Microphone
C	Charging Pin	H	Touch Interface
D	Power Indicator	I	LED Indicator
E	Eartips	J	Type-C Input

NOISE CANCELLING

Tap **H** on Left side once to cycle through:

1. Active Noise Cancellation
2. Ambient Sound Mode ON
3. Ambient Sound Mode OFF



Active Noise Cancellation (ANC)

ANC microphone analyze and block out environmental and in-ear noises respectively.

Ambient Sound Mode


Ambient Sound Mode uses the microphones built into the left and right sides to allow you to hear ambient sound even while wearing headphones. Pay attention to the sounds around you to enjoy listening to music safely.

CHARGING

Charging Earbuds

★ White.....Charging


★ Off Charged




Charging Case (Unplugged)

★ ★ ★

Flash OFF OFF **LOW**
ON OFF ON  Placed
ON ON ON 



Charging the Case




Power Source
(DC 5V/1A)

*It is recommended to use the supplied charging cable to provide the optimal charging experience


Charging Case (Charging)

★ ★ ★

Flash OFF OFF 
ON Flash OFF 
ON ON Flash 
ON ON ON 



WEARING



PAIRING

Connects each other automatically.



1. L R flash blue ... Connecting
2. L flashes / 1S R flashes off ... Connected

"Bip" sound will be heard on each earbud.

Make sure your device's Bluetooth function is turned on

Look for "THECOOPIDEA BEANS PRO 2" from the bluetooth device list and press connect.

Indicator on Earbuds should be off if the it is successfully paired.



CONTROLS



Play/Pause	▷	●
Next track	▷▷	████ 2S
Previous track	KK	████ 2S
Volume up	◻◻◻	●●●
Volume down	◻◻	●●
ANC/Ambient ON/OFF	●	
Siri/Google assistant	●●●	●●●
Pick up call	📞	● or ●
Hang up	ⓘ	● or ●
Reject call	ⓘ	████ 2S or █████ 2S
Power On	Pick up earbuds from charging case	
Power Off	Place earbuds back to charging case	
Manual On	████ 3S	and █████ 3S
Manual Off	████ 5S	and █████ 5S
Auto Power Off	Idle for 10 minutes	

Hard Reset Turn off earbuds, hold both buttons for 10 secs and release, "Bip" sound will be heard. Earbuds will turn off, then on again, the earbuds will pair within 15 secs

● TAP █████ HOLD

*Control only applicable when both earbuds are used together

SPECIFICATION

Model Number	CP-TW08
Color Options	Sakura, Olive, Matt Black
Bluetooth Version	5.1
Frequency Range	20-20KHz
Impedance	32Ω
Sensitivity	98dB ± 3 dB
Driver Size	10mm
Support Codex	AAC, SBC
Support Profile	HFP, HSP, A2DP, AVRCP
Play Time	Up To 3H (ANC On), 4H (ANC Off)
OTG Play Time	Up To 21H (ANC On), 25H (ANC Off)
Standby Time	80H
Recharge Time	1H (Charging Case), 1H (Earphones)
Battery Capacity	380mAh (Charging case), 40mAh (Earphones)
Case Dimensions	47 x 47 x 30mm (LxWxH)
Case Net Weight	31g
Earbuds Dimensions	31 x 15 x 24mm (LxWxH) (Each)
Earbuds Net Weight	4g (Each)
Waterproof Rating	IPX5 (Earphones)
Safety Protections	Short Circuit, Over Charge, Over Discharge

WARNING

Always store the earbuds in the charging case and safely protected.

Avoid storing the earbuds in hot or cold environments to prevent depletion of the battery capacity

Avoid storing the earbuds for extended periods of time without recharging them.

If the earbuds or the charging case become dirty, it is recommended to clean them with a soft cloth that has been dampened with clean water.

The OS version of mobile devices may affect performance of BEANS PRO 2, it is recommended to update the OS of your mobile device to the latest version before use.

Don't put the BEANS PRO 2 into Charging case while there is moist. Doing so can cause severe damage to the electronics or housing of BEANS PRO 2. BEANS PRO 2 Charging case is not waterproof.

Store the product in a dry area. Keep away from fire, heat, moist and erosive materials.

Remove from power source once the product is fully charged. Extended periods of over-charging will decrease battery life.

It is strongly recommended to clean and dry BEANS PRO 2 properly when it has been exposed to water and sweat.

Do not use rough chemical such as soap or cleanser to scrub the product.

Do not disassemble, damage, or expose the product to water or fire. Warranty will be voided by any misuse of the product.

If the battery is expanded or emits smell, stop using the product immediately.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

We locate the MIC Logo and ID and the Product name, the Brand ,the Model name on the Color box and the instructions

#THECOOPIDEA #BOLDTOBEFREE

For other languages and
soft copy of the manual,
Scan:



 R 210-148022

FCC ID: 2AUDS-CP-TW08

Find out more at
www.thecoopidea.com



thecoopidea

Manufacturer: Dongguan Roker Electronics Co., Limited

Address: 6/F Guanghui Building Dongzheng Road,
Changping, Dongguan, Guangdong, China, 523570

Inspirations from New Zealand. Designed in Hong Kong.
Produced in China. Copyright 2020 The Coop Idea Ltd.