

Figure 5
General Appearance of the EUT




Figure 6
Inside Configuration of the EUT



Figure 7
Inside Configuration of the EUT




Figure 8
Inside Configuration of the EUT



Figure 9
Inside Configuration of the EUT




Figure 10
Inside Configuration of the EUT




Figure 11
Label of the Panel



Figure 12
Frontside of the Main Board




Figure 13
Backside of the Main Board




Figure 14
Inside Configuration of the EUT




Figure 15
Inside Configuration of the EUT




Figure 16
Inside Configuration of the EUT



Figure 17
Speaker




Figure 18
RF Module





Figure 19
Adapter**Figure 20**
Adapter


Figure 21
Adapter**Figure 22**
Adapter

Figure 23
Adapter



Figure 24
HDMI Cable

