
SZIG:55x55mm

Know about the Smart Gateway



This smart gateway, adopting super low power consumption wireless technology, can work with kinds of smart sensors and smart home appliances to build a smart home system and the gateway works as the central controller. Built-in Wi-Fi module support direct connection to user's home Wi-Fi network.



Blinking: The gateway enters Wi-Fi configuration mode OFF: No network connection ON: Connected to the Wi-Fi network

Reset or enter Wi-fi configuration mode: Press and hold the button for 5 seconds until the blue LED blinks. the gateway will enter Wi-fi configuration mode

Blinking: The gateway enters adding sub-device mode OFF: The gateway is under idle status

Ouick Installation Guide

1. (If you have installed the smart life APP on your mobile phone ,please go to step2)Scan below OR code or search Smart Life in APP Store or Google Play to install APP(new user must register account first).




3.(If the blue LED is blinking, please go to step4)

2.Connect mobile phone to your 2.4GHz Wi-Fi

router(with internet) and plug in the Smart

Gateway to outlet.

Pressing the button for 5 seconds until the blue LED blinks.



4.Run Smart Life APP, Click"+" at the top right corner **Option ONE:**

It will be discovered automatically as below. click "Go go add" and follow the in-app instructions to connect the smart gateway to your network.



Option ONE:

If it can't be discovered, please select Gateway Control-> Wireless Gateway(Bxx) to add it manually.then follow the in-app instructions to connect the smart gateway to your network.



5. Waiting for a few seconds, you can see the gateway is shown and you may rename it.



6. Press Done to finish the installation of gateway.

(9)

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
 Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
 This device complies with part 15 of the FCC Rules. Operation is subject to the
- following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.