

品牌

2020.08.17  
V1.0 首次创建

2020.10.27  
V2.0 首次创建

2020.11.18  
V3.0 首次创建

2020.12.16  
V4.0 首次创建

2021.06.03  
V5.0 首次创建

**ISEDIC RSS WARNING:**  
This device complies with ISEDIC licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.  
Le présent appareil est conforme aux CNR d'ISEDIC applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:  
(1) l'appareil ne doit pas produire d'interférence, et (2) l'appareil doit accepter toute interférence radioélectrique subie, même si l'interférence est susceptible d'en compromettre le fonctionnement.

**ISEDIC RADIATION EXPOSURE STATEMENT:**  
This equipment complies with ISEDIC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.  
Cet appareil est conforme aux limites d'exposition de rayonnement RF ISEDIC établies pour un environnement non contrôlé.

**DANS LA BOÎTE**  
Plaque murale x1 Câble USB x1  
Adhésif de fixation x1 Bloc d'alimentation x1  
Vis de fixation x1 Guide de démarrage rapide x1  
Caméra Wyze x1

**SETUP**  
➤ Téléchargez l'application Wyze et créez un compte.  
➤ Connectez la caméra à une prise de courant et attendez 20 secondes ou jusqu'à ce que la lumière de statut clignote jaune.  
➤ Appuyez sur le bouton SETUP pendant 3 secondes ou jusqu'à ce que la voix vous dise d'arrêter.  
➤ Suivez les instructions dans l'application Wyze pour terminer la configuration.

**INDICATEURS LUMINEUX LORS DE L'INSTALLATION**  
Lumière fixe rouge  
Le périphérique est sous tension et est en train de démarrer.  
Lumière clignotante rouge  
Le périphérique est prêt à se connecter.  
Lumière clignotante rouge et bleue  
Connexion en cours.  
Lumière clignotante bleue  
Le périphérique est connecté et fini sa configuration.  
Lumière fixe bleue  
Le périphérique fonctionne correctement.

**LIGHT INDICATORS AFTER SETUP**  
Solid red light  
Live stream is being viewed or a recording is in progress.  
Quickly flashing red light  
Siren is in use.  
Solid blue light  
The device is working properly and no operations are running (edited).

**QUICK START GUIDE**

**IN THE BOX**  
Wyze Cam x1 Indoor Power Adapter x1  
USB Cable x1 Mounting Tape x1  
Wall Plate x1 Mounting Screws x1  
Quick Start Guide x1

**SETUP**  
➤ Download the Wyze app and sign in or create an account.  
➤ Connect the camera to a power outlet and wait for 20 seconds or until the status light flashes red.  
➤ Press the SETUP button for 3 seconds or until there is a voice prompt.  
➤ Follow the instructions in the Wyze app to finish setup.

**LIGHT INDICATORS DURING INSTALLATION**  
Solid red light  
The device is powered on and initializing.  
Flashing red light  
The device is ready to connect.  
Flashing red & blue lights  
Connection is in progress.  
Flashing blue light  
The device is connected and finishing setup.  
Solid blue light  
The device is working properly.

**LIGHT INDICATORS AFTER SETUP**  
Solid red light  
Live stream is being viewed or a recording is in progress.  
Quickly flashing red light  
Siren is in use.  
Solid blue light  
The device is working properly and no operations are running (edited).

**FCC WARNING:**  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC RADIATION EXPOSURE STATEMENT:**  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

**NEED HELP?**  
Contact our support team: <https://support.wyze.com>  
Join our Community: <https://wyze.com/community>

**VOUS AVEZ BESOIN D'AIDE?**  
Contactez nos magiciens du soutien: <https://support.wyze.com>  
Rejoignez notre communauté: [wyze.com/community](https://wyze.com/community)

Scale 1:1 Unit:mm

型号:WYZEC3  
规格:WYZEC3-KS  
ZP01 V5.0  
物料编码:

产品名 ▶ WYZEC3小方

印刷颜色 ▶ CMYK

物料材质 ▶ 105g无光铜

样品

设计于 ▶ 曹佳丽

成品尺寸 ▶ 60 × 50mm

特种工艺 ▶

样品数量 ▶