
SVN FUTURE 360 SPEAKER



FUTURE360SP

Operation Instructions

Preface

Thanks for selecting the bluetooth speaker manufactured by our company. In order to let you easily experience the product, we equip the instructions for use with detailed contents. You can obtain the product-related introduction, use method and other knowledge. Please carefully read the instructions before use. We apologize for the inconvenience in case of any error in printing or translation.

Note

In order to correctly use the player and guarantee good performance of the player, please correctly read and comply with:

- . Do not seriously impact the host.
- •Do not contact benzene, thinner and other chemical drugs.
- •Do not get close to intense magnetic field and electric field.
- ·Please avoid direct sunlight or heating appliance.
- ·Do not conduct disassembly, repair or reconstruction independently.
- •Do not use the player or earphone during riding and driving of automobile or motorcycle, so as to avoid danger.
- •Do not listen with high volume, so as to avoid adverse effect on hearing.
- Please classify and appropriately handle the discarded package, battery and old electronic products.

Functional characteristics

[Bluetooth audio] Bluetooth 4.2+BR+EDR, receiving range 10-15m. [Bluetooth call] Clear voice, no echo

[MP3 play] Directly play MP3 file stored in TF card

[Audio input] Stereo audio input interface, easy connection with the computer, digital music player, mobile and other audio source devices. [Breakpoint memory] Automatic memory of the track and volume at last quit.

[Built-in battery] Built-in rechargeable Li-ion Battery, environmentalfriendly, energy saving and practical

[TWS pairing] turn on two stereos at the same time, press the pairing


button, the scheme will be automatically matched, and the left and right sound channels will be distinguished to achieve stereo effect.

[IP X6 waterproof] adopts IP X6 waterproof design, which can resist the water flow from nozzles in all directions and the music rhythm will not break.

Operation to play music

The speaker is in the default bluetooth mode at startup, insert TF card for automatic identification and play. The principle of latter priority is adopted, and the play mode can also be switched automatically; Insert the audio signal wire for automatic switching. For detailed function operation, please read the "definition of key and jack functions of the product".

Definition of key and jack functions of the product



- 1. [Pairing key] long press: TWS paired ; short press: mode switched.

 Betton Light: White color means button wake-up, without operation, it extinguish automatically after 15 seconds
- 2. [Volume plus key] long press: next track; short press: Volume plus.
- 3.[play / pause key] long press: disconnect / reconnect bluetooth; short press: play / pause; short press / hang off key in the call mode; Long press for reject, Double click for callback; automatic

search key in FM mode.

- 4.[Previous track] long press: previous track; short press: Volume reduction.
- 5.[Power key] on/off
- 6. [reset key] Reset and restart the stereo
- 7. [Micro interface] DC 5V charging interface.
- 8. [AUX interface] external audio input interface;
- 9. [TF card interface] insert TF card to play mp3 music.
- 10. [Ball indicator] Four Levels LED power display
- 11.[MIC] The microphone can be used to enhance the effect of the call

Introduction to the indicator lamp

Power indicator: the power is displayed by four levels of LED. When charging, it flashes upward and lights up when full

Bluetooth connection method

- Start the machine by default into bluetooth mode, the machine emits prompt tone, the status indicator light slowly flashes
- 2. Turn on the bluetooth function of the mobile device (mobile, computer and so on), and search the bluetooth device.
- 3. Manually click it, the device will be automatically paired and connected, and the prompting voice will be sent after successful connection. (It is not required to enter the password generally. Prompt the output password for the special model, and enter "0000")
- The device successfully paired will be automatically connected at next startup.

Remarks: the bluetooth will automatically search the device for pairing and connection within 10s after entering the bluetooth mode, and shall be manually connected after 10s.

TWS Pair Methods

- 1. Turn on the two sound systems at the same time, and enter bluetooth mode. At this time, the status indicator light flashes slowly.
- 2. Long press the "pair" button of any stereo, and the machine emits a prompt sound and enters the TWS search state. At this time, the status indicator light flashes quickly.
- When the TWS pair is successfully matched, the machine will emit a
 prompt sound. At this time, the host status indicator light will be slow
 and the auxiliary status indicator light will be long.

Note: the function of TWS must be matched before connecting to mobile devices (mobile phones, computers, etc.). Otherwise, the function of TWS cannot be matched after connecting to mobile devices (mobile phones, computers, etc.).

Method for charging

Insert an end of the power cord into [Micro interface] of the machine, and insert USB at the other end into USB interface of the computer, or connect it with standard 5V 1000mA charging interface. The "red lamp" is on during charging, and the "red lamp" is off after charging.

Remarks: the overcharge protection circuit is built in the machine, which can be connected with the computer or charger for use for a long term, and the battery is fully charged after about 3 hours; each endurance time of the battery will be different due to use time and volume.

Low battery

In case of low battery, the system sends voice prompt and be shut down automatically. Please timely charge at the moment; if the machine is not used for a long term, it shall be charged at least once in a month, which can protect the battery, and extend the battery life.

Technical specifications

Output power: 5W *2

Operating voltage: 3.7V Frequency response: 65Hz-16KHz

Signal-to-noise ratio:≥85dBA

Distortion degree: <10%

Audio input: Bluetooth, TF card, AUX
Support MP3: Bit rate, 32Kbps-320Kbps

Horn impedance: 4Ω

Input power: Built-in rechargeable Li-ion Battery or

external DC5V

Adjustment form: Key adjustment Input sensitivity: 500±50mV

FAQ

1. Q: automatic shutdown after startup?

A: the battery level is insufficient. Please timely charge, and it is suggested to use after charging for two hours.

2. Q: automatic shutdown or restart after the play blue lamp flashes rapidly?

- A: the battery level is insufficient. Please timely charge, and it is suggested to use after charging for two hours.
- 3. Q: it cannot be charged?
 - A: please use the charging cable with the machine, and confirm that the voltage of USB interface accessed is normal.
- 4. Q: the charging red lamp is not on or dark?
 - A: normal. When the battery has been or is about to be fully charged, the charging red lamp will not be on or will be very dark. In a word, the lower the battery level is, the brighter the red lamp is during charging.
- 5. O: the horn has no sound?

A: confirm it at the playing state in TF/ bluetooth /FM/AUX mode, and adjust it to the appropriate volume.

- 6. O: AUX has no voice?
 - A: 1. Please use the audio cable with the machine, and select the correct audio output interface.
 - 2. Insert UBS cable, and it cannot enter AUX mode. AUX mode can only be switched by pressing [O/PLAY] key. Whether the volume of external audio source device is turned on.
- 7. Q: the bluetooth cannot be automatically connected?
 - A: 1. Only the paired device will be automatically connected.
 - 2. If the bluetooth device is turned on after the speaker enters bluetooth for 10s, the speaker will not be automatically connected. For detailed use method of the bluetooth, please refer to "Article 6" of the instructions
- 8. Q: the bluetooth has no sound?
 - A: 1. please confirm whether the bluetooth has been successfully connected.
 - 2. whether the volume of the bluetooth device has been turned on.
- 9. O: the key has no function or has wrong function?
 - A: start up after shutdown.

Package accessories

Bluetooth Clock Speaker 1 set
Data cable 1 pcs
Instructions 1 copy

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.