Product Structure



User Guide

- Make sure to read this User Guide before use and use the product safely and correctly
- . The images in this User Guide may differ from the actual appearance, and some contents are subject to change without notice for performance improvement
- · Please install and update the latest version of the SmartThings App from Galaxy Store.
- Galaxy Friends App; 2.1.15.46 or higher version Galaxy Wearable App: 2.2.32 or higher version
 Smart Things App: 1.7.50 or higher version
- *App contents support: S8 or subsequent terminals, Android OS 9 or higher
- *If the watch and terminal are not linked, the installation of contents will be limited.
- · Wireless charge and contents compatible models: Galaxy Watch3, Galaxy Watch Active 1, 2
- * Contents installation for Galaxy Watch Active 1,2 models will be supported by subsequent SW undates

How to Use

- Link the Watch and terminal. * For detailed information about how to link, see the Watch User Manual.
- Connect the charger and power system, and put the terminal aside.
- Place the Watch on the charger.
- When wireless charging starts. installation of the Samsung Galaxy Friend Service begins
- When the Galaxy Friend Service is installed, theme contents are applied to the terminal, and the Watch Face App is installed in the Watch.
- The contents are maintained even if you remove the Watch from the charger



· The charger shall be near the power socket during charging, and keep it within easy reach.

 A mobile network or WiFi connection is required for contents update.

Precautions in Charging





Align the charger and the Watch in the center as shown in Figure 1/2/3. If the Watch is placed incompletely as shown in Figure 4. charging efficiency may be lower.

To use the product, the back of the Watch needs to touch the wireless charge zone, and dropping the Watch on the product may cause product damage. This subjects it to damages caused by user negligence. Please take precautions for use.

FCC Instructions

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

FCC Radiation Exposure Statement This equipment complies with ECC radiation exposure limits set forth for an uncontrolled environment, This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with

any other antenna or transmitter.

Precautions for Safety

- * Please read and follow the instructions carefully before use.
- This product is for age 14 and up.
- · Do not keep it in damp or high temperature conditions
- · Keep the product away from children and
- · This product can be exchanged or compensated based on the consumer dispute settlement standards notified by the Korea Fair Trade Commission
- Failure caused by user negligence / mishandling, or arbitrary dissembling / change / damage is not subject to free
- · Do not touch the product with wet hands. Avoid serious impact such as dropping the
- · The suitable service temperature range is 0° C~35°C, and anything out of this range may damage the product.
- Make sure no conductive substance (liquid. dust, metal powder, pencil lead, etc.) is inserted into the connection unit of the charger (connection lack and plug for exterior connector).
- Do not remodel / dissemble / repair the product arbitrarily.

Precautions in Connection

- · Connect to a charger or a PC to use the product,
- · Make sure no foreign substance (liquid, dust, etc.) is inserted into the connection lack in power system. Otherwise, it may cause trouble in product operation.
- · Do not move the Watch while it is being charged, Otherwise, it may limit smooth charging and the provision of contents.

Product A/S Related Inquiry

- For A/S requests, please provide the product model name, failure status, and contact information
- · For product failure, please contact the Mobee-K Customer Center (+82-70-4492-1261).
- The product warranty period is 6 months from the date of purchase. For failures caused by a defective product, the product will be exchanged after collecting / inspecting the product.
- · Please use the designated delivery company for product collection. You may be charged the difference in delivery cost for using an undesignated delivery company. For islands or isolated regions, you may be charged an additional cost.
- · A delivery cost will be charged to collect/return the product due to failure caused by user negligence.

Free Services

You can request free services for failures from normal use within the warranty period, but non-failure services or failure caused by user negligence are excluded.

Componention

		Compensation	
User Damage Type		Within Warranty Period	After Warranty Period
Product damage during delivery	Within 7 days from pur- chase	Product exchange or refund from the place of purchase	
Perfor- mance or functional failure from normal use conditions within A/S period (6 months)	Within 7 days from pur- chase	After product collection and defect check by Mobee-K Customer Center, exchange the product or get a refund from the place of purchase	N/A
	Within 7 days from pur- chase	After defect check by Customer Center, exchange the product	

*Refund: Purchase place/Purchase price refund (submit the purchase receipt)

Paid Services

If the failure is not a product defect but is caused by user negligence, check the User Guide first because a service request can be charged regardless of the warranty period.

User	Compensation		
Damage Type	Within Warranty Period	After Warranty Period	
Failure caused by intentional user negligence	If partial repair is not possible, you can buy the product at the selling price (within A/S inventory holding period (6 months) from the point of purchase)	N/A	

- Failure caused by user negligence
 Failure caused by negligence in use (flooding, destruction, damage) Failure caused by not complying with the
- "Precautions" in the User Guide

2. Other cases Failure caused by natural disaster (fire, salt

damage, flood damage, lightning, etc.

* Services may be rejected in the following cases. Arbitrary remodeling / change /

- reproduction, or using non-genuine or
- imitation parts
 Replacement by a part different from the one used at the point of purchase (or A/S)

Product specifications

	•
Product Name	Smart Watch Wireless Charge
Model Name	MS230
Manufacturer	Mobee-K
Manufactur- ing Country	Republic of Korea
Warranty Period	6 months
Contact for the Person in Charge of AS	Mobee-K+82-70-4492-1261
Input Power	5V==/1A
RF	BLE 4.2, 2.4GHz
Product Material	PC
Composition	Smart Watch Wireless Charge Inner Box, User Guide

	initial bong oper datac
Size	Exterior (Width X Length X Height) 45 X 45 X 13.4 (mm)
Weight	26g

DC. IEC 60417-5031 (2002-10)

This product is powered by USB source. (DC 5 V. 1A or less)



mobee·K

www.mobee-k.com

OFFICE

A/S Inquiry +82-70-4492-1261

4F. 10. Seongnam-daero

Republic of Korea

926beon-gil, Bundang-gu,

Seongnam-si, Gyeonggi-do.

SMART WATCH

WIRELESS CHARGER

Smart Watch Wireless Charger User Guide