

Kodak Wall Frame App - Create Playlists 建立播放列表

Kodak Wall Frame App

Step 1-4
步驟 1-4

Step 5
步驟 5


Step 6
步驟 6

Step 7
步驟 7


Step 8
步驟 8




Playlist created
播放列表已建立



Assign playlists to your
picture frame
將播放列表連結到相框



Select your picture frame
選擇您的相框




Assign playlists to Wall frame
completed
Playlist title showed below
成功將播放列表連結到相框
播放列表的名稱會顯示在底部

Kodak Wall Frame App - Assign playlists to the Frame 加入播放列表到相框

Kodak Wall Frame App

Step 1
步驟 1




Select the frame
選擇相框

Step 2
步驟 2



Press on the playlist
按一下播放列表

Step 3
步驟 3




Select the playlist you want
to add and press confirm
選取需要加入的播放列表
按確認鍵




"Playlist Updated" will be show on
the frame
“播放列表更新”的提示會顯示在
相框

Remote Control Functions 遙控器按鈕功能

Kodak Wall Frame



To access your playlist page directly, press "Playlist" button
播放清單鍵：直接進入播放清單頁面




Remote Control Functions 遙控器按鈕功能 - 主頁面

Kodak Wall Frame





To access frame setting, press "menu" button
按菜單按鈕進入相框設置



Remote Control Functions - Display Menu Settings 遙控器按鈕功能 - 主頁面設置


Kodak Wall Frame



- Photo display duration adjustment 照片顯示時長調整
- Photo display mode adjustment (zoom in / zoom out / fade in & out / None)
照片顯示模式調整 (放大/縮小/淡入/淡出/無)
- Photo transition mode adjustment (fit to screen / fill screen / full screen)
照片過渡模式調整 (適合屏幕/填充屏幕/全屏)

Display Menu Settings 主頁面設置

Kodak Wall Frame



Adjust the frame brightness level
自由調整亮度

Display Menu Settings 主頁面設置

Kodak Wall Frame






Photo LIVE: ON/OFF 開/關

Time display: AMPM/24HRS/OFF 時間顯示: AMPM/24小時制/關

Change the photo display orientation: Horizontal/Vertical
更改顯示方向: 水平/垂直

Display Menu Settings 主頁面設置

Kodak Wall Frame





Connect to WiFi 連接到WiFi

Launcher information, include information on binded user ID, email, product serial number, launcher version, local storage information and "Check for Update" button
相框系統信息, 包括已綁定的用戶ID, 電子郵箱, 產品序列號, 相框系統版本, 本地存儲信息, 檢查更新按鈕等

Time zone: selection of Time Zone 時區: 選擇時區

Support languages: selection of language at launcher
支持語言: 選擇相框系統的使用語言

Restore Settings: restore to factory settings
恢復設置: 恢復出廠設置



Kodak Wall Frame App - Photo LIVE 動態照片

Kodak Wall Frame App

Photo LIVE 動態照片




Photo LIVE * is a feature which supports Live Photos™ playback. The Photo LIVE pictures will automatically activate. Delivering a more interactive product for a unique viewing experience.

iOS users -
Live Photos™ ** are motion pictures taken by iOS devices. Users can also create live photo through our conversion service with your video files

Android users-
Android users can create their own Photo LIVE media through video upload. Video can be converted through our conversion service with your video files

Photo LIVE * 是一項支援 Live Photos™ 播放的功能。Photo LIVE 照片能自動激活，提供更具互動性的產品，帶來獨特的觀看體驗。

iOS 用戶 -
Live Photos™ ** 是 iOS 設備拍攝的動態影像。用戶還可以通過我們的視頻文件轉換服務創建實時照片。


Android 用戶 -
Android 用戶可以通過視頻上傳，創建自己的 Photo LIVE 照片。使用您的視頻通過轉換服務進行轉換。

*Photo LIVE features brief action playback of your Live Photo™
**Live Photo™ is a trademark of Apple Inc., registered in the U.S. and other countries

Kodak Wall Frame App - Photo LIVE 動態照片


Kodak Wall Frame App

Step 1
步驟 1




Select the Photo LIVE conversion service under the conversion tap in E-shop
在E-shop的轉換服務選擇 Photo LIVE 動態照片轉換

Step 2
步驟 2




Select the video in which you would like to convert
選擇你要轉換的影片

Step 3
步驟 3



Users are able to trim and preview a "15 seconds clip" with the selected video and convert to Photo LIVE media
用戶可剪輯與預覽最多15秒的片段轉換成動態照片

Step 4
步驟 4



After press the trim video button, users can confirm the conversion by clicking "Free"
確定剪輯後，用戶可按下“免費”以確定轉換

Kodak Wall Frame App - E-shop 電子商店

Kodak Wall Frame App



E-shop 電子商店

With each Kodak Wall Frame, users can access the Art World image gallery, which features a vast range of works from global artist collaboration.

Each user can access unlimited artworks from around the world, available to download and display on their Kodak Wall Frame at home.

通過每個Kodak Wall Frame，用戶可以訪問Art World 在線圖像庫，其中包含全球藝術家合作的大量作品

每個用戶都可以進入來自世界各地的無限藝術品，在家里的KODAK掛牆式相框上下載和播放


Kodak Wall Frame App - E-shop 電子商店

Kodak Wall Frame App



Kodak Wall Frame App - E-shop Global Artists 全球藝術家收藏

Kodak Wall Frame App



Art World
Art World


Art World is an online image gallery created for global artists who would like to share their works with audience around the world.

Unique and renowned artworks that are founded in world museums, galleries & online are also available for purchase.

Art World是一個在線圖片庫，專為希望與世界各地客戶分享作品的藝術家而設

客戶可以從我們的圖片庫中找到和購買

Kodak Wall Frame App - E-shop Photo Preview 電子商店照片預覽




Users can select their favorite photos and preview it on their Kodak Wall Frame before confirmation on purchase. Choose photo and Click "Preview", the selected photo will be displayed with watermark on your Picture Frame.

*Watermark only applies to preview photos

Kodak用戶可以在購買確認前，選擇自己喜歡的照片並在Kodak 掛牆式相框上進行預覽。請注意，所有預覽照片的會加上Kodak水印作標記。

*水印照片僅適用於預覽



Kodak Wall Frame App - E-tokens & Shopping Cart 電子代幣和購物車

Kodak Wall Frame App



E-tokens & Shopping Cart 電子代幣和購物車

E-tokens are used for purchasing artwork. The amount of E-tokens required depends on the different artists, photos and types of services.


The amount of E-tokens can be found on the right hand corner of the wallet button.

電子代幣用於購買照片。所需的電子代幣數量取決於不同的藝術家，照片和服務類型。

電子代幣的數量可以在帳戶錢包按鈕的右上角找到。

Kodak Wall Frame App - System Default Albums 應用程式 - 系統預設相冊

Kodak Wall Frame App



System Default Albums
系統預設相冊

Kodak wall Frame


1. “E-shop” Album
(All purchased photos will be saved in this album)
2. “Conversion”Album
(Video to Photo LIVE photo conversions will be saved in this album)

Kodak 挂墙式相框

1. “電子商店”相冊
(所有購買的照片將保存在此相冊中)
2. “轉換”相冊
(視頻到Photo LIVE實時照片轉換將保存在此相冊中)

Kodak Wall Frame App - Others 應用程式 - 其他

Kodak Wall Frame App



Add friends / Social function
增加好友 / 社交功能

Search and add friends through the user community.
Add & share contents with your friends.


*All the purchased photos are not allowed to share.

通過Kodak用戶社區搜索和添加朋友。
與朋友一起添加和分享內容。

*所有購買的照片將無法分享。

Kodak Wall Frame App - Others 應用程式 - 其他

Kodak Wall Frame App



Personal Profile Settings

個人資料設置

You are able to change your user profile password, language settings, notification settings, other additional profile and access to user application version for reference.

Key Feature Settings :

- Purchase History
- Change password
- Notification settings
- Redemption
- Firmware version for Kodak Wall Frame

您可以更改用戶配置文件密碼，語言設置，通知設置，其他附加配置文件和訪問用戶應用程序版本以供參考。

主要功能設置：

- 購買歷史
- 更改密碼
- 通知設置
- 代碼兌換
- 手機應用程式韌體版本


Kodak Wall Frame App - Others 應用程式 - 其他

Kodak Wall Frame App


Step 1
步驟 1

Step 2
步驟 2


Step 3
步驟 3



Press on the frame you want to restore to factory setting.
點擊需要恢復出廠參數設定的相框



Press on the reset button under Factory Reset
點擊恢復出廠參數設定的恢復鍵



Select "Yes, I agree." and press OK
點選“同意”後按確定

Restore to factory settings
恢復設置: 恢復出廠參數設定

For reset to factory default:

Select frame with online status then go to setting page and select sign out.

恢復出廠參數設定

選擇相框後, 去設定介面並選擇登出

Kodak Wall Frame App - Others 應用程式 - 其他

Kodak Wall Frame



The frame reset to factory default
User can set up the frame now
(User guide page 4 for more details)

相框已經恢復為出廠設定
用戶可以開始設置相框
(參考用戶指南 page 4)

Additional Instructions of The Remote Control 遥控器说明

Kodak Wall Frame

Additional instructions:

There is a button cell inside remote control, In order to reduce the risk of accidental ingestion by children, please note:

1.This product contains a lithium button/coin cell battery.

If a new or used lithium button/coin cell battery is swallowed or enters the body, it can cause severe internal burns and can lead to death in as little as 2 hours. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

2. Replaceable button cell should be noted: even used cells may cause damage, so please do not throw away optionally ;Batteries should be disposed of properly and kept away from children.

3. If not used for a long time, please insert the insulation piece into the box.



Please remove the insulating strip before use

IC Caution.

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

***IC warning**

To maintain compliance with Canada's RF exposure guidelines, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

FCC Caution.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

***FCC warning**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



The Kodak trademark, logo and trade dress are used under license from Kodak. © 2019 by Maxtalent Industrial Limited. All rights reserved, All information contained in this document is subject to change without notice.

Made In China

FC IC CE RoHS