


Key Features

- Bluetooth headphone
- Built-in microphone for hands-free use with Bluetooth enabled devices
- Comfortable adjustable design
- Connects automatically to previously connected devices

Description of Parts:



1	TF card slot
2	Volume down/Previous track
3	Volume up/Next track
4	Build-in Microphone
5	AUX port
6	LED Light Indicator
7	Type-C Charging port
8	Phone/Play/Pause button
9	Power on/off button

INSTRUCTIONS FOR USE

Charging Instructions

- Connect the USB charging cable to a computer USB port and the Micro USB plug to the charging port of the device. The Red LED light turns on while the device is charging. It takes 1-1.5 hours for the unit to fully charge. When the battery is fully charged, the red light will be off.

Turning on/off the device

- Press the “⏻” button for 2-4 seconds to turn ON or OFF the device with indication tone.

Pairing the device with Bluetooth devices (phone or music device)

- Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer’s instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your device, select the “ ” from the list of available Bluetooth devices.
- You can now start to use the device.
- Please note pairing mode on the device will last for around 10 minutes. If no devices are paired within around 10 minutes the device will power off automatically.
- If pairing is unsuccessful, turn off the device and try again.
- Once you have paired the Bluetooth Headphone with a device, the Headphone will remember this device and will pair automatically when the device’s Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

Function Summary

Control Function—Music mode

Function	Operation	Button
Increase Volume	Playing music	A long press on the “V+” button
Decrease Volume	Playing music	A long press on the “V-” button
Pause/Pause	Playing music	A short press on the “▶ ” button
Previous track	Playing music	A short press on the “V-” button
Next track	Playing music	A short press on the “V+” button

Control Function—Phone mode

Function	Operation	Button
Answer a call	Incoming Call	Short press the “▶ ” button once
End a call	Incoming Call	Short press the “▶ ” button once.
Reject call	Incoming call	Long press the “▶ ” button
Increase Volume	During a call	A long press on the “V+” button
Decrease Volume	During a call	A long press on the “V-” button
Redial last number	Standby mode and connected to a device	Short press the “▶ ” button twice

Please Note

- Not all mobile phones support all the functions listed above. Please refer to your cell phone’s user manual for further information.
- Certain functions and indication tone maybe vary depending on your mobile phone.

TF Card/Bluetooth function switch

1. Insert the TF card to change to music mode automatically.
2. Short press the “⏻” button to switch mode.

Google & Siri :

Press the “▶||” button three times to activate Google or Siri then one press to quit.

LED indicator

Please refer to the below tables for a list of the LED status while using the Bluetooth Headphone.

Charging Indication

LED indicator	Status of the BT Headphone
Solid Red LED	Charging
Solid Blue LED	Charging Completed

LED Indication

LED indicator	Status of the BT Headphone
LED red and blue lights flashing alternately	Pairing mode
The blue light is always on	Connected
The blue light flashed slowly	Playing music / Phone mode

Specifications

Bluetooth version	V5.0
Operating distance	33 Feet
Working time (in middle volume)	4-6 hours
Charging input voltage	DC 5V
Charging time	About 1-1.5 hours
Driver unit :	40mm 32Ω
Built-In Battery	150mAh

(Note: Battery life & charging time may vary based on usage & types of devices used.)

FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.—Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.