




1. Remove back cover.




2. Take out the battery.  
Lift from white arrow.



3. Insert nano SIM card by following the arrows.  
For extra memory, insert micro SD card.  
To remove, press the edge of the SIM or SD card.




4. Place back battery and back cover.  
Fully charge the phone.



5. Press and hold the power button  
to turn on your Fairphone 3.

## New to Android?



Don't worry, we'll go through it with you,  
step by step. Check out  
[fairphone.com/androidsetup](https://fairphone.com/androidsetup)


FAIRPHONE

Change  
is in your  
hands

To learn more on how we're  
changing the industry go to  
[fairphone.com/story](https://fairphone.com/story)

0000-0000-000000-0005

No charger,  
less electronic  
waste




We don't include a USB-C cable and  
power adapter because you probably  
already own one. If not, order at  
[fairphone.com/charger](https://fairphone.com/charger)

Your phone  
your style,  
your  
accessories



Discover our Fairphone 3  
accessories collection at  
[fairphone.com/accessories](https://fairphone.com/accessories)

Care for the  
planet



Recycling your old phone is a great  
way to show you care about fairer  
electronics. Learn how at  
[fairphone.com/recycle](https://fairphone.com/recycle)

Designed  
to open



With the screwdriver in this box, you  
can take extra care of your phone.  
Find out more at  
[fairphone.com/support](https://fairphone.com/support)

FAIRPHONE

Take a  
look  
inside

Fairphone 3  
Quick Start Guide