




1. External Photograph of EUT

Brand Name: FAIRPHONE; Model Name: FP4






Brand Name: FAIRPHONE; Model Name: FP4





Brand Name: FAIRPHONE; Model Name: FP4






Brand Name: FAIRPHONE; Model Name: FP4



Brand Name: FAIRPHONE; Model Name: FP4





Brand Name: FAIRPHONE; Model Name: FP4





2. Photograph of Accessory

Brand Name: FAIRPHONE; Model Name: FP4

List of Accessory:

Specification of Accessory				
AC Adapter	Brand Name	FAIRPHONE	Model Name	A2009-03
Battery	Brand Name	FAIRPHONE	Model Name	F4AC1
USB Cable 1	Brand Name	FAIRPHONE	Model Name	11001-8A090-02 (USB 3.2)
USB Cable 2	Brand Name	FAIRPHONE	Model Name	11001-8A090-02 (USB 2.0)
Earphone	Brand Name	FAIRPHONE	Model Name	JWEP1212-C15H

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: FAIRPHONE; Model Name: FP4




Brand Name: FAIRPHONE; Model Name: FP4

AC Adapter



Brand Name: FAIRPHONE; Model Name: FP4




Brand Name: FAIRPHONE; Model Name: FP4



Brand Name: FAIRPHONE; Model Name: FP4

USB Cable 1



Brand Name: FAIRPHONE; Model Name: FP4

USB Cable 2



Brand Name: FAIRPHONE; Model Name: FP4

