#### Greetings from realme Mobile

This guide will show you how to use the phone and its important functions. You may also visit realme official website to get more information about the phone.



## ⚠ Warning:

- Do not place the phone or battery near or inside the heating equipments, cooking equipments, high pressure vessels (such as microwave ovens, induction cooker, electric oven, heater, pressure cooker, water heater, gas stove, etc.) to prevent the battery overheating which may lead to an explosion.
- The original charger, data cable and battery shall be used. Unapproved chargers, data cables, or batteries that are not certified by the manufacturer may result in electric shock, fire, explosion, or other hazards.

- ▶ When charging, please place the device in an environment that has a normal room temperature and good ventilation. It is recommended to charge the device in an environment with temperature ranging from 5°C~35°C.
- ▶ Back cover can't be removed.

### How to reboot the phone:

Press and hold the Power Button and Volume Up Button at the same time until the realme boot animation is displayed to reboot the phone.

How to transfer contents from an old phone to a new phone
You can quickly transfer contents such as photos, videos, music, contacts,

You can quickly transfer contents such as photos, videos, music, contacts, messages, and apps from an old phone to a new phone via realme Clone Phone. I Scan the QR code below using the old phone to install "Clone Phone"; on the new phone, launch "Clone Phone" directly.



2 Follow the prompts on the screen to complete the data transfer.

#### Standard accessories

You are provided with the following standard accessories:

1 Phone, 1 Charger, 1 USB data cable, 1 Safety Guide, 1 Quick Guide,

1 SIM Elector Tool. 1 Protective Case.

# Specification

Product		RMX3286	
Main screen pa	rameter	16.8cm(6.6")	
Dimension		164.1×75.5×8.5(mm)	
Battery		4880mAh/18.88Wh(Min) 5000mAh/19.35Wh(Typ)	
Camera		16 Megapixels Front 50 Megapixels + 2 Megapixels + 2 Megapixels Rear	
Operating temperature		0°C-35°C	
SAR Values	FCC SAR	1.136W/kg(Head) 0.992W/kg(Body)	

Radio Waves Specifications					
Radio	Frequency (V1.0)	Frequency (V2.0)	Frequency (V3.0)	Max. Output Power	
		33.5dBm			
GSM		31dBm			
		30.5dBm			
WCDMA	Band 1	Band 1	Bands 1/2/4	24.3dBm	
WCDIMA	Bands 5/8	Bands 5/8	Bands 5/8	24.5dBm	
LTE FDD -	Bands 1/3	Bands 1/3	Bands 1/2/3/4/66	24dBm	
	Bands 5/8	Bands 5/8/20/28	Bands 5/8/12/17/26/28	24.5dBm	
	-	Band 7	Band 7	24.4dBm	
	_	_	Band 20	25dBm	
LTETDD	Bands 38/40/41		Bands 38/41	24dBm	
Bluetooth	2.4-2.4835GHz			15dBm(EIRP)	
2.4G Wi-Fi		21dBm(EIRP)			
5G Wi-Fi	5	20dBm(EIRP)			
og ski-Fi		20dBm(EIRP)			
NFC	_	_	13.56MHz	≤42dBuA/m @10m	

◄ عند الشحن، يرجى وضع الجهاز في بيئة ذات درجة حرارة غرفة عادية وتهوية جيدة, يوصى بشحن الجهاز في بيئة ذات درجة حرارة تتراوح بين 5 درجة منوية و35 درجة منوية. كيفية إعادة تشغيل الهاتف:

كيفية نقل المحتويات من هاتف قديم إلى هاتف جديد

يمكنك نقل محتويات مثل الصور و الفيديو هات والموسيقي وجهات الاتصال و الرسائل والتطبيقات من هاتف قديم إلى هاتف جديد بسرعة عبر تطبيق نسخ الهاتف من realme.

> ا امسح رمز QR أدناه باستخدام الهاتف القديم لتثبيت "نسخ الهاتف"; وعلى الهاتف الجديد، افتح "نسخ الهاتف" مباشرة.




٢ اتبع التعليمات الموجودة على الشاشة لإكمال نقل البيانات.

### الملحقات القياسية

سيتم تزويدك بالملحقات القياسية التالية: سيتم تزويدك بالملحقات القياسية التالية: ۱ هاتف: ۱ شاهن، سماعة أذن ۱ أداد لإنخال وإخراج بطاقة SIM ۱ كابل بيانات USB ۱ دليل أمان، ۱ دليل سريع.

# خالص التحيات من الهاتف المحمول realme

وَّ سيظهر لك هذا الدليل كيفية استخدام الهاتف ووظائفه الهامة. يمكنك أيضًا زيارة موقع الويب الرسمي للهاتف realme للعصول على مزيد من المعلومات هول الهاتف.



#### ئحذیر:

- ◄ لا تضع الهاتف أو البطارية بالقرب من أجهزة التسخين أو الطبخ أو الأولني ذات الضغط الطابي أو بداخلها (على سبيل المثال أقران الميكروريف والعرف الذي يمعل بالتت والفرن الكيريشي والسخان والموق الذي يعمل بالضغط وسخان الهياه وموقد الغاز، وما إلى ذلك و لكلك فنع سخورة البطارية بدرجة مفرطة مما قد يتنسب في حدوث الفجار.
  - پنصح باستخدام الشاحن و البطارية و كابل البيانات الأصليين فقد تتسبب الشواحن أو
     كابلات البيانات أو البطاريات غير المعتمدة من الشركة المصنعة في حدوث صدمة كهربائية أو حريق أو انفجار أو مخاطر أخرى
    - ◄ الغطاء الخلفي لا يمكن نزعه.

مواصفات الموجات اللاسلكية						
أقصى طاقة إخراج	التر دد (۷3.0)	التر دد (۷2.0)	التردد (V1.0)	لاسلكي		
33.5dBm	850MHz/900MHz					
31dBm	1800MHz			GSM		
30.5dBm	1900MHz					
24.3dBm	Bands 1/2/4	Band 1	Band 1	WCDMA		
24.5dBm	Bands 5/8	Bands 5/8	Bands 5/8			
24dBm	Bands 1/2/3/4/66	Bands 1/3	Bands 1/3	LTE FDD		
24.5dBm	Bands 5/8/12/17/26/28	Bands 5/8/20/28	Bands 5/8			
24.4dBm	Band 7	Band 7	_			
25dBm	Band 20	_	-			
24dBm	Bands 38/41	Bands 38/40/41		LTETDD		
15dBm(EIRP)	2.4-2.4835GHz			Bluetooth		
21dBm(EIRP)	2.4-2.4835GHz			2.4G Wi-Fi		
20dBm(EIRP)	5.15-5.35GHz; 5.47-5.725GHz			5G Wi-Fi		
20dBm(EIRP)	5.725-5.85GHz					
≤42dBuA/m @10m	13.56MHz	_	_	NFC		

		المواصفات الفنية	
RMX3286		طراز المنتج	
6.6 بو صة	خصائص شاشة العرض الرئيسية		
164.1×75.5×8.5 (ماليمتر )	الابعاد		
4880mAh/18.88Wh(Min) 5000mAh/19.35Wh(Typ)	البطارية		
16 ميجابكسل أمامية 50 ميجابكسل + 2 ميجابكسل + 2 ميجابكسل خلفية		الكاميرا	
35℃ — 0℃	درجة حرارة التشغيل		
ارد <sup>ا</sup> س) 1.136W/kg (جسم) 0.992W/kg	FCC SAR	قیم SAR	

## FCC Regulations:

This mobile phone complies with part 15 of the FCC Rules.

- Operation is subject to the following two conditions: (1) This device may not cause harmful interference.
- (2) this device may not cause narmal interference.

  (2) this device must accept any interference received, including interference that
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

### FCC Note:

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 1.5 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/per/e-affcrief after searching on FCC ID-2AIJYERMX3286

For this device, the highest reported SAR value for usage against the head is 1.136 W/kg, for usage near the body is 0.992 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 15 mm between the unit and the human body. Carry this device at least 15 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 15mm between this device and your body.

body. RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

# Regulatory

Steps to search E-label: Go to Settings -About Phone - Certificate Information.

realme

**Quick Guide** 

RMX3286

realme



