




### VHT40 CHANNEL 3 CARRIER LEVEL




### VHT40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




### VHT40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### VHT40 CHANNEL 6 CARRIER LEVEL




VHT40 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




VHT40 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




VHT40 CHANNEL 7 CARRIER LEVEL




VHT40 CHANNEL 7, SPURIOUS  
30 MHz ~ 3 GHz




VHT40 CHANNEL 7, SPURIOUS  
2 GHz ~ 25 GHz




### VHT40 CHANNEL 8 CARRIER LEVEL




### VHT40 CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




### VHT40 CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




### VHT40 CHANNEL 9 CARRIER LEVEL




VHT40 CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz





VHT40 CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 1 CARRIER LEVEL




802.11ax-20 CHANNEL 1, SPURIOUS  
30 MHz ~ 3 GHz



### 802.11ax-20 CHANNEL 6 CARRIER LEVEL




### 802.11ax-20 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




### 802.11ax-20 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




### 802.11ax-20 CHANNEL 10 CARRIER LEVEL




802.11ax-20 CHANNEL 10, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 10, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 11 CARRIER LEVEL




802.11ax-20 CHANNEL 11, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 11, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11ax-40 CHANNEL 3 CARRIER LEVEL




### 802.11ax-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




### 802.11ax-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### 802.11ax-40 CHANNEL 6 CARRIER LEVEL




802.11ax-40 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 7 CARRIER LEVEL



802.11ax-40 CHANNEL 7, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 7, SPURIOUS  
2 GHz ~ 25 GHz







802.11ax-40 CHANNEL 8 CARRIER LEVEL




802.11ax-40 CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz



802.11ax-40 CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz





802.11ax-40 CHANNEL 9 CARRIER LEVEL




802.11ax-40 CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz

802.11ax-40 CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




Aux. Antenna

802.11b CHANNEL 1 CARRIER LEVEL



802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz



802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz



802.11b CHANNEL 6 CARRIER LEVEL

