




VHT40 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




VHT40 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




VHT40 CHANNEL 9 CARRIER LEVEL




VHT40 CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




VHT40 CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 1 CARRIER LEVEL




802.11ax-20 CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 6 CARRIER LEVEL




802.11ax-20 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 11 CARRIER LEVEL




802.11ax-20 CHANNEL 11, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 11, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 3 CARRIER LEVEL




802.11ax-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 6 CARRIER LEVEL




802.11ax-40 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 9 CARRIER LEVEL



802.11ax-40 CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




MIMO-Main Antenna

802.11b CHANNEL 1 CARRIER LEVEL



802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL




802.11b CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




### 802.11g CHANNEL 1 CARRIER LEVEL




### 802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz



### 802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




### 802.11g CHANNEL 6 CARRIER LEVEL







802.11g CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 11 CARRIER LEVEL




802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 CHANNEL 1 CARRIER LEVEL



802.11n-20 CHANNEL 1, SPURIOUS  
30 MHz ~ 3 GHz



802.11n-20 CHANNEL 1, SPURIOUS  
2 GHz ~ 25 GHz



802.11n-20 CHANNEL 6 CARRIER LEVEL

