




802.11ax-20 MHz CHANNEL 10, Carrier level




802.11ax-20 MHz CHANNEL 10, Reference level




802.11ax-20 MHz CHANNEL 10, Band Edge




802.11ax-20 MHz CHANNEL 11, Carrier level




802.11ax-20 MHz CHANNEL 11, Reference level




802.11ax-20 MHz CHANNEL 11, Band Edge




802.11ax-40 MHz CHANNEL 3, Carrier level




802.11ax-40 MHz CHANNEL 3, Reference level




802.11ax-40 MHz CHANNEL 3, Band Edge




802.11ax-40 MHz CHANNEL 7, Carrier level




802.11ax-40 MHz CHANNEL 7, Reference level




802.11ax-40 MHz CHANNEL 7, Band Edge




802.11ax-40 MHz CHANNEL 8, Carrier level




802.11ax-40 MHz CHANNEL 8, Reference level




802.11ax-40 MHz CHANNEL 8, Band Edge




802.11ax-40 MHz CHANNEL 9, Carrier level



802.11ax-40 MHz CHANNEL 9, Reference level




802.11ax-40 MHz CHANNEL 9, Band Edge




Aux. Antenna


802.11b CHANNEL 1, Carrier level




802.11b CHANNEL 1, Reference level




802.11b CHANNEL 1, Band Edge




802.11b CHANNEL 11, Carrier level




802.11b CHANNEL 11, Reference level




802.11b CHANNEL 11, Band Edge




802.11g CHANNEL 1, Carrier level




802.11g CHANNEL 1, Band Edge




802.11g CHANNEL 11, Carrier level




802.11g CHANNEL 11, Reference level




802.11g CHANNEL 11, Band Edge




802.11n-20 CHANNEL 1, Carrier level




802.11n-20 MHz CHANNEL 1, Reference level





802.11n-20 MHz CHANNEL 1, Band Edge



802.11n-20 MHz CHANNEL 11, Carrier level




802.11n-20 MHz CHANNEL 11, Reference level







802.11n-40 CHANNEL 3, Carrier level




802.11n-40 MHz CHANNEL 3, Reference level




802.11n-40 MHz CHANNEL 3, Band Edge




802.11n-40 MHz CHANNEL 9, Carrier level




802.11n-40 MHz CHANNEL 9, Reference level



802.11n-40 MHz CHANNEL 9, Band Edge




VHT(20 MHz) CHANNEL 1, Carrier level



VHT(20 MHz) MHz CHANNEL 1, Band Edge



VHT(20 MHz) MHz CHANNEL 1, Reference level



VHT(20 MHz) MHz CHANNEL 1, Band Edge

