




802.11n-40 MHz CHANNEL 4, Reference level





802.11n-40 MHz CHANNEL 4, Band Edge




802.11n-40 MHz CHANNEL 8, Carrier level




802.11n-40 MHz CHANNEL 8, Reference level




802.11n-40 MHz CHANNEL 9, Carrier level




802.11n-40 MHz CHANNEL 9, Reference level




802.11n-40 MHz CHANNEL 9, Band Edge




VHT(20 MHz) CHANNEL 1, Carrier level




VHT(20 MHz) CHANNEL 1, Reference level





VHT(20 MHz) CHANNEL 1, Band Edge




VHT(20 MHz) CHANNEL 11, Carrier level




VHT(20 MHz) CHANNEL 11, Reference level




VHT(40 MHz) CHANNEL 3, Carrier level




VHT(40 MHz) CHANNEL 3, Reference level




VHT(40 MHz) CHANNEL 3, Band Edge




VHT(40 MHz) CHANNEL 4, Carrier level




VHT(40 MHz) CHANNEL 4, Reference level




VHT(40 MHz) CHANNEL 4, Band Edge




VHT(40 MHz) CHANNEL 7, Carrier level




VHT(40 MHz) CHANNEL 7, Reference level




VHT(40 MHz) CHANNEL 7, Band Edge




VHT(40 MHz) CHANNEL 8, Carrier level




VHT(40 MHz) CHANNEL 8, Reference level



VHT(40 MHz) CHANNEL 8, Band Edge




VHT(40 MHz) CHANNEL 9, Carrier level







VHT(40 MHz) CHANNEL 9, Reference level





VHT(40 MHz) CHANNEL 9, Band Edge




802.11ax-20 MHz CHANNEL 1, Carrier level




802.11ax-20 MHz CHANNEL 1, Reference level




802.11ax-20 MHz CHANNEL 10, Carrier level




802.11ax-20 MHz CHANNEL 10, Reference level



802.11ax-20 MHz CHANNEL 10, Band Edge




802.11ax-20 MHz CHANNEL 11, Carrier level







802.11ax-20 MHz CHANNEL 11, Reference level




802.11ax-20 MHz CHANNEL 11, Band Edge




802.11ax-40 MHz CHANNEL 3, Carrier level




802.11ax-40 MHz CHANNEL 3, Reference level




802.11ax-40 MHz CHANNEL 3, Band Edge




802.11ax-40 MHz CHANNEL 4, Carrier level



802.11ax-40 MHz CHANNEL 4, Reference level



802.11ax-40 MHz CHANNEL 4, Band Edge



802.11ax-40 MHz CHANNEL 7, Carrier level

