




802.11ax-40 MHz(RU106) CHANNEL 7




802.11ax-40 MHz(RU106) CHANNEL 8



802.11ax-40 MHz(RU106) CHANNEL 9




802.11ax-40 MHz(RU242) CHANNEL 3



802.11ax-40 MHz(RU242) CHANNEL 6





802.11ax-40 MHz(RU242) CHANNEL 7



802.11ax-40 MHz(RU242) CHANNEL 8

802.11ax-40 MHz(RU242) CHANNEL 9



Aux. Antenna

802.11b CHANNEL 1




802.11b CHANNEL 6




802.11b CHANNEL 11




802.11g CHANNEL 1




802.11g CHANNEL 6




802.11g CHANNEL 11




802.11n-20 MHz CHANNEL 1




802.11n-20 MHz CHANNEL 6




802.11n-20 MHz CHANNEL 11




802.11n-40 MHz CHANNEL 3




802.11n-40 MHz CHANNEL 6




802.11n-40 MHz CHANNEL 9




VHT(20 MHz) CHANNEL 1




VHT(20 MHz) CHANNEL 6




VHT(20 MHz) CHANNEL 11




VHT(40 MHz) CHANNEL 3



VHT(40 MHz) CHANNEL 6




VHT(40 MHz) CHANNEL 9




802.11ax-20 MHz(SU) CHANNEL 1




802.11ax-20 MHz(SU) CHANNEL 6



802.11ax-20 MHz(SU) CHANNEL 11



802.11ax-40 MHz(SU) CHANNEL 3




802.11ax-40 MHz(SU) CHANNEL 6




802.11ax-40 MHz(SU) CHANNEL 9




802.11ax-20 MHz(RU26) CHANNEL 1




802.11ax-20 MHz(RU26) CHANNEL 6




802.11ax-20 MHz(RU26) CHANNEL 11




802.11ax-20 MHz(RU52) CHANNEL 1




802.11ax-20 MHz(RU52) CHANNEL 6



802.11ax-20 MHz(RU52) CHANNEL 11




802.11ax-20 MHz(RU106) CHANNEL 1




802.11ax-20 MHz(RU106) CHANNEL 6




802.11ax-20 MHz(RU52) CHANNEL 11



802.11ax-40 MHz(RU26) CHANNEL 3




802.11ax-40 MHz(RU26) CHANNEL 6







802.11ax-40 MHz(RU26) CHANNEL 9




802.11ax-40 MHz(RU52) CHANNEL 3




802.11ax-40 MHz(RU52) CHANNEL 6




802.11ax-40 MHz(RU52) CHANNEL 9




802.11ax-40 MHz(RU106) CHANNEL 3



802.11ax-40 MHz(RU106) CHANNEL 6




802.11ax-40 MHz(RU106) CHANNEL 9



802.11ax-40 MHz(RU242) CHANNEL 3



802.11ax-40 MHz(RU242) CHANNEL 6



802.11ax-40 MHz(RU242) CHANNEL 9

