



MIMO-Main Antenna


802.11b CHANNEL 1




802.11b CHANNEL 6




802.11b CHANNEL 11




802.11g CHANNEL 1




802.11g CHANNEL 6




802.11g CHANNEL 11




802.11n-20 MHz CHANNEL 1




802.11n-20 MHz CHANNEL 6




802.11n-20 MHz CHANNEL 11




802.11n-40 MHz CHANNEL 3




802.11n-40 MHz CHANNEL 4




802.11n-40 MHz CHANNEL 6




802.11n-40 MHz CHANNEL 8




802.11n-40 MHz CHANNEL 9




VHT(20 MHz) CHANNEL 1




VHT(20 MHz) CHANNEL 6




VHT(20 MHz) CHANNEL 11




VHT(40 MHz) CHANNEL 3




VHT(40 MHz) CHANNEL 4




VHT(40 MHz) CHANNEL 6




VHT(40 MHz) CHANNEL 7




VHT(40 MHz) CHANNEL 8




VHT(40 MHz) CHANNEL 9



802.11ax-20 MHz(SU) CHANNEL 1




802.11ax-20 MHz(SU) CHANNEL 6




802.11ax-20 MHz(SU) CHANNEL 10




802.11ax-20 MHz(SU) CHANNEL 11



802.11ax-40 MHz(SU) CHANNEL 3




802.11ax-40 MHz(SU) CHANNEL 4



802.11ax-40 MHz(SU) CHANNEL 6




802.11ax-40 MHz(SU) CHANNEL 7




802.11ax-40 MHz(SU) CHANNEL 8




802.11ax-40 MHz(SU) CHANNEL 9




802.11ax-20 MHz(RU26) CHANNEL 1




802.11ax-20 MHz(RU26) CHANNEL 6




802.11ax-20 MHz(RU26) CHANNEL 10




802.11ax-20 MHz(RU26) CHANNEL 11




802.11ax-20 MHz(RU52) CHANNEL 1




802.11ax-20 MHz(RU52) CHANNEL 6




802.11ax-20 MHz(RU52) CHANNEL 10




802.11ax-20 MHz(RU52) CHANNEL 11




802.11ax-20 MHz(RU106) CHANNEL 1




802.11ax-20 MHz(RU106) CHANNEL 6




802.11ax-20 MHz(RU106) CHANNEL 10




802.11ax-20 MHz(RU160) CHANNEL 11




802.11ax-40 MHz(RU26) CHANNEL 3



802.11ax-40 MHz(RU26) CHANNEL 4




802.11ax-40 MHz(RU26) CHANNEL 6







802.11ax-40 MHz(RU26) CHANNEL 7




802.11ax-40 MHz(RU26) CHANNEL 8




802.11ax-40 MHz(RU26) CHANNEL 9



802.11ax-40 MHz(RU52) CHANNEL 3



802.11ax-40 MHz(RU52) CHANNEL 4



802.11ax-40 MHz(RU52) CHANNEL 6

