




VHT20 CH1




VHT20 CH2




VHT20 CH3




VHT20 CH4



VHT20 CH5



VHT20 CH6




VHT20 CH9




VHT20 CH10




VHT20 CH11



VHT40 CH3



VHT40 CH4




VHT40 CH5




VHT40 CH6




VHT40 CH7




VHT40 CH8




VHT40 CH9




802.11ax-20 MHz(SU) CH1




802.11ax-20 MHz(SU) CH2



802.11ax-20 MHz(SU) CH3




802.11ax-20 MHz(SU) CH4



802.11ax-20 MHz(SU) CH5



802.11ax-20 MHz(SU) CH6



802.11ax-20 MHz(SU) CH8



802.11ax-20 MHz(SU) CH9



802.11ax-20 MHz(SU) CH10



802.11ax-20 MHz(SU) CH11



802.11ax-40 MHz(SU) CH3



802.11ax-40 MHz(SU) CH4



802.11ax-40 MHz(SU) CH5



802.11ax-40 MHz(SU) CH6




802.11ax-40 MHz(SU) CH7



802.11ax-40 MHz(SU) CH8




802.11ax-40 MHz(SU) CH9




802.11ax-20 MHz(RU26) LOW CHANNEL



802.11ax-20 MHz(RU26) MIDDLE CHANNEL



802.11ax-20 MHz(RU26) HIGH CHANNEL



802.11ax-20 MHz(RU52) LOW CHANNEL



802.11ax-20 MHz(RU52) MIDDLE CHANNEL



802.11ax-20 MHz(RU52) HIGH CHANNEL



802.11ax-20 MHz(RU106) LOW CHANNEL



802.11ax-20 MHz(RU106) MIDDLE CHANNEL




802.11ax-20 MHz(RU106) HIGH CHANNEL




802.11ax-40 MHz(RU26) LOW CHANNEL



802.11ax-40 MHz(RU26) MIDDLE CHANNEL




802.11ax-40 MHz(RU26) HIGH CHANNEL



802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL



802.11ax-40 MHz(RU52) HIGH CHANNEL





802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL



ANT 1:

802.11b CH1



802.11b CH2



802.11b CH3



802.11b CH6



802.11b CH10



802.11b CH11



802.11g CH1




802.11g CH2




802.11g CH3




802.11g CH4



802.11g CH6



802.11g CH9




802.11g CH10




802.11g CH11




802.11n-20 MHz CH1




802.11n-20 MHz CH2



802.11n-20 MHz CH3




802.11n-20 MHz CH4




802.11n-20 MHz CH6




802.11n-20 MHz CH9



802.11n-20 MHz CH10



802.11n-20 MHz CH11




802.11n-40 MHz CH3




802.11n-40 MHz CH4




802.11n-40 MHz CH5




802.11n-40 MHz CH6




802.11n-40 MHz CH7




802.11n-40 MHz CH8



802.11n-40 MHz CH9



VHT20 CH1




VHT20 CH2




VHT20 CH3




VHT20 CH4




VHT20 CH5



VHT20 CH6




VHT20 CH9




VHT20 CH10




VHT20 CH11



VHT40 CH3




VHT40 CH4



VHT40 CH5



VHT40 CH6






VHT40 CH7



VHT40 CH8



VHT40 CH9



802.11ax-20 MHz(SU) CH1



802.11ax-20 MHz(SU) CH2



802.11ax-20 MHz(SU) CH3



802.11ax-20 MHz(SU) CH4



802.11ax-20 MHz(SU) CH5



802.11ax-20 MHz(SU) CH6



802.11ax-20 MHz(SU) CH8



802.11ax-20 MHz(SU) CH9



802.11ax-20 MHz(SU) CH10



802.11ax-20 MHz(SU) CH11



802.11ax-40 MHz(SU) CH3



802.11ax-40 MHz(SU) CH4



802.11ax-40 MHz(SU) CH5



802.11ax-40 MHz(SU) CH6



802.11ax-40 MHz(SU) CH7



802.11ax-40 MHz(SU) CH8



802.11ax-40 MHz(SU) CH9



802.11ax-20 MHz(RU26) LOW CHANNEL



802.11ax-20 MHz(RU26) MIDDLE CHANNEL



802.11ax-20 MHz(RU26) HIGH CHANNEL



802.11ax-20 MHz(RU52) LOW CHANNEL



802.11ax-20 MHz(RU52) MIDDLE CHANNEL



802.11ax-20 MHz(RU52) HIGH CHANNEL



802.11ax-20 MHz(RU106) LOW CHANNEL



802.11ax-20 MHz(RU106) MIDDLE CHANNEL



802.11ax-20 MHz(RU106) HIGH CHANNEL




802.11ax-40 MHz(RU26) LOW CHANNEL




802.11ax-40 MHz(RU26) MIDDLE CHANNEL




802.11ax-40 MHz(RU26) HIGH CHANNEL




802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL



802.11ax-40 MHz(RU52) HIGH CHANNEL



802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL



MIMO ANT 0:

802.11b CH1



802.11b CH2



802.11b CH3



802.11b CH6



802.11b CH10




802.11b CH11






802.11g CH1




802.11g CH2




802.11g CH3



802.11g CH4



802.11g CH6



802.11g CH9




802.11g CH10




802.11g CH11



802.11n-20 MHz CH1




802.11n-20 MHz CH2




802.11n-20 MHz CH3



802.11n-20 MHz CH4




802.11n-20 MHz CH6




802.11n-20 MHz CH9




802.11n-20 MHz CH10



802.11n-20 MHz CH11




802.11n-40 MHz CH3




802.11n-40 MHz CH4




802.11n-40 MHz CH5




802.11n-40 MHz CH6




802.11n-40 MHz CH7




802.11n-40 MHz CH8



802.11n-40 MHz CH9



VHT20 CH1




VHT20 CH2



VHT20 CH3




VHT20 CH4



VHT20 CH5



VHT20 CH6



VHT20 CH9




VHT20 CH10



VHT20 CH11



VHT40 CH3



VHT40 CH4




VHT40 CH5



VHT40 CH6




VHT40 CH7



VHT40 CH8



VHT40 CH9



802.11ax-20 MHz(SU) CH1



802.11ax-20 MHz(SU) CH2



802.11ax-20 MHz(SU) CH3



802.11ax-20 MHz(SU) CH4



802.11ax-20 MHz(SU) CH5



802.11ax-20 MHz(SU) CH6



802.11ax-20 MHz(SU) CH8



802.11ax-20 MHz(SU) CH9



802.11ax-20 MHz(SU) CH10

