
# **INSTRUCTION MANUAL**

Service Email: sales@jousecu.com




### Setup and use your digital video baby monitor

A. Place Baby Unit on a flat surface, such as a desk.



Never place the baby unit or the cord within 1 meter of the crib.


B. Connect the small plug of the power adapter to the Baby Unit and the other end to a suitable electrical outlet. Only use the enclosed adapter (5V DC 1000mA). The baby unit is turned on and the power LED will be green.





Connecting the power supply for the Parent Unit Connect the small plug of the power adapter to the base bracket or the parent unit, and the other end to a electrical outlet. Only use the enclosed adapter(5V DC/2000mA).

Recommend charging time of at least 3 hours before first use.







#### Precaution: use of battery for Parent Unit

Only charge the battery when the battery life indicator is low. Constant recharging of your battery before the low battery indicator light comes on will decrease the life of your batteries.

When battery is low, the power on/off LED (icon) will flash red and on screen display battery icon will flash red indicating that the battery needs to be charged.



#### Notice:

If you use the parent unit for the first time, when you turn on the parent unit. some boot menus will pop-up on the screen, we try to explation status and function on these menus, please according to the tips to switch to the monitor p system interface. When you are fimaliar with this monitor, you could switch off these on screen tips in menu.

#### Function of keys and LED indicators 3


#### Parent Unit

#### Sound Level indicator

Visual indicator for sound picked up from baby unit. The louder the sound is from Baby unit, the more LEDs are light on.

Power on off status LED

Steady Orange: Charging battery.



and split screen

Power Saving-on/off mode Press to turn on/off


Screen turns off when power saving mode is on.

Press and hold to talk to baby unit

#### Antenna


Steady Green: Power saving mode is activated

Lift up antenna to have better reception of audio and video signal.



VOL- VOL+	Volume down/up	Press to decrease and increase volume.
<u></u>	Talk	Press and hold to talk to baby unit.
vox	Power Saving-on/off Press to switch on/off Power Saving (voice activation m	
OK VIEW	Select	Switch back-and-forth to view each sigle screen, and split screen.
• •	Up/Down Camera Up/Down	Menu mode (Press to adjust menu settings) Single screen mode (Press to control the current camera to rotate up/down)
• •	Left/Right Camera Left/Right	Menu mode (Press to adjust menu settings) Single screen mode (Press to control the current camera to rotate left/right

#### **Baby Unit**



PAIR	Pairing button	When camera is powered on, press this button and the power LED starts to blink, the camera is in pairing mode. Press it again to exit pairing mode.		

### Start to use monitor

#### Status bar



Talk function is activated

Lullaby is activated ⊕. Zoom in is activated

Monitor is muted 

Four different monitoring modes

23 °C Baby room temperature

Battery level

#### Menu operation



Feeding time reminder is activated.



Adjust Parent Unit LCD Brightness lighter or darker.

**N** Temperature alert is activated

Signal strength reference

CAM1 Camera number



Adjust camera volume : Sound level from 1 to 5.



Activate or deactivate lullaby function, 5 lullabies can be chosen. When turn on lullaby, on Baby Unit side will always hear the ringtone from Parent Unit. Repeat: Repeat all Juliabies.

OFF OFF: Deactivate Iullaby function.



### (H) ADD: Add additional camera. Two cameras can be added.

Step 1: Move the parent unit to the same area as the camera. Both parent and baby unit are switched on. Step 2: Select ADD in Menu. The next available camera will automatically be

highlighted. Press "Select" to begin pairing.

Step 3: Within 10 seconds, press "Pairing button" of camera

Step 4: Once successfully paired, the camera light will stop flashing and video will appear on the monitor screen within 20 seconds.

**Delete**: Delete paired camera from the list.

Single Screen: Show the selected single camera

ngle Screen: Alternate to show each single came 

lit Screen: Select automatically to receive audio from louder came

Split Screen: Alternate to receive audio every 10s between both camera



Zoom 🔍 Out 🔍 In

HIGH High: Beep Alarm is issued when room temperature is higher than this setting.

Low Beep Alarm is issued when room temperature is lower than this setting. C: Display temperature in Celsius scale.

F: Display temperature in Fahrenheit scale.

Temperature calibration: Calibrate room temperature display to your standardized one.

ON: Activate room temperature alarm function.

**OFF**: Deactivate room temperature alarm function.

### **Two different power saving modes**To select ECO or SCREEN OFF mode

Activation sound level selection and leave audio off in power saving mode. **Quiet**: Baby cry a little bit to activate the Parent Unit.

Medium: Baby cry moderate to activate the Parent Unit. **Loud**: Baby cry louder to activate the Parent Unit.

Turn off screen and leave audio on: Keep audio continuously on when screen is off in power saving mode.





**Email**: Sales@jousecu.com

**Sound Bar**: This sound bar is designed for deaf parents to reflect sound level picked up from camera. You can turn visual sound level indication

**Ci)** Explanation On/Off: We try to explation status and function on the boot menu. You can turn the explanation on or off based on your usage.

## WARNING THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION

- RESPONSIBLE ADULT SUPERVISION

  When an AC Adapter is plugged into an electrical outlet, do not the exposed end.

  Test baby monitor before first use, periodically, and when changing location of the baby un
  Do not use monitor near water (Such as bathtub, Sink, etc)

  Keep parent unit away from heat sources (Such as stoves, radiators, etc)

  Make sure there is proper ventilation around baby unit and parent unit.

  This product is not a toy. Do not allow children to play with it.

# Battery Warning

### **Precautions**

(1) This device may not cause harmful interference, and (2) This device must accept a interference received, including interference that may cause undesired operation.