



BLUETOOTH HEADPHONE

N-LITE 208

QUICK START GUIDE

Product Overview



Earphones x2 (L & R) Charging case x1




USB-C cable x1

Quick start guide and

Charging

Before using the " Monster N-Lite 208 ", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first



Power On/Off

When open the charging case, the earphones will power on automatically, If you want to turn off the earphones, please put the earphones into the charging case and close the cover, the earphones will power off and charge at the same time,

电源开、关

When open the charging case, the earphones will power on automatically.

请在使用此设备前先给耳机和充电仓充满电,此设备可以通过USB-C


For new device connection, turn on the Bluetooth in your device and choose " Monster N-Lite 208 " from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device.

If the earphones have been connected before, they will connect to the last connected device automatically after


Wearing

Put the " Monster N-Lite 208 " onto your ears and rotate to fit comfortably to get the best wearing and sound quality





MFB Operation





When the earphones is not connected to the mobile phone, quickly click the touch button five times, and the earphones will automatically power off after successful operation.

Additional Operation

Answer call	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB 2 seconds
Turn down the volume	While the music is playing, slide down
	the MFB
Turn up the volume	While the music is playing, slide up
	the MFB
LED indicator (charging case)	
Charging	The orange light goes off in 8 seconds,
	when fully charged, the white light will
	turn off for 8 seconds
Low Battery	Each time the earphones leaves the
	charging case and enters the
	charging case, the orange light will turn
	off for 4 seconds
Discharge	The white light is on for 4S and then off

*Private replacement of batteries without permission is not recommended *Batteries [battery packs or battery combinations] should not

be exposed to lighting, baking or similar overheating environments.

*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2AVD2-MH22211

Model No : MH 22211



N-LITE 208

请仔细阅读本快速指南并妥善保存以备将来使用。 本产品由中国平安保险公司承保

产品概述



USB-C充电线 x1













快速指南/保修卡


打开充电盒盖,耳机将自动开机。如果想要关闭耳机,请将耳机放入 充电盒并关盖,耳机会关机同时进行充电。

打开充电盒,耳机会自动开机。对于新设备连接,请打开蓝牙设备并 搜索" Monster N-Lite 208"进行连接,配对成功后,您会听到系

USB-C 接口处


如果耳机之前已配对过,开机就会尝试连接上一次的设备。

拿出耳机,将"Monster N-Lite 208"放入耳中,并轻轻旋转至舒 适位置,以确保获得最佳的佩戴效果和音质体验。





按键操作



恢复出厂设置

耳机未连接手机状态下,快速点击触摸按键5次,操作成功后耳机自动

更多操作

	接听	双击左或右耳
	挂断	双击左或右耳
	拒接	按MFB键2秒
	调低音量	在音乐播放状态下,向下滑动触摸区域
	调高音量	在音乐播放状态下,向上滑动触摸区域
	LED 指示灯(充电盒)	
	充电	橙色灯亮8秒后熄灭,
		满电后,白灯亮8秒熄灭
	低电提醒	耳机每次离仓和入仓时,橙色灯亮4秒熄灭
	放电	白灯亮4S后熄灭
1		

- *不建议未经许可私下更换电池。
- *电池[电池组或电池组合]不得暴露在照明,烘烤或类似过热的环境中。
- *耳机充电仓在外接电源充电时,输入电压电流标准≤5V/1A;

封面