


## True Wireless Earbuds

### USER MANUAL

Thanks for purchasing and using this product, to ensure this product brings you better experience. Please read this manual firstly and also refer to the manual of your connecting mobile phone or electronic product for related Bluetooth setting.



#### Packing list

Ear buds x 2                      Charging case x1

User manual x1                  USB cable x1

Rubber tips x2(Large, Small)

Model No.	TWS1	Stand-by Time	250Days
Bluetooth Distance	≤10m	Music Time	6.Hours
Speaker Diameter	6mm	Charging Interface	TYPE-C
Impedance	16Ω	Charging Times(Full Charge of Case)	4
Frequency	30-20KHZ	Earbud N.W. (per piece)	4.5g
Earbuds Battery Capacity	40mAh	N.W.( Earbuds with charging case)	34g
Charging Case Battery Capacity	400mAh	TYPE-C charging connector	5V/200mA
Charging Case Input Voltage	5V		

#### Touch Area

1	Power on/off	Earbuds will turn on when removed from charging case, and turn off when put back in.
2	Play next	Tap and hold the right earbud for 3 seconds.
3	Play previous	Tap and hold the left earbud for 3 seconds.
3	Pause/Play	Double-tap the right earbud.

4	Answer call / End call	Double-tap either earbud.
5	Decline call	Tap and hold either earbud for 3 seconds.
6	AI Voice	Double-tap the left earbud.

**LED notifications:**

1	Charging case LED	Red: Connected to power and charging White: Charging complete Flashing red: Low battery warning
2	Earbud LED	Red: Charging White for 10 seconds: Fully charged Flashing red: Low battery Flashing white: Pairing Off: Connected

**Pairing True Wireless Earbuds with your phone**

1. Turn on the earbuds by taking them out of the case. The LEDs on each earbud will flash white.
2. On your phone, find Bluetooth settings, make sure Bluetooth is ON, and pair with "Earbuds\_TWS1". Consult your phone user guide for details.

Tip:

- a) If you don't see the headphones on the list, you can reset the headphones by tapping both earbuds 3 times.
  - b) If pairing fails, put the earbuds back in the case and start again.
3. Once paired, earbuds will automatically connect when taken out of the case.
  4. When you're done, put the earbuds back in the case to turn them off and charge them. Make sure to recharge the case periodically.

**Things to keep in mind with True Wireless Earbuds**

- True Wireless Earbuds should not be used in extreme temperatures.
- Make sure to use a 5 volt charger and charge the batteries before use.

## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.