

VA-018 GAMEPAD

User manual:

- 1、The product is mainly applicable to the android /iOS/Win 7/8/10 system bluetooth connection and the PS3 game console wireless connection, when the game operation.
- 2、Applicable device: smartphone/tablet/box /PC /PS3 game console.
- 3、LT/RT is the analog function, paying more attention to the experience details of the smart TV set, the top of the machine, making the game precise and controllable.
- 4、It can be used on PC/PS3 and other devices with receiver.

※Due to irresistible factors such as official system, game, game platform upgrade or change, some games or directly unable to connect with the product,

Our company assumes no responsibility. Our company reserves the right of final interpretation

Android devices User manual:

- 1、At the same time, hold down the A button +HOME button for 2 seconds, then the LED1 indicator flashes (it has been connected, you can directly press the HOME button to connect);
- 2、Turn on the bluetooth function of Android devices and click "scan";
- 3、When you find the name of a bluetooth device called "GamepadPlus V3," select the paired connection;
- 4、Successful connection, LED1 indicator light is always on;
- 5、Directly playable: honor of Kings, exciting battlegrounds, endless duels, wilderness action (except game changes);

Top button +HOME button: select king of glory; Right-click +HOME button: choose to stimulate the battlefield;

Button +HOME button: select endless duel; Left button +HOME button: select wilderness action; King of glory by default.

- 6、Use the ShootingPlus V3 App to adjust the keys to play more games;

A、To install the android version of ShootingPlus V3 App, go to the Google Play Store
Search for "ShootingPlus V3" to download, or scan the code:



- B、How do I change the keys on android ShootingPlus V3 App
- a. Connect to bluetooth, install ShootingPlus V3 App, and push the App to the background.
 - b. After directly starting the game, click the "V3" hover ball icon on the screen or press the "START" button on the controller to enter the key interface of the App.
 - c. Drag the key icon in the change key interface to the desired operation position on the game. (click the key icon to select key properties)
 - d. Click "save" on the menu bar, then "confirm" save.
 - e. Click "close" on the menu bar or press "START" again (or click "V3" again) to exit the interface.
 - f. In the game, you can press the "SELECT" key on the gamepad to call up the set key prompt.
- C、After installing ShootingPlus V3 App, you can also directly download the set game keys from the "cloud keys list" on the main interface of the App.
- 7、Mediatek (MTK) mobile phone, please use the X +HOME button to enter the standard android mode and use the game hall (Such as: grape game hall, game housekeeper, octopus and so on).
- Note: if you get into the wrong apple mode, please cancel the bluetooth pairing and then re-pair to android mode.

iOS Apple devices User manual:

- 1、 At the same time, hold down Y button +HOME button for 2 seconds, and the LED2 indicator flashes (connected, you can directly press HOME button to connect);
- 2、 Turn on the bluetooth function of Apple devices and click "scan";
- 3、 When you find the name of a bluetooth device called "GamepadPlus V3," select the paired connection;
- 4、 Successful connection, LED2 indicator light is always on;
- 5、 Directly playable: honor of Kings, exciting battlegrounds, endless duels, wilderness action (except game changes);

Top button +HOME button: select king of glory;Right-click +HOME button: choose to stimulate the battlefield;

Button +HOME button: select endless duel;Left button +HOME button: select wilderness action;King of glory by default.

- 6、 Support iOS mobile devices 11.3 to 12.1.4 system;
- 7、 Use the ShootingPlus V3 App to adjust the keys to play more games;
 - A、 Apple version ShootingPlus V3 App please go to the App Store and search "ShootingPlus V3" to download, or scan the code:



B、 How do I change the keys on apple ShootingPlus V3 App

- a. Connect to bluetooth and install ShootingPlus V3 App.
- b. Launch the game and take a screenshot of the game within the game (press "power on" and "volume +" simultaneously on iPhone X/MAX;
Other iPhones press the "power button" and the physical "HOME button" at the same time).
- c. Open ShootingPlus V3 App, click "V3" hover ball or press START to enter the App change interface.
- d. Long press the screen blank to start loading the game screenshot.Click select picture to select game screenshot (b. screenshot of operation).
(in the process of selecting the picture, there will be an access album reminder, please allow access, that is: click ok)
- e. Drag the key icon in the change key interface to the desired operation position on the game.(click the key icon to select key properties)
- f. Click "save" on the menu bar, then "confirm" save.
- g. Click "close" on the menu bar or press "START" again to exit the interface.

C、 After installing ShootingPlus V3 App, you can also directly download the set game keys from the "cloud keys list" on the main interface of the App.

Note: if you get into the wrong android mode, please cancel the bluetooth pairing and then re-pair to apple mode.

ShootingPlus V3 App for more details please pay attention to WeChat public account:



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.