

MOTIVE USER MANUAL

Product Review:



Product introduction:



Connection:

They are connected automatic when take them out charging case; open the Bluetooth function of mobile , choose the “Motive” and confirm.

How to use by calling:

Press the power on button is answer the calling when calling income; long press the power on button to refused the calling when do not want to answer the calling; press the volume button to change the volume of calling.

How to wake up the “Siri” or “OK google”

Press twice power on button on left side earphone to wake up “Siri” or “ok Google”

How to redial the last number:

Press twice power on button on right side earphone to call the last number;

How to use by Music Mode:

Press once power on button to play or paused the music , short press the volume button to change the volume of music; long press the “ volume - “ button change to pre-song and long press the “volume+” change to next song

Disconnect and re-connected:

When the battery is low or the earphones is over 10m far away from mobile, they will disconnect from mobile, recharged or less 10m away from mobile, they will re-connect automatic.

Charging:

Put the earphones into charging case, they will be charged automatic and power is off. The red LED is light on earphone; connect the USB cable included to charge for Charging case.

FCC Statement

FCC ID:2AVHS-MOTIVE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.