

















# RF48 User Manual






## 1 appearance



## 2 Key function

Key value	Specification
PAIR	press and hold  and  button ,the remote enters pairing mode
HEAD UP	Press and hold  button, head actuator moves out, stop when released

HEAD DOWN	Press and hold  button, head actuator moves in, stop when released
FOOT UP	Press and hold  button, foot actuator moves out, stop when released
FOOT DOWN	Press and hold  button, foot actuator moves in, stop when released
LUMBAR UP	Press and hold  button, Lumbar actuator moves out, stop when released
LUMBAR DOWN	Press and hold  button, Lumbar actuator moves in, stop when released
FLAT	Press and hold  button, the bed goes flat
ZG	Click  button, the bed moves to zeroG position, press and hold zeroG button for 5s, until backlight flashes, the control set the current position as zeroG position
TV	Click  button, the bed moves to TV position, press and hold TV button for 5s, until backlight flashes, the control set the current position as TV position
Antisnore	Click  button, the bed moves to Antisnore position, press and hold Antisnore button for 5s, until backlight flashes, the control set the current position as Antisnore position
M1	Click  button, the bed moves to M1 position, press and hold M1 button for 5s until backlight flashes, the control set the current position as M1 position
M2	Click  button, the bed moves to M2 position, press and hold M2 button for 5s, until backlight flashes, the control set the current position as M2 position
UBB	Click  button, open or close under bed light
CHILD LOCK	press and hold  button for 5s until backlight flashes, then the lock/unlock is complete. In locked state, press any button except this button and the pairing button, the backlight flashes

Massage head+	Click  button, head massage motor switches massage intensity, massage intensity switches among 0-1-2-3;
Massage timer	Click  If the massage motors do not work, the button is invalid, if the massage motors work, click the button to switch the massage time, when massage time switch to 0, turn off the massage;
Massage foot+	Click  button, foot massage motor switches massage intensity, massage intensity switches among 0-1-2-3;
Massage Mode	Click  button, to switch the massage mode of massage motors, massage mode switches among type0→type1→type2→type3→type0; this button can only switch the massage mode, it can not open massage motors;
MESSAGE ON/OFF	click  button to turn on/off head&foot massage

### **FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **ISED Warning:**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.