To Turn Vibrations On: On the TRYST v2:

- 1. Press 1 to turn on LED display and activate product.
- 2. Press again to start vibrations of motors 1 & 2, located in the arms of the TRYST v2.
- 3. Press 2 to turn on motor 3 in the base of the TRYST v2
- 4. Continue to press 1 to cycle through 10 vibration modes in motors 1 & 2. Continue to press 2 to cycle through 10 vibration modes in motor 3.

On the Wireless Remote:

- 5. After completing Steps 1 & 3, press 1 on the remote.

 Continue to press it to cycle through the 10 vibration modes of motors 1 & 2.
- 6. Press 2 on the remote to cycle through 10 vibration modes on motor 3

To Turn Vibrations Off: On the TRYST v2:

- 1. Hold **1** on the TRYST until the LED display and motors 1 & 2 power off.
- 2. Hold 2 on the TRYST until the LED display and motor 3 powers off.

On the Wireless Remote:

- 1. Hold 1 on the remote until motors 1 & 2 power off.
- 2. Hold 2 on the remote until motor 3 powers off.

[Please note: the remote cannot work before the product is activated.]


To Charge TRYST v2:

Plug included cable into a USB power source, then locate the charging port on the TRYST v2 and plug in.

Charge time: 60 minutes.
Usage time: 90 minutes.

Cleaning and Storage:

Spray your TRYST v2 with Doc Johnson Toy Cleaner or wash with mild soap and warm water. Allow to air-dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. Doc Johnson Toy Cleaner sold separately.



WARNING FOR VIBRATING PRODUCTS: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

Designed by Doc Johnson® in Los Angeles, California.Copyright © 2019 Doc Johnson Enterprises. All Rights Reserved.

For warranty information and product registration, please visit us online at **docjohnson.com**



DOCJOHNSON.com

.docjohnson.com/social-media

INS-0990-15

One base motor operates independently from arms One base Motor 3 Wireless remote uses 1 AAA Battery (Not Included)

About This Product

The revolutionary TRYST Multi Erogenous Zone Massager has gotten an upgrade. TRYST v2 features 3 motors with 10 vibrating functions. Its arms are bendable, creating a multitude of new uses and playtime experiences. This second version also includes a wireless remote, allowing hands-free use.

SUGGESTED USES:

The vibrating arms can bend to squeeze the clitoris, nipples, testicles, and anywhere else, applying exactly the right amount of pressure during solo or partner play.










To use TRYST v2 as a vibrating ball stretcher, fit bendable arms around the base of the testicles. Position with TRYST v2's base motor aligned close to the body for intense perineum stimulation.




TRYST v2 can be worn as a form-fitting C-ring in various positions and levels of snugness.





TRYST v2 in C-ring mode can be enjoyed hands-free during intercourse. Experiment with base and arm position to maximize everyone's pleasure!



Hold TRYST v2 by the arms to enjoy the base motor as a powerful external massager.



Bend and position TRYST v2's vibrating arms for internal stimulation of the vagina, anus, or both simultaneously.



CHOOSE TRYST V2 FOR A NEW INTIMATE ADVENTURE EACH AND EVERY TIME!

INNER TRI-FOLD

	Die #:	Date: 08-13-19	Artist: RM
6	Item #: INS-0990-15	Substrate: Paper	
M	COATING: Gloss (Overall)		
E COE	INKS: CMYK		
8	TREATMENTS:		
			* PLEASE REFER TO LAYERS

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.