




WM_ONN
 DP Audio
 100123973
 BTS Mini Speaker
 OPT03_QSG
 12/30/2022


Filename: WM_ONN_DP Audio_100123973_BTS Mini Speaker_OPT03_QSG_C
 Date: 30 Dec 2022
 Stock: 157g C2S
 Size: 22.75" x 4.48"

QUICK START GUIDE



100123973

Overview




Buttons

- Power Button**
Press and hold to turn the speaker on/off. Press to show current battery level.
- Volume Up/Next Button**
Press to turn up the volume. Press and hold to go to next song.
- Multi-function Button**
Press to pause/play the current track. Press to accept an incoming call. Press again to hang up. Press and hold to reject an incoming call.
- Volume Down/Previous Button**
Press to turn down the volume. Press and hold to go to previous song.
- Bluetooth® Button**
Press and hold to activate Party Sync Mode. Press to switch between AUX/FM/Bluetooth® modes.

Charging Your Device


Plug the included USB-C cable into the speaker's charging port, and connect the other end of the cable to a power adapter (sold separately). Allow approximately 3 hours to fully charge the battery.

Note: We recommend using a USB wall adapter with a 5V output.




CHARGING PORT

Press the Power button to check current battery level.



Initial Setup



- Once your device is fully charged, press and hold the Power button until you hear a prompt indicating the device has entered Bluetooth® pairing mode.
- On your smartphone or tablet, search for the Bluetooth® device named "on. bts mini spkr" and tap to connect.
- A prompt will play once pairing is successful.

on.™

HAVING TROUBLE? WE CAN HELP
1-888-516-2630
 7 DAYS/WEEK 7:00am- 9:00pm CST

SAVE THIS USER GUIDE
 Read entire user guide before use

Manufactured by Walmart

4.48"
113.79mm

3.792"
96.31mm

3.792"
96.31mm




3.792"
96.31mm

3.792"
96.31mm

3.792"
96.31mm


3.792"
96.31mm

22.75"
577.85mm

FRONT


Party Sync Mode



This device features Party Sync Mode technology, which allows you to play music on two of these mini-speakers simultaneously, creating a surround sound experience.

- Press and hold the Power button on both speakers to turn them on and enter Bluetooth® Pairing Mode.
- On your smartphone or tablet, search for the Bluetooth® device named "on. bts mini spkr" and tap to connect to one of the speakers.
- Press and hold the Bluetooth® button on the speaker that is connected to your smartphone or tablet.
- You will hear a sound prompt while the speakers are pairing. The status light will illuminate on both speakers once connected.

AUX Mode



Connect your external device to the AUX input on the side of the speaker via AUX cable (sold separately) to enter AUX mode and start streaming audio from your device.

Press the Bluetooth® button to exit AUX mode. NOTE: An AUX cable (sold separately) must be connected to detect AUX mode.

FM Radio Mode

- Switch to FM Radio mode by pressing the Bluetooth® button.
- Press and hold the Multi-function button to automatically scan for radio stations. Press and hold the Multi-function button again to remain on a selected channel.
- To manually scan for radio stations, press and hold the Previous and Next buttons.


Insert the included USB-C cable into the Charging Port while in FM mode to use it as an external antenna and improve signal.

Hands-Free Calling Controls

- Volume Down/Previous Button**
Press once to decrease volume
- Volume Up/Next Button**
Press once to increase volume
- Multi-function Button**
Press to accept an incoming call. Press again to hang up. Press and hold to reject an incoming call.

Reset

If your speaker is not operating properly, you may reset it. To do so, press and hold the Power button for approximately 8 seconds until the speaker powers off, and then power it on again as usual.



Specs

Speaker Output Power
3W RMS

Bluetooth® Speaker Frequency Response
150 Hz ~ 16000 Hz

Battery
Built-in rechargeable

Battery Life
Up to 13 Hours*

IPX5
Water-resistant, rainproof, sprayproof, and splashproof

Modes
Bluetooth® Mode
Party Sync Mode**
AUX Mode
FM Radio Mode

Range
33 ft (10m)

Input
AUX
USB C

*Battery life measured as number of playtime hours with volume set at 50%.
 **Can pair with another on.™ Rugged Mini-Speaker. Will NOT pair with the on.™ Mini Rugged Speaker series #100081667

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

FCC Warning (Continued)


particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

FCC ID: 2AVRV100123973

BACK



- Cut line
- Fold line
- Copy safe area
- Outside Bleed
- Glue area