

nickelodeon™


pinkfong  
**BABY SHARK™**

Floating Pool Speaker

Quick Start Guide

### In the Box

Floating Pool Speaker



USB-C®  
Charging Cable




Quick Start Guide



Warranty Card


### Device Overview



### Buttons and Ports

- Power Button**  
Press and hold to turn speaker on/off
- Volume Down / Previous Track**  
Press to turn down the volume  
Press and hold to select the previous song  
When in FM mode: Press and hold to select previous FM channel
- Play / Pause Button**  
Press to play / pause music  
Press and hold to play the preloaded Baby Shark song  
When in FM mode: Press to scan FM channels (all channels scanned will be automatically saved)
- Volume Up / Next Track**  
Press to turn up the volume  
Press and hold to play the next song  
When in FM mode: Press and hold to select next FM channel
- Bluetooth® / Lights / TWS Pairing / FM Mode**  
Press to cycle through 8 LED light modes  
Press and hold to enter Bluetooth® / FM mode  
Press twice to connect / disconnect TWS mode  
Press three times to connect / disconnect Bluetooth®

### Charging your Device




Plug the included USB-C® charging cable into the speaker's charging port, and connect the other end of the cable to a power adapter (sold separately). Allow approximately 4 hours to fully charge the battery.

When the battery is low, the indicator light will blink red. Once fully charged the red light will turn off.

**Note:**  
We recommend using a USB wall adapter with a DC5V=1A output.

**Important:** Do not place this device near or around water while charging.

### Bluetooth® Setup




- Once your speaker is fully charged, press and hold the **Power Button** until you hear a voice prompt indicating the device has entered Bluetooth® pairing mode.
- On your smartphone or tablet, search for the Bluetooth® device named "Baby Shark Pool Speaker" and tap to connect.
- A sound prompt will play once pairing is successful.

**Note:**  
\* If you turn on the speaker and do not connect to a device within 10 minutes, it will power off automatically.  
\* If you connect to a device and have no playback within 20 minutes, the speaker will power off automatically.

### TWS Sync Mode


This device features TWS (True Wireless Stereo) technology, which allows you to play music on two Baby Shark Floating Speakers simultaneously, creating a surround sound experience.



- Press and hold the **Power Button** on both speakers to turn them on, and wait until the indicator light flashes blue.
- Press the **Volume Down / Previous Track** button twice on one speaker to enter TWS mode. Both speakers will automatically connect.
- On your smartphone or tablet, search for the Bluetooth® device named "Baby Shark Pool Speaker". Once you hear a sound prompt, you have successfully connected the two speakers and can enjoy music on both simultaneously.

**Note:**  
\* In TWS (True Wireless Stereo) mode speakers will automatically connect if TWS is not disconnected on previous use.  
\* In TWS mode, turning off one speaker will power off the other as well.  
\* Press the **Volume Down / Previous Track** button twice to disconnect TWS mode.

## FM Radio Mode



Indicator Light

1. Press and hold the  $\frac{3}{4}$  button to switch to FM Radio Mode. The indicator light will turn blue once in FM Radio Mode.
2. Press the **MI** button to automatically scan for available radio stations. Press the **MI** button again to remain on a specific channel during the scan. All radio stations scanned will be automatically saved. Press and hold the +/- buttons to cycle through saved stations.

**Note:**  
Please use the provided USB-C® charging cable as an external antenna to improve signal strength when in FM Radio Mode.

## Lights / Resetting Your Device

This device features 8 different LED light effects. Press the  $\frac{3}{4}$  button to cycle through all 8 LED light effects.



If the speaker is not operating properly, you may reset it by pressing the **⏻** button for 8 seconds. The speaker will power off and power back on again.

## Specifications

- Floating Pool Speaker
- Input Power: 5V / 1A
- Impedance: 4  $\Omega$
- Signal to Noise Ratio:  $\geq 75$ dB
- IPX7 - Protected from immersion in up to 3 feet of water for 30 minutes
- Built-in Microphone / Rechargeable Battery
- Wireless Range: 33ft (10m)
- Frequency Response: 130Hz-18KHz
- TWS Sync Mode (True Wireless Stereo)
- Up to 8 hours of playtime (battery life is measured as number of playtime hours with volume set at 50%)

**WARNING:** CHOKING HAZARD - Small parts, not for children under 2 years. Use with adult supervision only.



This symbol indicates that this product should not be treated as regular household waste. Please bring this item to an approved recycling collection facility for proper disposal.

© Smart Study Co., Ltd. All Rights Reserved. Pinkfong® and Baby Shark™ are trademarks of Smart Study Co., Ltd. © 2023 Viacom International Inc. All Rights Reserved. Nickelodeon is a trademark of Viacom International Inc. "Baby Shark" song arranged by Pinkfong and KizCastle, and performed by KizCastle, Sarah Bock, Andy Degan, Finn Phoenix, and Bommie Catherine Han.



## Important Safety Warning

### Protect Your Child from Potential Hazards!

**Attention Parents and Guardians:** Your child's safety is of paramount importance to us. We must alert you to potential risks associated with the use of recalled bath toys, specifically when used in bathtubs or wading pools. It is crucial to understand and mitigate the potential dangers your child may face when interacting with these toys.

### Potential Hazards:

**Slip and Fall Risks:** Please be vigilant when your child is using bath toys, including the Baby Shark Pool Speaker, in wet environments. Slips and falls can occur, leading to potential injuries. **Impalement, Lacerations, and Punctures:** The hard plastic top fin of the shark poses risks of impalement, lacerations, and punctures if a child falls or sits onto it. Immediate action must be taken to prevent such accidents. **Safeguarding Measures:**

**Adult Supervision:** Always supervise your child while they are playing with the Baby Shark Pool Speaker or any other bath toys. Maintain constant visual contact to ensure their safety. **Secure and Stable Environment:** Place the Baby Shark Pool Speaker on a stable surface, away from the edge of bathtubs or wading pools, reducing the risk of slips or falls. Confirm that the area is free from any potential hazards that could harm your child. **Educate and Warn:** Inform your child about the importance of safe play and the potential risks associated with the hard plastic top fin of the shark. Encourage them to avoid sitting or standing on it to prevent accidents. **Regular Inspection:** Before each use, carefully examine the Baby Shark Pool Speaker for any signs of wear, damage, or loose parts. If you notice any issues, discontinue use immediately and contact our customer support for assistance.

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**WARNING:** Cancer and Reproductive Harm  
www.P65Warnings.ca.gov

## Need Help?

For customer support regarding your device, please submit a request by emailing [support@dpaudiovideo.zendesk.com](mailto:support@dpaudiovideo.zendesk.com). You will be provided a ticket number regarding your inquiry, which you can refer to when contacting us further. You may also reach a DP AV customer service representative by calling **1-833-909-2673**. We are available Monday - Friday, 9am - 5pm PST, except major holidays.

Thank you for purchasing a Pinkfong Baby Shark product.



MODEL: BSBT220  
FCC ID: 2AVRVBSBT220