





Restrict Band NVNT ac20 5745MHz Ant1 Peak




Restrict Band NVNT ac20 5745MHz Ant1 Average






Restrict Band NVNT ac20 5825MHz Ant1 Peak




Restrict Band NVNT ac20 5825MHz Ant1 Average






Restrict Band NVNT ac40 5755MHz Ant1 Peak




Restrict Band NVNT ac40 5755MHz Ant1 Average






Restrict Band NVNT ac40 5795MHz Ant1 Peak




Restrict Band NVNT ac40 5795MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Test Graphs

Restrict Band NVNT a 5745MHz Ant2 Peak




Restrict Band NVNT a 5745MHz Ant2 Average






Restrict Band NVNT a 5825MHz Ant2 Peak




Restrict Band NVNT a 5825MHz Ant2 Average








Restrict Band NVNT n20 5745MHz Ant2 Peak




Restrict Band NVNT n20 5745MHz Ant2 Average






Restrict Band NVNT n20 5825MHz Ant2 Peak




Restrict Band NVNT n20 5825MHz Ant2 Average






Restrict Band NVNT n40 5755MHz Ant2 Peak




Restrict Band NVNT n40 5755MHz Ant2 Average






Restrict Band NVNT n40 5795MHz Ant2 Peak




Restrict Band NVNT n40 5795MHz Ant2 Average






Restrict Band NVNT ac20 5745MHz Ant2 Peak




Restrict Band NVNT ac20 5745MHz Ant2 Average






Restrict Band NVNT ac20 5825MHz Ant2 Peak




Restrict Band NVNT ac20 5825MHz Ant2 Average






Restrict Band NVNT ac40 5755MHz Ant2 Peak




Restrict Band NVNT ac40 5755MHz Ant2 Average






Restrict Band NVNT ac40 5795MHz Ant2 Peak




Restrict Band NVNT ac40 5795MHz Ant2 Average








Restrict Band NVNT ac80 5775MHz Ant2 Peak




Restrict Band NVNT ac80 5775MHz Ant2 Average






Restrict Band NVNT ac80 5775MHz Ant2 Peak



Restrict Band NVNT ac80 5775MHz Ant2 Average





### E.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5745	Ant1	5744.98	-20000	-3.48	25	Pass
NVNT	ac20	5785	Ant1	5784.98	-20000	-3.46	25	Pass
NVNT	ac20	5825	Ant1	5824.98	-20000	-3.43	25	Pass
NVNT	ac40	5755	Ant1	5755.04	40000	6.95	25	Pass
NVNT	ac40	5795	Ant1	5795	0	0	25	Pass
NVNT	ac80	5775	Ant1	5774.92	-80000	-13.85	25	Pass

Note:Only recorded the worst result of AC mode




Shenzhen LCS Compliance Testing Laboratory Ltd.  
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
 Scan code to check authenticity




Test Graphs

Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5785MHz Ant1






Freq. Stability NVNT ac20 5825MHz Ant1




Freq. Stability NVNT ac40 5755MHz Ant1






Freq. Stability NVNT ac40 5795MHz Ant1



Freq. Stability NVNT ac80 5775MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5745	Ant2	5744.98	-20000	-3.48	25	Pass
NVNT	ac20	5785	Ant2	5784.98	-20000	-3.46	25	Pass
NVNT	ac20	5825	Ant2	5824.98	-20000	-3.43	25	Pass
NVNT	ac40	5755	Ant2	5754.96	-40000	-6.95	25	Pass
NVNT	ac40	5795	Ant2	5795	0	0	25	Pass
NVNT	ac80	5775	Ant2	5775	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.  
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT ac20 5745MHz Ant2




Freq. Stability NVNT ac20 5785MHz Ant2








Freq. Stability NVNT ac20 5825MHz Ant2




Freq. Stability NVNT ac40 5755MHz Ant2






Freq. Stability NVNT ac40 5795MHz Ant2



Freq. Stability NVNT ac80 5775MHz Ant2





### E.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant1	96.94	0.13	0.72
NVNT	a	5785	Ant1	96.94	0.13	0.72
NVNT	a	5825	Ant1	96.94	0.13	0.72
NVNT	n20	5745	Ant1	96.7	0.15	0.78
NVNT	n20	5785	Ant1	96.77	0.14	0.78
NVNT	n20	5825	Ant1	96.7	0.15	0.78
NVNT	n40	5755	Ant1	93.53	0.29	1.57
NVNT	n40	5795	Ant1	93.54	0.29	1.57
NVNT	ac20	5745	Ant1	96.76	0.14	0.76
NVNT	ac20	5785	Ant1	96.76	0.14	0.76
NVNT	ac20	5825	Ant1	96.76	0.14	0.76
NVNT	ac40	5755	Ant1	93.68	0.28	1.53
NVNT	ac40	5795	Ant1	93.82	0.28	1.53
NVNT	ac80	5775	Ant1	88.08	0.55	3.08




Shenzhen LCS Compliance Testing Laboratory Ltd.  
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
 Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5785MHz Ant1






Duty Cycle NVNT a 5825MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant1






Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant1






Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant1






Duty Cycle NVNT ac20 5745MHz Ant1




Duty Cycle NVNT ac20 5785MHz Ant1








Duty Cycle NVNT ac20 5825MHz Ant1




Duty Cycle NVNT ac40 5755MHz Ant1






Duty Cycle NVNT ac40 5795MHz Ant1



Duty Cycle NVNT ac80 5775MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant2	96.94	0.13	0.72
NVNT	a	5785	Ant2	96.94	0.13	0.72
NVNT	a	5825	Ant2	96.94	0.13	0.72
NVNT	n20	5745	Ant2	96.7	0.15	0.78
NVNT	n20	5785	Ant2	96.7	0.15	0.78
NVNT	n20	5825	Ant2	96.62	0.15	0.78
NVNT	n40	5755	Ant2	93.68	0.28	1.57
NVNT	n40	5795	Ant2	93.68	0.28	1.57
NVNT	ac20	5745	Ant2	96.68	0.15	0.76
NVNT	ac20	5785	Ant2	96.76	0.14	0.76
NVNT	ac20	5825	Ant2	96.76	0.14	0.76
NVNT	ac40	5755	Ant2	93.82	0.28	1.53
NVNT	ac40	5795	Ant2	93.68	0.28	1.53
NVNT	ac80	5775	Ant2	88.08	0.55	3.08




Shenzhen LCS Compliance Testing Laboratory Ltd.  
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
 Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5745MHz Ant2




Duty Cycle NVNT a 5785MHz Ant2






Duty Cycle NVNT a 5825MHz Ant2




Duty Cycle NVNT n20 5745MHz Ant2






Duty Cycle NVNT n20 5785MHz Ant2




Duty Cycle NVNT n20 5825MHz Ant2






Duty Cycle NVNT n40 5755MHz Ant2




Duty Cycle NVNT n40 5795MHz Ant2






Duty Cycle NVNT ac20 5745MHz Ant2




Duty Cycle NVNT ac20 5785MHz Ant2








Duty Cycle NVNT ac20 5825MHz Ant2




Duty Cycle NVNT ac40 5755MHz Ant2





Duty Cycle NVNT ac40 5795MHz Ant2



Duty Cycle NVNT ac80 5775MHz Ant2

