
使用说明书(印刷时请删除此页)					
尺寸		85×8			
材质		封面內	两页 157g 铜版纸,内页内页 80g 双胶纸		
工艺		单黑双面印刷,封面覆哑膜			
成型方式		钉装			
履历页					
版本	页》	欠	更新内容	更新时间	
V1. 0	所有	有	在 BM21-B 中性 V1.2 英文版的基	2020-08-27	
			础上文件名更新为 BM21-G		
V1. 1	目录、11		更新页码,更新单词	2021-03-30	
	" househlod " 为				



BM_Series_Speaker User Manual

Note: All the pictures in this manual are for reference only, please refer to the actual product.

Contents

1.	Important Information	1
2.	Safety Warnings and Precautions	2
3.	FCC Statement	8
4.	Special statement	.12
5.	Product Appearance	. 15
6.	Product Usage	.17
7.	Common faults and troubleshooting	29
В.	Key Specifications	. 33
9.	FCC Statement	.33
10	Padiation Exposure Statement	37

Important Information

This manual Contains the precautions and the product usage. Please read and understand all the instructions before using the device. The damage caused by failure to follow the instructions is not covered by the warranty. Please keep this manual properly.

- 2. Safety Warnings and Precautions
- 2.1. Be careful of electric shock or fire!
- 2.1.1. This device is not waterproof, please keep it dry; if water is immersed in this product, please shut down immediately and contact the customer service centre according to the prompt provided by the customer service centre before using it again.
- 2.1.2. Never place this device and accessories near the burning flames or other heat sources, Including direct sunlight.

- This device should be turned off and unplugged before lightning storms.
- 2.2. Be careful of short circuit or catching fire!
- 2.2.1. Before connecting this device to an electrical outlet, please make sure that the power supply voltage matches the voltage value printed on the back or bottom of the product. Never connect the product to an electrical outlet when the voltage is different
- 2.3. Be careful of injury or harm this speaker!

- Never place this device or any objects on a power cord or other electronic devices.
- 2.3.2. If this product is transported at a temperature below 5°C, please unpack the product and wait until the temperature reaches room temperature before connecting it to a power outlet.
- 2.3.3. This product comes with sharp objects, please handle it carefully so as to avoid injury to the user or scratching the appearance of the product or damaging the

internal parts of the product!

2.4. Be careful overheat!

2.4.1. Never install this device in an enclosed space. Always leave at least 4 inches space around the product for ventilation.

2.5. Children's health

2.5.1. This device and accessories may contain some small parts, please keep them out of the reach of children to avoid danger.

2.6. Care for the environment!

2.6.1. This device applies recyclable

high-performance materials and components.

- 2. 6. 2. Never dispose of this product with other household wastes. Please understand the local regulations on the sorting collection of electronic, electrical products and batteries.
- 2.6.3. Proper disposal of these products helps to avoid potential negative effects on the environment and human body health.

2.7. Care for the product!

2.7.1. Clean this device only with a piece of

microfiber cleaning cloth.

2.8. Maintenance & servicing

- Please contact professional service personnel for all repair services;
- 2.8.2. Please do not insert any sharp object into the inside of the device;
- 2.8.3. Please do not drop or hit the device to avoid damaging it.

FCC Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a

circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By the appropriate disposal of this product you also

help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.

4. Special statement

4.1. Intellectual property statement: the hardware design and software programs of this product are copyright protected. Anyone copying the contents of this product and instructions without the authorization of this company will bear the corresponding legal responsibilities.


- 4.2. This manual is for reference only. The actual final functions are subject to the actual ordering of the customer and the actual functions of the product received.
- 4.3. The pictures are for reference only, please refer to the actual product. The company

reserves the right to make improvements on and changes to the product appearance and design without prior notice.

Bluetooth[®]

Bluetooth words and trademarks are owned by Bluetooth SIG, Inc.

5. Product Appearance



- a. Type-C port
- b. 4-section 3.5 mm audio input/output hole
- c. Volume down Button
- d. Bluetooth Button
- e. Microphone mute Button
- f. Answer/hang up Button
- g. Volume up Button
- h. Power Button

6. Product Usage

6.1. Turn on/off the device

Long press and hold the power key for 2 seconds to turn on or off the device.

6. 2. Bluetooth

- 6.2.1. When Bluetooth is not connected, long press to turn Bluetooth on/off:
- When Bluetooth is connected, long press to disconnect the current Bluetooth connection.

6.3. Four types of connection modes

- 6.3.1. Mode 1: Connect the computer/conference plat (Windows or Mac) to this device via USB cable.
- 6. 3. 2. Mode 2: Connect this device with the original AUX audio cable (4 sections).
- 6.3.3. Mode 3: Connect this device with Bluetooth. The Bluetooth indicator will flash to indicate that the device is in Bluetooth pairing state. Enable Bluetooth functions on mobile phones/other devices, and select to connect this device from the Bluetooth

device list. Please refer to the nameplate at the bottom of the device for the name of bluetooth (when the conference panel is connected to the wireless omnidirectional mic speaker, USB bluetooth adapter is required to ensure the stability of bluetooth connection)

- 6.3.4. Mode 4:USB Bluetooth audio adapter (supporting win7/8/10 and Mac OS), operating as follows:
 - Insert the USB Bluetooth audio adapter

into the computer, and turn on the device to enter the Bluetooth pairing status (If you use a USB Bluetooth adapter to connect to the conference plat, please connect it to the front-mounted USB port of the conference plat to ensure best use effect);

② USB Bluetooth audio adapter will be automatically connected to the device(which is the only device bound by USB Bluetooth audio adapter); (3) If it is necessary to re-pair the USB Bluetooth audio adapter to the new wireless omni-directional speaker, the distance between the USB Bluetooth audio adapter and the wireless omni-directional speaker should be controlled within 3 meters. When Bluetooth is disconnected from the wireless omni-directional speaker. long press and hold the Bluetooth key for 9 seconds to enter the binding mode. After plugging the USB Bluetooth audio

adapter, the USB Bluetooth audio adapter will be rebound successfully within 30 seconds.

Note: to connect computer/conference plat with USB Bluetooth audio adapter, it is necessary to set this device as the default playback and recording device in the computer/conference plat sound setting interface.

6.4. Multi-party conference

It supports multi-channel data fusion of USB, Bluetooth and audio ports. It can work in three connection modes at the same time so as to support simultaneous access of multiple parties for the conference.

6.5. Answer/hang up call

*This device can only use the function of answering and hanging up the phone when connecting to the phone.

- 6.5.1. When there is an incoming call, press the ""\(\epsilon\)" key to answer the call.
- 6.5.2. When it is in calling state, press the "l" key to hang up the call.

6.5.3. When there is an incoming call, long press and hold the "C" key for 3 seconds to reject the call.

6.6. Mute microphone

When the device is connected to Bluetooth or plugged into a AUX audio cord or USB cord, short press the microphone mute key to turn the microphone on or off.

6.7. Volume adjustment

Press volume "+" and volume "-" keys to increase or decrease the volume accordingly.

6.8. Bluetooth status/Settings

Statu	Indicat	State	This state is
s	or	descripti	actionable
	status	on	
S1	Blue	Waiting	Long press the
	lights	for	bluetooth button
	flashin	bluetooth	3s to enter S4;
	g	connectio	Long press the
		n	bluetooth button
			9s to enter \$3
S2	Blue	Bluetooth	Long press the

	light is	connected	bluetooth button
	always		3s to enter S1
	on		
S3	White	Repair	Long press the
	lights	status	bluetooth button
	flashin	with USB	3s to enter S1
	g	bluetooth	
		adapter	
S4	White	Bluetooth	Long press the
	light is	function	bluetooth button
	always	turned	3s to enter \$1

	on	off	
--	----	-----	--

6.9. Charging the Device

- 6.9.1. Connect the original power adapter (5V/2A) with USB cable for charging.
- 6.9.2. Use the selected wireless charger to charge the device (this device has the wireless charging function. In order to ensure the charging quality and charging safety, it is suggested that you purchase this wireless charger via proper channel).
- 6.9.3. When charging, the white indicator of the

power key will flash; when fully charged, the green indicator of the power key will be normally on.

6.10. Checking the battery

In the power-on state, short press the power key to view the current remaining electric quantity.

When the light bar displays 5 squares, the battery is full. When the electric quantity is relatively low, the power key's red indicator light will flash and the low electric quantity prompt tone is broadcast.

7. Common faults and troubleshooting

The following table contains common faults and their solutions. Please read it carefully.

Fault	Possible Cause	Solution
Unable to	Low or no	Connect the
turn on the	electricity	adapter to
device		charge
Shut down	Insufficient	Connect the
automaticall	electric	adapter to
y after	quantity	charge
running for a		

while		
No sound	Is the	Select the
	connection	correct sound
	correct? Is the	source input;
	volume turned	adjust the
	on?	device

Unable to	Is there any	Please use the
work with	mistake in using	original USB
USB	the USB cable?	cable to make a
		call.
Unable to	Is there any	Please use the
work with	mistake in using	original AUX
AUX	the AUX cable?	cable (4
		sections)
		to make a call.

Invalid key	The key may	Long press
	be accidentally	and hold the
	touched.	power button for
		8seconds to
		reset the
		system.
Unable to	The charging	Replace it with a
charge the	device is in	charging device
device	fault or the	with normal
	battery is	functions
	already full.	

8. Key Specifications

Frequency band(s): 2402-2480MHz(BT)

Maximum power transmitted: 13dBm

9. FCC Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must

accept any interference received, including interference that may cause undesired operation.

Non-modification Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

10. Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

11. ISED Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure Statement

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout
 brouillage radioélectrique subi, même si le
 brouillage est susceptible d'en compromettre le
 fonctionnement.

Déclaration d'exposition aux radiations

Cetéquipementestconforme Canada limitesd'exposition aux radiations dans un environnement non contrôlé.

Cetéquipementdoitêtreinstallé et utilisé à distance minimum

de 20cm entre le radiateur et votre corps.

A distance of 20cm shall be maintained between the antenna and users. And the transmitter may not be co-located with any other transmitter or antenna.