



**Figure 1: Remote Control - RSE - 1-5 GHz - Setup Antenna View**




**Figure 2: Remote Control - RSE - 1-5 GHz - Setup Front View**




**Figure 3: Remote Control - RSE - 1-5 GHz - Setup Rear View**



**Figure 4: Remote Control - RSE - 30-1000 MHz - Setup Antenna View**



**Figure 5: Remote Control - RSE - 30-1000 MHz - Setup Front View**



**Figure 6: Remote Control - RSE - 30-1000 MHz - Setup Rear View**