

Thank you for your support, we will do better!

In order to make your use of this product better, please be sure to read this manual carefully.

Changes to the product due to technical improvements are subject to change without notice!

The changes will be directly incorporate;d into the new manual, please understand!

Note: Thank you for using this product. This manual is only for reference. Please refer to the actual multimedia entertainment system.

- Please read this manual carefully before installing and using the unit, and it is recommended that the unit be installed by a car audio professional.
- This machine is suitable for 12V power supply system (with grounding wire). Please do not install this machine directly on 24V truck or other high-powered vehicles.
- Under the guidance of no professional, please do not change the power fuse or use some improper fuses, otherwise it will cause damage and fire.
- The display of this product uses a precision electronic structure. Do not strike the display with a sharp object to avoid damage.
- To avoid violating traffic rules, drivers should not watch videos, pictures, text programs and operate the unit while driving to avoid traffic accidents.
- To ensure safety and ensure the normal use of this product, please submit it to the professional who sells the product. Do not disassemble and repair the machine yourself to avoid damage or other accidents. For more information, please consult your local professional car audio store.
- Do not expose the unit to humid environment or water to avoid electric shock, damage and fire due to short circuit.
- To prevent short circuit, please turn off the car and disconnect the car battery before installation.

Functional operation

Panel button function

- Short press the front defrost button on the panel to turn on the front defrost function of the air conditioner.
- Short press the rear defrost button on the panel to turn on the rear defrost function (LV3 also the mirror heating function).
- Short press the power button on the panel to enter the home page; press and hold the power button on the panel for 2 seconds to enter the standby clock interface; press and hold the power button on the panel for 10 seconds to restart the multimedia entertainment system.
- Short press the panel button volume - to decrease the volume; press and hold the panel button volume - to continuously decrease the volume.
- Press the panel button volume + to increase the volume; press and hold the panel button volume + to increase the volume continuously.

Steering wheel controls



【SIRI】 : If the phone link is in use, press the [SIRI] button to enter the Easy Connection voice interface, and the long press is invalid.

【SRC】 : Short press the [SRC] button. The multimedia system will switch between valid sources; long press is invalid.

【◀】 : Short press [◀] key in USB music or BT music to perform the previous song function; and if in FM/AM, will search for radio stations at lower frequencies. Long press [◀] key in USB music to perform fast rewind function; and if in FM/AM, will steps to a lower frequency, when key released, it stops at the current frequency and plays.

【▶】 : Short press [▶] key in USB music or BT music to perform next song function; and if in FM/AM, will searches for stations at higher frequencies. Long press [▶] key in USB music to perform fast forward function; and if In FM/AM, will steps to a higher frequency, when key released, it stops at the current frequency and plays.

【VOL+】 : Short press [Volume +] volume +1; and long press, the volume continues to increase until it is maximum.


【VOL-】 : Short press [Volume -] volume -1; and long press, the volume will continue to decrease until it is minimum.

【TEL ON】 : If Bluetooth is connected and with incoming calls. Short press this button To answer the call; when Bluetooth isn't connected, short press this button to enter the Bluetooth setting page; long press is invalid.

【TEL OFF/MUTE】 : If Bluetooth is connected, and with incoming calls , short press this button to reject the call or hang up the phone. In other cases, short press the button, the multimedia is muted; short press to cancel the mute again; long press is invalid.





- 1) When the car gear is in ACC, ON, or ignition gear, the multimedia entertainment system displays the startup LOGO, and enters the main page after the boot animation ends.
- 2) When the car position is in the OFF position, the multimedia entertainment system will automatically turn off after 3 minutes.
- 3) When the car is in the OFF position, press the power button or switch the driver side door to immediately close the multimedia entertainment system.




1) After entering the main page, you can select [Music], [air conditioner], [Radio] in the shortcut menu to perform the function operation.


2) Icon is divided into two pages, which can be swiped left and right to switch between pages. The first page icons including: Mobile phone, Apple CarPlay, Android Auto ; the second page icons including: Air conditioner, User manual, Settings.


3) Click " " enter the air conditioning control interface.

4) Click " " enter the air conditioning control interface.








5) Click " " turn off air conditioning.

6) Click " " enter the air conditioning control interface.


7) Click " " enter the air conditioning control interface.




1. Music


- 1) Click "  ", enter the music interface.
- 2) Click "  ", Play the next song.
- 3) Click "  ", Play the previous song.
- 4) Click "  ", Open music list.
- 5) Click "  ", Save the current song to my favorites list.
- 6) Click "  ", Set the playback loop mode.
- 7) Click "  ", play/pause music.
- 8) Support audio format: MP3/AAC/ WMA .
- 9) Click the Bluetooth music button to enter the Bluetooth music player interface.

Note: Some audio files may have no sound output due to different audio decoders.



2. Phone

- 1) Click"  , enter the Bluetooth phone interface.
- 2) Click "Recents" to enter the phone call record page, you can select the call record to make a call.
- 3) Click "Keypad" to enter the dial-pad page, you can enter the number and make a call.
- 4) Click "Contacts" Go to the address book page, if the unsynchronized contacts display is not available.




When incoming call, the user can choose to answer or hang up.




4.Apple CarPlay

After the Apple phone is successfully connected, you can use the Apple CarPlay function.



4. Android Auto


After the Android phone is successfully connected, you can use the Android Auto function.





5. Radio


1) Click "  ", enter the radio interface.


2) The radio page can be switched between the "AM" and "FM" bands.


3) Click "  ", During the search, the radio interface will prompt "Search channels, please wait..." and the system will be muted until the search is completed.

4) Click "  ", Stepping to high frequency, the FM step is 50KHz; AM is 1KHz.


5) Click "  ", Stepping to a low frequency, the FM step is 50KHz; AM is 1KHz.


6) Click "  ", The radio performs a downward (high frequency) search function.

7) Click "  ", The radio performs a downward (low frequency) search function.

8) Click "", The current station will be added to my favorites list.






9) Click "", Can control the radio play/pause.


10) Click "", Swipe favorite list to the left.

11) Click "", Swipe favorite list to the right.





6. Air conditioning

- 1) Click "  ", Enter the air conditioning control interface.
- 2) Click [AC] Turn on the air conditioner compressor.
- 3) Click [] / [] The button adjusts the temperature gear or slides the white square to adjust the temperature gear.
- 4) Click [] / [] Press the button to adjust the air volume or slide the white square to adjust the air volume.
- 5) Mode: It is divided into blowing face, blowing face and foot, blowing foot, blowing foot and front defrosting, front defrosting, and rear defrosting mode. Click the mode icon to switch the corresponding mode.
- 6) Loop: divided into inner loop and outer loop, click the loop icon to switch the loop mode.
- 7) OFF: Turn off the air conditioner.



7. Setting

- 1) Click"  , Go to the settings page.
- 2) When entering the Bluetooth switch setting for the first time, the car does not have Bluetooth history pairing, the phone and car Bluetooth need to be paired.
- 3) When the car has historical pairing history, click the Bluetooth name of the mobile phone to connect to the device.
- 4) When Bluetooth is disconnected, you can delete it from the "My Devices" list by clicking the delete icon.




Click the [Vehicle Setting] button to enter the vehicle settings page, including

“Vehicle window” , “Vehicle lock” , “Vehicle lights” , “Wiper” .




1) Remote window lowering: When set to open, the user can remotely roll down all windows by long pressing the remote key unlock button.



1) Automatic door locking: When set to open, when the vehicle speed increases to more than 10km/h, the vehicle door will locked automatically.

2) Vehicle locking prompt: Can be set to flash + whistle or only flash.




1) Lane change flashing: When set to on, after user turn off the change lanes shifter immediately, the lane change lamp will flashing three times. When it is set to off, it will only flashing once.

2) Interior lighting extending time: According to the time set, start counting timing after power off (ON won' t count time, the indoor light will always be on), if the state of the car changes during timing, such as key position, door switch, unlocking, etc, the indoor lamp time counting will be re-calculated. Can be set to 10min, 20min, 30min, the default is 10min.


3) Time setting for Walk me home: set to 30s, after the user locks the car, the headlights will automatically turn off after 30s; so is 50s and 75s. Trigger method: the vehicle is turned off, the headlights continuously turned twice and closed the door, and lock the car. When user leaves the vehicle, the headlights of the vehicle will continue to be illuminated, and

the duration can be set to off, 30s, 50s, 75s (time counting from user locking the door).


4) Find My Vehicle: can be set to flash or flash + whistle. Flash: user quickly presses the lock button twice, the vehicle will lights up and continues to flash for 20s; flash + whistle: the vehicle lights up, continues to flash for 20s and whistle 3 times.




Wiper: When set to On, the wiper moves to the middle of the front windshield, and when set to Off, the wiper returns to the initial position.




Click the [Volume] button to enter the volume setting page. On this page, you can set the media volume, phone volume.



Click the [Display] button to enter the brightness setting page. In this page, you can choose to display the brightness mode [Day] / [Night] / [Auto]. When the [Day] / [Night] mode is selected, the brightness value can be adjusted with the slider.




Click the [Language] button to enter the language setting page. You can switch between English/Spanish.




Date & Time

- 1) Click [Date & Time] button to enter the time setting page.
- 2) In this page, you can select the [12 hours] or [24 hours] format.
- 3) Click [Time Zone] to select the time domain, and bring out the corresponding date and time according to the time domain. After clicking [Set Date]/[Set time], the date/time setting appears. Swipe up and down to set the "Year/Month/Day" or "Hour/Minute" setting.



Click the [Sound Effect] button to enter the sound effect page. On this page, you can set Advanced Sound, Custom Sound, Equal Loudness, and Balance.




1) Factory Reset: Refers to all multimedia features and options restored to factory state.

2) Factory reset conditions:


a. The vehicle power status must be in the ON position

b. The vehicle is at a standstill.

3) The multimedia entertainment system is automatically restarted after the factory reset is successful.



Click [About] to go to the About Wuling page. Display system version information; SOC version, MCU version, hardware version, display version, SN number.



8. User manual

- 1) The user manual implements as a simple electronic manual. The operation instructions and interfaces are made into pictures for the users to view and learn the way to operate this system.
- 2) View the contents by sliding up and down. The contents of the manual will be slightly different depending on the functions.
- 3) Enter the first page by default.
- 4) User manual is for reference only, please refer to the actual product.



9. Reverse Video Control

When the user is in reverse gear, the multimedia entertainment system automatically switches to the reverse video interface.

Note: LV2 only has 4 radars behind, LV3 has 6 radars (front 2 and rear 4)

FCC Notices:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications made to this equipment not expressly approved by SAIC GM Wuling Automobile Co., Ltd. may void the FCC authorization to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.