

DigiDragon



Mobile Phone User Manual

DigiDragon Model:G37

Thank you for purchasing this mobile. For the best performance, we recommend that you read the manual carefully.

CALL CENTER.....	2
MULTIMEDIA.....	3
PHONEBOOK.....	5
MESSAGING.....	6
FILE MANAGER.....	6
SETTINGS.....	7
INTERNET.....	10
FUN.....	11
TOOLS.....	11
CALENDAR.....	11
ALARM.....	11
BLUETOOTH.....	12
CALCULATOR.....	12
STK.....	12
WORLD CLOCK.....	12

Call center

You can view your recent call situation.

[Missed calls]: Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.

[Dialed calls]: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.

[Received calls]: Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency

[Rejected calls]: Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.

Press the OK softkey to enter the options menu can be more than the number of call records in the following:

- Details: View the current record date, time, type.
- Call: Call the current number
- Save: You can save the current record to the phone or SIM card
- Write message: send the current record of SMS
- Add to contacts: the number of the record the name added to the existing record which

Camera

▪ Add to blacklist: the current record to reject a call which

Delete: Delete the currently selected record

- Delete all: Delete all call records
- Mark: Mark to operation

[Delete all]: Delete all call records

[Call times]: Last time zero starting time for last call statistics, a total of dialed calls, received calls, all calls total, all the time can also be zero.

Multimedia

Camera

The phone supports photo, so you can capture your favorite scenes anywhere. Photos will be saved in the phone comes with a file system, photographs as JPG format, you can phone provides photographs sent to a computer via USB connection to view, can also be set Image for the standby

Note : This function can work without driver under Windows XP by directly connecting your mobile to the computer

Audio player

Play audio files, MP3 songs; to play audio files, MP3 songs, press the Up and Down keys to adjust the volume, press the left and right keys to select the

Recorder

present, the next song, press the OK button for the on / off Music

[Start recording]: Start recording

[Record file list]: The memory card inside the recording file list

[Storage]: Set the locate of storage

[File format]: Set the format of record file

FM radio

[Auto search and save]: Channel auto search and save

[Channel list]: View channel list

[Save]: Save the channel to the channel list

[Manual search]: Manually enter the channel and find

[Open speaker]: Choose whether to open the microphone

[Background play]: Choose whether to open the Background Play

[Record]: Record the FM

[Timing record]: Set the time to record

[Record file list]: The list of FM record file

[Storage]: Set the location of storage

[Help]: FM Help

Phonebook

You have 2 phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 300 phone numbers and the SIM card's capacity depends on its type.

l In standby mode, enter a number, press the call key pieces to make a call, press the OK key to save

- If 'To SIM 1/2' is selected, users can edit name and number.

- If 'To phone' is selected, the user can edit the name, mobile number, image, ringtone, caller groups

Into the phone book list, the list on the left displays a small icon indicates that the record exists SIM card or mobile phone, the right is the record of the name and number information.

Standby mode, press the right soft key to enter into the address book or from the menu

Into the address book, do the following:

Messaging

The Messaging function is a network service. Sending and receiving Text can only be used if the service is proposed by your network operator.

You can send ordinary Text messages. The SMS is sent to the Text messages center in the network firstly, and then to the target user. If the receiver's mobile is power off or cannot receive messages, the network will store the message temporarily and the store duration is determined by the user configuration and the service provider.

The message will be directly stored in the SIM card if the capacity is not full. A blinking icon at the head row of the main screen will be displayed if the capacity is full. Messages unread

If the Text message has been sent to the receiver, a beep will sound. (If the tone for Text messages and message report are activated).

File manager

[Memory Card]: SD card needs to support T card

[New folder]: Create a new folder.

[Delete]: delete the specified folder.

[Details]: View the folder or file for more information

[Edit]: The selected folder or rename the file or copy

[Search]: Enter the folder name to find out.

LIMITED WARRANTY PERIOD

The warranty period starts at the time of Product's original purchase by the first end-user. Warranty period for the device and accessories is defined below:-

- a) Twelve (12) months for the mobile device (included in the mobile device sales package)
- b) Six (6) months for the following consumable parts and accessories: batteries, chargers.

Note: This Limited Warranty period will not be extended or renewed or otherwise affected due to subsequent resale, repair and replacement of Product. In the event of repairs of any part/s of the unit, this warranty will thereafter continue and remain in force only till the warranty period applicable from date of purchase.

LIMITED WARRANTY NON-APPLICABILITY

- The completed warranty card is not presented to the service engineer at the time of repairs being undertaken/requested.
- The product purchased is not used in the normal customary manner or not according to instructions given in the Instruction manual or Quick Start Guide, as determined by the company personnel.
- The product is not purchased from an authorized sales dealer.
- The original serial number is removed, obliterated, or altered from the product.
- Defects or damage resulting from misuse, accident, neglect, improper testing operation, maintenance, insulation, alteration, modification, tampering or adjustment.
- Defects or damage caused by viruses from your or from a third party's unauthorized access to services, other accounts, computer systems or networks
- Products rented out or transfer of ownership.
- Operations or damage caused by unauthorized accessories or any other equipment used with the product.
- Without permission of Authorized Local Distributor and/or Service Partner. Non-service personnel or customer himself opening the product without permission of Authorized Distribution and/or Service Partner.
- If the Product has been exposed to moisture, to dampness or to extreme thermal or environmental conditions or to rapid changes in such conditions, to corrosion, to oxidation, to spillage of food or liquid or to influence from chemical products.
- If the product is damaged/broken.

ANY CLAIM UNDER THIS LIMITED WARRANTY IS SUBJECT TO YOU NOTIFYING AUTHORIZED LOCAL DISTRIBUTOR OR ITS AUTHORISED SERVICE CENTRE OF THE ALLEGED DEFECT WITHIN A REASONABLE TIME OF IT HAVING COME TO YOUR ATTENTION BUT NO LATER THAN BEFORE THE EXPIRY OF THE WARRANTY PERIOD.

AUTHORIZED SERVICE NETWORK DETAILS

For information on Service Network, please log on to <http://www.somitech.com.cn/service/mobile>

- This Limited Warranty is non-transferrable and confined only to the first purchaser of the product.
- Repairs under Limited Warranty period shall only be carried by the Authorized service center or personnel
- In order to obtain Limited Warranty service the customer needs to contact and bring the unit to the nearest authorized service center.

Customer's Copy (to be retained by customer)
Please keep this card along with proof of purchase

Name of Customer : _____

Address : _____

Contact Number : _____

Date Of Purchase : _____

Invoice Number : _____

Model No : _____

IMEI Number (Please Put Sticker B): _____

Name and address of Dealer : _____

Customer's Signature & Date _____

(I accept the terms & conditions of warranty*)
*Please read the warranty terms & conditions carefully

Dealer's Signature with Stamp _____

*Please note that the warranty card is invalid without the Authorized Dealer Stamp

[Sort]: By the way you choose to sort the files.
[Mark]: Select Mark / Unmark single / all
[More]

- Memory Card capacity: View the memory card capacity
- Format Memory Card: Format memory card

Settings

Call settings

[Dual-SIM]:

[Standby mode]: Dual SIM standby or standby only SIM1 or SIM2 only

[Reply by original SIM]: Reply the call/SMS by original SIM

[Set SIM name]: SIM1 and SIM2 in the card slot to set the display name

[Set SIM color]: SIM1 and SIM2 in the card slot to set the display color

[Call divert]: Transfer a call, respectively SIM1/SIM2

- Call forwarding unconditional: Set a forwarding number, for forwarding all calls are
- Call forwarding on busy: set the forwarding number, transfer calls when in busy
- Call forwarding on no reply: Set a forwarding number, in case of no response transfer

- Diver if unreachable: to set the forwarding number in the phone unable to connect the case of transfer
- Cancel all diverts: cancel all of the transfer

[Call waiting]: open call waiting, respectively SIM1/SIM2

[Call barring]: respectively SIM1/SIM2 call for restrictions

[Hide ID]: respectively SIM1/SIM2 to hide the machine when the power numbers.

Phone settings

[Date & time]

- Set time: set the phone to display the time
- Set date: set the phone to display the date
- Time format: Set the display time format
- Date format: Set the date display format
- Update time settings: Select open update time

[Language settings]: Select phone display language.

[Shortcut settings]: Set the function of shortcut

[Auto power on/off]: Set the time and frequency of Automatic Turning

[Restore factory settings]: restore the factory settings

Display

[Wallpaper settings]: Set wallpaper

[Brightnss]: adjust the screen's backlight brightness

[Backlight]: Set the time of display light

[Keypad backlight time]: Set the backlight time key

Security setting

[PIN]: Select open or modify the phone's PIN code

[Modify PIN2]: PIN2 choose to modify the phone code

[Phone locked]: Set the phone locked

[Modify the cellphone password]: Modify the password of phone

[Privacy]: set access to enter the password to view functionality. (Including: call logs / message / camera / phonebook / my files / calendar / U disk/audio player/video player)

[Auto keypad lock]: Set the auto keypad lock

[Lock screen by end-key]: Press the end key to select whether the off-screen function

[Fixed dialing]: Set the fixed dialing function

[Blacklist]: Set the blacklist with call or message

Connections

[Network account]: Create or edit the network account

[New connection]: Create a new Internet account

[Add from list]: From the system built-in Internet account to add a new account

[Search]: from the current logged on to Internet search to the card account information, which added to the list after the selected

[Data connection settings]: The type of data connection

[Network selection]: Choose auto or manual select network

Use the effect for menu list

[About my phone]

Introduce the phone functions

Profiles

[Add]: Add the new profile

[Delete]: Delete the profile

[Settings]: Set the selected mode

[Rename]: Rename the profile

[Ring settings]

- SIM call ring: set the SIM card of the ringing tone
- SIM message ring: set the SIM card message

tone

Internet

Use the function of internet

[Bookmark]: Website of interest can be saved in the bookmarks and the bookmarks can be edited or direct them to surf.

[History]: Mobile recently logged in the menu page is saved, you can directly select the records inside the surf

[Offline pages]: Throughout the course of mobile browsing, save the snapshot shown here

[Homepage]: Open the home page

[Settings]: Set account/homepage/content/restore default

[Exit]: Exit browser

Fun

[Snake]:

Provide the Snake game

Tools

Calendar

Press the left soft key to access the calendar display interface, the first line shows the year, month, and the third line shows the week, the middle section shows the specific date of a month, the last line shows the right and left soft key in the message. Interface in the calendar, press the arrow keys on the date forward one week, press the arrow keys to move one week after the date, press the left arrow key date forward one day, press the right arrow keys to move the day after the date, select the date to a dark display

Alarm

This machine has three alarm times available for your settings. Access any time, you can set its status to on / off, ring time, repeat mode, ring tones, alarm clock name, etc.

Bluetooth

[Open Bluetooth]: Choose to activate the Bluetooth

[Bluetooth visibility]: Bluetooth visibility set

[Paired device]: Search and paired Bluetooth devices

[Device name]: Local Bluetooth name

[Bluetooth file storage]: Storage location

[Help]: Help Documentation

Calculator

Can be continuously mixed arithmetic, the operation is simple, practical, convenient

Torch light

Choose to open the torch

STK

Full name of the SIM card application tool kit (SIM Application Tool kit). It can provide you with flexible information functions, such as stock information, traffic information, weather and so on. STK functionality provided by the network operator decision. The business needs the support of SIM cards and network

World clock

View the time of countries

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.