This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



mode, bluetooth indicate blue flicker alternately, together with voice prompts, the speaker is in impairing state at

".click on it in you

automatically once it is turned or

2.If the speak has not been connected with Bluetooth devices before, it will enter impairing mode, click connecting is achievable

3 Other phones or tablets can not be connected with the Bluetooth speaker when the speaker is being connected with a phone or tablet.

4 The phone or tablet can not be connected with the Bluetooth speaker if it is _____ connected with other Bluetooth devices. You should turn off your Bluetooth connection and connect your phone with the Bluetooth speaker again

Lamp function

Long Press the switch of the speaker on the bottom. Turn on the light by tap the mesh on the top, and the lamp will light on in the dimmest grade one. The brightness can be adjusted by tap the top mesh, and there are 3

brightness grades: low brightness, intermediate brightness, and high brightness. Tapping the top mesh when it high brightness, the light will be off.

Frequently Asked Questions

| Questions | Solutions |
|--|---|
| Unsuccessful pairing and connection repeatedly | Check the speaker and make sure it is in the searching state or reboot the speaker. Connection is difficult when there are too many Bluetooth devices nearby. Turn off other Bluetooth devices. Turn off the Bluetooth device that was connected with the Bluetooth speaker last time, and reconnect the speaker r. |
| Muted or distorted sound | Check the volume of your phone or the speaker, and adjust the volume. The battery is low. Please charge it. |
| Choppy music play | Check if the device is beyond the effective connection distance. Check if there is any obstacle between the speaker and your device. |
| The indicator not shining in Bluetooth mode | 1.The battery is low. Please charge it. 2.Please reboot the speaker. |