

品名:	T26说明书 (中性通用)	材料 工艺:	成品尺寸: 53*80mm
时间:	2020-09-08		双面单黑印刷, 40P, 骑马钉
制作:	王润婷		105g哑粉纸
料号:	SM-EJ-T26-V1		

英

<p>封底</p> <p>T26 Wireless Earbuds User Manual</p>	<p>封面</p> <p>T26 Wireless Earbuds User Manual</p>	<p>English Version</p> <p>Package Contents 1 At a Glance 2 Earbuds LED Indicator Guide 3 Charging Case LED Indicator Guide 4 Using the Earbuds 5 Charging the Earbuds and Charging Case 6 Trouble Shooting 9 Specifications 10 SAFETY AND WARRANTY 11</p>	<p>Deutsche Version</p> <p>Paketinhalte 1 Überblick 2 Anleitung zu den LED-Anzeigen der Kopfhörer 3 LED-Anzeige für den Ladekoffer 4 Verwendung der Kopfhörer 5 Laden des Kopfhörers und des Ladekoffers 6 Fehlerbehebung 9 Spezifikationen 10 SICHERHEIT UND GARANTIE 11</p>	<p>Package Contents</p> <p>1. Wireless earbuds x 1 pair (L / R) 2. Charging case x 1 3. Earbuds x 2 pairs (S / M / L, M size ear tips provided) 4. USB-C charging cable x 1 5. User manual x 1 6. Quick start guide x 1</p>	<p>At a Glance</p> <p>Charging Case</p> <p>Earbuds</p>	<p>Earbuds LED Indicator Guide</p> <table border="1"> <thead> <tr> <th>System State</th> <th>Indicator Activity</th> </tr> </thead> <tbody> <tr> <td>Powering On</td> <td>Flashes red and white alternately</td> </tr> <tr> <td>Connected</td> <td>Flashes white once every 3 seconds</td> </tr> <tr> <td>Being charged</td> <td>Not lit</td> </tr> <tr> <td>Fully charged</td> <td>Off</td> </tr> <tr> <td>Low battery</td> <td>Flashes red four every 3 seconds, left ear only</td> </tr> </tbody> </table>	System State	Indicator Activity	Powering On	Flashes red and white alternately	Connected	Flashes white once every 3 seconds	Being charged	Not lit	Fully charged	Off	Low battery	Flashes red four every 3 seconds, left ear only	<p>Notes:</p> <p>The charging indicator stops red when the charging case is being charged and goes of when fully charged.</p> <p>Using the Earbuds</p> <p>When you use the earbuds for the first time, remove the charging case from the charging contacts of the earbuds.</p> <p>Charge the earbuds</p> <p>1) Plug the earbuds into the USB-C cable in the charging case. 2) Close the case lid.</p>	<p>Notes:</p> <p>1) Make sure the earbuds and your Bluetooth device are not too close or when it's too far and there are no obstacles between.</p> <p>2) Turn on the Bluetooth of both earbuds to sync with the Bluetooth of your Bluetooth device.</p> <p>3) Turn on the Bluetooth of your Bluetooth device.</p> <p>4) In the list of found Bluetooth devices in your Bluetooth device, choose "T26" to pair.</p>	<p>Button controls</p> <table border="1"> <thead> <tr> <th>Function</th> <th>What to do</th> </tr> </thead> <tbody> <tr> <td>Play/Pause</td> <td>Double-press the touch button of either earbud.</td> </tr> <tr> <td>Previous/Next track</td> <td>Triple-press the touch button of the touch button.</td> </tr> <tr> <td>Answer/End a call</td> <td>Double-press the touch button of either earbud for 2 seconds.</td> </tr> <tr> <td>Reject a call</td> <td>Tap and hold the touch button of either earbud for 2 seconds.</td> </tr> <tr> <td>Active/Deactive</td> <td>Tap and hold the touch button for 5 seconds when using the touch button.</td> </tr> </tbody> </table> <p>Reset the earbuds</p> <p>1) Put the earbuds back into the charging case and the earbuds indicator stays red.</p> <p>2) Hold the touch button of both earbuds for 10 seconds and the indicator of the right earbud flashes white 3 times.</p>	Function	What to do	Play/Pause	Double-press the touch button of either earbud.	Previous/Next track	Triple-press the touch button of the touch button.	Answer/End a call	Double-press the touch button of either earbud for 2 seconds.	Reject a call	Tap and hold the touch button of either earbud for 2 seconds.	Active/Deactive	Tap and hold the touch button for 5 seconds when using the touch button.								
System State	Indicator Activity																																								
Powering On	Flashes red and white alternately																																								
Connected	Flashes white once every 3 seconds																																								
Being charged	Not lit																																								
Fully charged	Off																																								
Low battery	Flashes red four every 3 seconds, left ear only																																								
Function	What to do																																								
Play/Pause	Double-press the touch button of either earbud.																																								
Previous/Next track	Triple-press the touch button of the touch button.																																								
Answer/End a call	Double-press the touch button of either earbud for 2 seconds.																																								
Reject a call	Tap and hold the touch button of either earbud for 2 seconds.																																								
Active/Deactive	Tap and hold the touch button for 5 seconds when using the touch button.																																								
<p>Trouble Shooting</p> <p>Q: Pairing fails</p> <p>1) Put the earbuds back to the charging case and earbuds are being charged.</p> <p>2) Take the earbuds out of the case and earbuds enter pairing mode.</p> <p>3) Choose "T26" in your phone to pair.</p> <p>4) If the pairing still fails, check the following points:</p> <ul style="list-style-type: none"> Make sure the earbuds and your Bluetooth device are not too close or when it's too far and there are no obstacles between. Turn on the Bluetooth of both earbuds to sync with the Bluetooth of your Bluetooth device. Turn on the Bluetooth of your Bluetooth device. 	<p>Q: I paired the earbuds with my phone before, but failed to pair them with my phone again.</p> <p>1) Turn on the Bluetooth of your phone and in "T26" choose "T26" and tap "T26" - Forget This Device". Then pair the earbuds with your phone again.</p> <p>2) Choose "T26" in your phone to pair.</p> <p>3) If the pairing still fails, check the following points:</p> <ul style="list-style-type: none"> Make sure the earbuds and your Bluetooth device are not too close or when it's too far and there are no obstacles between. Turn on the Bluetooth of both earbuds to sync with the Bluetooth of your Bluetooth device. Turn on the Bluetooth of your Bluetooth device. 	<p>Q: When playing music, the left and right earbuds cannot be synchronized.</p> <p>1) Tap and hold the touch button of the RIGHT earbud for 2 seconds to enter the ANC function and the two earbuds will be synchronized.</p> <p>2) Choose "T26" in your phone to pair.</p> <p>3) If the pairing still fails, check the following points:</p> <ul style="list-style-type: none"> Make sure the earbuds and your Bluetooth device are not too close or when it's too far and there are no obstacles between. Turn on the Bluetooth of both earbuds to sync with the Bluetooth of your Bluetooth device. Turn on the Bluetooth of your Bluetooth device. 	<p>Specifications</p> <table border="1"> <thead> <tr> <th>Model</th> <th>T26</th> </tr> </thead> <tbody> <tr> <td>Bluetooth version</td> <td>V5.2</td> </tr> <tr> <td>Battery</td> <td>20mAh (each earbud), 200mAh (charging case)</td> </tr> <tr> <td>Charging time</td> <td>Approximately 1.5 hours (charging case)</td> </tr> <tr> <td>Usage time</td> <td>Up to 5 hours per charge</td> </tr> <tr> <td>Playtime (earbuds)</td> <td>Up to 5 hours per charge (ANC off), 4 hours per charge (ANC on)</td> </tr> <tr> <td>Playtime (charging case)</td> <td>Up to 20 hours per charge (ANC off), 18 hours per charge (ANC on)</td> </tr> <tr> <td>Bluetooth Range</td> <td>10 ~ 132 ft</td> </tr> <tr> <td>Supporting Protocol</td> <td>A2DP, AVRCP, HSP, HFP, A2DP, AVRCP</td> </tr> <tr> <td>Working Temperature</td> <td>0°C to 40°C</td> </tr> </tbody> </table>	Model	T26	Bluetooth version	V5.2	Battery	20mAh (each earbud), 200mAh (charging case)	Charging time	Approximately 1.5 hours (charging case)	Usage time	Up to 5 hours per charge	Playtime (earbuds)	Up to 5 hours per charge (ANC off), 4 hours per charge (ANC on)	Playtime (charging case)	Up to 20 hours per charge (ANC off), 18 hours per charge (ANC on)	Bluetooth Range	10 ~ 132 ft	Supporting Protocol	A2DP, AVRCP, HSP, HFP, A2DP, AVRCP	Working Temperature	0°C to 40°C	<p>SAFETY AND WARRANTY</p> <p>Important safety instructions</p> <ul style="list-style-type: none"> Use of earbuds may impair your ability to hear other sounds. Use caution when using your earbuds when you are engaged in any activity that requires your full attention. If you have a pacemaker or other electrical medical device, consult your physician before using this product. This product is not a toy - never allow children to play with this product. The bag components of the very small parts may be inhaled or swallowed. If you have children, please do not use this product. Do not use the product in wet areas, such as in a shower or while swimming, or when participating in water sports, e.g., swimming, water skiing, surfing, etc. Do NOT wear the earbuds while driving or operating machinery. Do NOT expose the product to moving water, such as rain, snow, etc. Do NOT wear the earbuds while driving or operating machinery. Do NOT expose the product to moving water, such as rain, snow, etc. Do NOT use the product in wet areas, such as in a shower or while swimming, or when participating in water sports, e.g., swimming, water skiing, surfing, etc. Use of a power supply or charger that is not recommended or used in power pack, may damage the product. Do not use the product in wet areas, such as in a shower or while swimming, or when participating in water sports, e.g., swimming, water skiing, surfing, etc. 	<p>Do not use the charging case in excess of its rated output.</p> <p>Do not use a charging case that is damaged or modified. Damaged or modified cases may affect the performance of the earbuds.</p> <p>Disposal of the product according to local regulations and regulations.</p> <p>WARRANTY</p> <p>We strive to build our products with the highest attention to detail and performance; however, sometimes there are occurrences of defect, so we are happy to offer a 12-month warranty for you. For any questions about our products, please contact us.</p>	<p>Using the Earbuds</p> <p>When you use the earbuds for the first time, remove the charging case from the charging contacts of the earbuds.</p> <p>Charge the earbuds</p> <p>1) Plug the earbuds into the USB-C cable in the charging case. 2) Close the case lid.</p>	<p>Notes:</p> <p>1) Make sure the earbuds and your Bluetooth device are not too close or when it's too far and there are no obstacles between.</p> <p>2) Turn on the Bluetooth of both earbuds to sync with the Bluetooth of your Bluetooth device.</p> <p>3) Turn on the Bluetooth of your Bluetooth device.</p> <p>4) In the list of found Bluetooth devices in your Bluetooth device, choose "T26" to pair.</p>	<p>Button controls</p> <table border="1"> <thead> <tr> <th>Function</th> <th>What to do</th> </tr> </thead> <tbody> <tr> <td>Play/Pause</td> <td>Double-press the touch button of either earbud.</td> </tr> <tr> <td>Previous/Next track</td> <td>Triple-press the touch button of the touch button.</td> </tr> <tr> <td>Answer/End a call</td> <td>Double-press the touch button of either earbud for 2 seconds.</td> </tr> <tr> <td>Reject a call</td> <td>Tap and hold the touch button of either earbud for 2 seconds.</td> </tr> <tr> <td>Active/Deactive</td> <td>Tap and hold the touch button for 5 seconds when using the touch button.</td> </tr> </tbody> </table> <p>Reset the earbuds</p> <p>1) Put the earbuds back into the charging case and the earbuds indicator stays red.</p> <p>2) Hold the touch button of both earbuds for 10 seconds and the indicator of the right earbud flashes white 3 times.</p>	Function	What to do	Play/Pause	Double-press the touch button of either earbud.	Previous/Next track	Triple-press the touch button of the touch button.	Answer/End a call	Double-press the touch button of either earbud for 2 seconds.	Reject a call	Tap and hold the touch button of either earbud for 2 seconds.	Active/Deactive	Tap and hold the touch button for 5 seconds when using the touch button.	<p>Missing the Earbuds and Charging Case</p> <p>The earbuds and charging case may require periodic cleaning.</p> <p>Earbud cover</p> <p>Close only with a dry cloth. Do not use any liquid or abrasive materials on the earbud cover.</p> <p>Charging case</p> <p>Close only with a dry cloth. Do not use any liquid or abrasive materials on the charging case.</p>
Model	T26																																								
Bluetooth version	V5.2																																								
Battery	20mAh (each earbud), 200mAh (charging case)																																								
Charging time	Approximately 1.5 hours (charging case)																																								
Usage time	Up to 5 hours per charge																																								
Playtime (earbuds)	Up to 5 hours per charge (ANC off), 4 hours per charge (ANC on)																																								
Playtime (charging case)	Up to 20 hours per charge (ANC off), 18 hours per charge (ANC on)																																								
Bluetooth Range	10 ~ 132 ft																																								
Supporting Protocol	A2DP, AVRCP, HSP, HFP, A2DP, AVRCP																																								
Working Temperature	0°C to 40°C																																								
Function	What to do																																								
Play/Pause	Double-press the touch button of either earbud.																																								
Previous/Next track	Triple-press the touch button of the touch button.																																								
Answer/End a call	Double-press the touch button of either earbud for 2 seconds.																																								
Reject a call	Tap and hold the touch button of either earbud for 2 seconds.																																								
Active/Deactive	Tap and hold the touch button for 5 seconds when using the touch button.																																								

德

<p>T26 Bluetooth Kopfhörer Benutzerhandbuch</p> <p>1. Bluetooth Kopfhörer x 1 Paar (L / R) 2. Ladekoffer x 1 3. Ohrstöpsel x 3 Paare (S / M / L, M Größe Ohrstöpsel sind im Lieferumfang enthalten) 4. USB-C-Ladekabel x 1 5. Benutzerhandbuch x 1 6. Schnellstartanleitung x 1</p>	<p>Paketinhalte</p>	<p>Überblick</p> <p>Ladekoffer</p> <p>Kopfhörer</p>	<p>Anleitung zu den LED-Anzeigen der Kopfhörer</p> <table border="1"> <thead> <tr> <th>Systemzustand</th> <th>LED-Anzeigeaktivität</th> </tr> </thead> <tbody> <tr> <td>Einrichten</td> <td>Flashes red and white alternately</td> </tr> <tr> <td>Verbunden</td> <td>Flashes white once every 3 seconds</td> </tr> <tr> <td>Wird geladen</td> <td>Not lit</td> </tr> <tr> <td>Vollständig geladen</td> <td>Off</td> </tr> <tr> <td>Niedrige Batterie</td> <td>Flashes red four every 3 seconds, left ear only</td> </tr> </tbody> </table>	Systemzustand	LED-Anzeigeaktivität	Einrichten	Flashes red and white alternately	Verbunden	Flashes white once every 3 seconds	Wird geladen	Not lit	Vollständig geladen	Off	Niedrige Batterie	Flashes red four every 3 seconds, left ear only	<p>Verwendung der Kopfhörer</p> <p>Laden Sie die Kopfhörer auf</p> <p>1) Stecken Sie die Ohrstöpsel in die Ladekoffer.</p> <p>2) Schließen Sie den Ladekoffer.</p> <p>Laden Sie den Ladekoffer auf</p> <p>1) Stecken Sie das andere Ende des USB-C-Kabels in den USB-C-Port des Ladekoffers.</p> <p>2) Schließen Sie das andere Ende in einen USB-Adapter ein oder einen Computer (USB-C) ein, um es anzuschließen.</p>	<p>Einwickeln</p> <p>Einwickeln: Öffnen Sie den Ladekoffer.</p> <p>Auswickeln: Schließen Sie den Ladekoffer (2) wieder.</p> <p>Einwickeln</p> <p>Wenn die Kopfhörer in Ladekoffer aufbewahrt werden, schließen Sie den Ladekoffer automatisch.</p>	<p>Planung</p> <p>1) Stellen Sie sicher, dass die Kopfhörer und der Bluetooth-Controller synchronisiert sind.</p> <p>2) Stellen Sie sicher, dass die Kopfhörer und der Bluetooth-Controller synchronisiert sind.</p> <p>Wichtige Sicherheitsanweisungen</p> <ul style="list-style-type: none"> Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. 	<p>ANC-Funktion</p> <p>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang, um die ANC-Funktion zu aktivieren / deaktivieren. Wenn Sie einen Kopfhörer verwenden, wird die ANC-Funktion automatisch deaktiviert.</p>	<p>Verwendung der Kopfhörer und des Ladekoffers</p> <table border="1"> <thead> <tr> <th>Funktion</th> <th>Was ist zu tun</th> </tr> </thead> <tbody> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> </tbody> </table>	Funktion	Was ist zu tun	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	<p>Fehlerbehebung</p> <p>F: Die Paarung schlägt fehl.</p> <p>A: 1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p> <p>Wenn die Kopplung immer noch fehlerhaft ist, überprüfen Sie die folgenden Punkte:</p> <ul style="list-style-type: none"> Stellen Sie sicher, dass beide die Kopfhörer und der Bluetooth-Controller synchronisiert sind. Stellen Sie sicher, dass beide die Kopfhörer und der Bluetooth-Controller synchronisiert sind. 				
Systemzustand	LED-Anzeigeaktivität																																
Einrichten	Flashes red and white alternately																																
Verbunden	Flashes white once every 3 seconds																																
Wird geladen	Not lit																																
Vollständig geladen	Off																																
Niedrige Batterie	Flashes red four every 3 seconds, left ear only																																
Funktion	Was ist zu tun																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																
<p>Es gibt andere Bluetooth-Geräte, die in der Nähe sind, aber nicht synchronisiert werden.</p> <p>1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p>	<p>Spezifikationen</p> <table border="1"> <thead> <tr> <th>Modell</th> <th>T26</th> </tr> </thead> <tbody> <tr> <td>Bluetooth-Version</td> <td>V5.2</td> </tr> <tr> <td>Batterie</td> <td>20mAh (jeweils Kopfhörer), 200mAh (Ladekoffer)</td> </tr> <tr> <td>Ladezeit</td> <td>Ca. 1,5 Stunden (Ladekoffer)</td> </tr> <tr> <td>Wiedersprechzeit</td> <td>Bis zu 5 Stunden pro Ladung</td> </tr> <tr> <td>Empfang</td> <td>10 ~ 132 ft</td> </tr> <tr> <td>Unterstützte Protokolle</td> <td>A2DP, AVRCP, HSP, HFP, A2DP, AVRCP</td> </tr> <tr> <td>Arbeitsbereich</td> <td>0°C bis 40°C</td> </tr> </tbody> </table>	Modell	T26	Bluetooth-Version	V5.2	Batterie	20mAh (jeweils Kopfhörer), 200mAh (Ladekoffer)	Ladezeit	Ca. 1,5 Stunden (Ladekoffer)	Wiedersprechzeit	Bis zu 5 Stunden pro Ladung	Empfang	10 ~ 132 ft	Unterstützte Protokolle	A2DP, AVRCP, HSP, HFP, A2DP, AVRCP	Arbeitsbereich	0°C bis 40°C	<p>SICHERHEIT UND GARANTIE</p> <p>Wichtige Sicherheitsanweisungen</p> <ul style="list-style-type: none"> Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen. 	<p>Das Verarbeiten des Produkts an heißen oder kalten Orten, wie z.B. in einem Sportwagen, kann zu einer Schwellung des Produkts führen.</p> <p>1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p>	<p>Faktoren, die die Leistung des Kopfhörers beeinträchtigen können.</p> <p>1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p>	<p>Garantie</p> <p>Wir sind bestrebt, unsere Produkte mit der höchsten Aufmerksamkeit zu entwickeln und zu produzieren. Dennoch können gelegentlich Defekte auftreten, die nicht auf unsere Mängel zurückzuführen sind. Wir sind bereit, eine 12-monatige Garantie für Sie anzubieten. Für alle Fragen zu unseren Produkten kontaktieren Sie bitte unseren Kundendienst.</p>	<p>ANC-Funktion</p> <p>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang, um die ANC-Funktion zu aktivieren / deaktivieren. Wenn Sie einen Kopfhörer verwenden, wird die ANC-Funktion automatisch deaktiviert.</p>	<p>Verwendung der Kopfhörer und des Ladekoffers</p> <table border="1"> <thead> <tr> <th>Funktion</th> <th>Was ist zu tun</th> </tr> </thead> <tbody> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> <tr> <td>Abbrechen / Paaren</td> <td>Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.</td> </tr> </tbody> </table>	Funktion	Was ist zu tun	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.	<p>Fehlerbehebung</p> <p>F: Die Paarung schlägt fehl.</p> <p>A: 1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p>	<p>F: Ich habe die Kopfhörer schon einmal mit meinem Telefon gekoppelt, aber es ist mir nicht gelungen, sie wieder zu koppeln.</p> <p>A: 1) Gehen Sie die Kopfhörer wieder in den Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>2) Nehmen Sie die Kopfhörer aus dem Ladekoffer und die Kopfhörer werden synchronisiert.</p> <p>3) Wählen Sie "T26" in Ihrem Telefon zu koppeln.</p>
Modell	T26																																
Bluetooth-Version	V5.2																																
Batterie	20mAh (jeweils Kopfhörer), 200mAh (Ladekoffer)																																
Ladezeit	Ca. 1,5 Stunden (Ladekoffer)																																
Wiedersprechzeit	Bis zu 5 Stunden pro Ladung																																
Empfang	10 ~ 132 ft																																
Unterstützte Protokolle	A2DP, AVRCP, HSP, HFP, A2DP, AVRCP																																
Arbeitsbereich	0°C bis 40°C																																
Funktion	Was ist zu tun																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																
Abbrechen / Paaren	Tippen Sie auf die Touch-Taste des Bluetooth-Kopfhörers 2 Sekunden lang.																																