





Restrict Band NVNT ac40 5190MHz Ant1 Peak




Restrict Band NVNT ac40 5190MHz Ant1 Average






Restrict Band NVNT ac40 5230MHz Ant1 Peak




Restrict Band NVNT ac40 5230MHz Ant1 Average






Restrict Band NVNT ac80 5210MHz Ant1 Peak




Restrict Band NVNT ac80 5210MHz Ant1 Average






Restrict Band NVNT ac80 5210MHz Ant1 Peak




Restrict Band NVNT ac80 5210MHz Ant1 Average






Restrict Band NVNT ax20 5180MHz Ant1 Peak




Restrict Band NVNT ax20 5180MHz Ant1 Average






Restrict Band NVNT ax20 5240MHz Ant1 Peak




Restrict Band NVNT ax20 5240MHz Ant1 Average






Restrict Band NVNT ax40 5190MHz Ant1 Peak




Restrict Band NVNT ax40 5190MHz Ant1 Average






Restrict Band NVNT ax40 5230MHz Ant1 Peak




Restrict Band NVNT ax40 5230MHz Ant1 Average






Restrict Band NVNT ax80 5210MHz Ant1 Peak




Restrict Band NVNT ax80 5210MHz Ant1 Average






Restrict Band NVNT ax80 5210MHz Ant1 Peak



Restrict Band NVNT ax80 5210MHz Ant1 Average





D.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5180	0	0	25	Pass
NVNT	a	5200	Ant1	5199.98	-20000	-3.85	25	Pass
NVNT	a	5240	Ant1	5240	0	0	25	Pass
NVNT	n20	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	n20	5200	Ant1	5200	0	0	25	Pass
NVNT	n20	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NVNT	n40	5190	Ant1	5190	0	0	25	Pass
NVNT	n40	5230	Ant1	5230	0	0	25	Pass
NVNT	ac20	5180	Ant1	5180	0	0	25	Pass
NVNT	ac20	5200	Ant1	5199.98	-20000	-3.85	25	Pass
NVNT	ac20	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NVNT	ac40	5190	Ant1	5190	0	0	25	Pass
NVNT	ac40	5230	Ant1	5230	0	0	25	Pass
NVNT	ac80	5210	Ant1	5210	0	0	25	Pass
NVNT	ax20	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	ax20	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NVNT	ax20	5240	Ant1	5240	0	0	25	Pass
NVNT	ax40	5190	Ant1	5190	0	0	25	Pass
NVNT	ax40	5230	Ant1	5230	0	0	25	Pass
NVNT	ax80	5210	Ant1	5210	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
 Scan code to check authenticity




Test Graphs

Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5200MHz Ant1






Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT n20 5180MHz Ant1






Freq. Stability NVNT n20 5200MHz Ant1




Freq. Stability NVNT n20 5240MHz Ant1






Freq. Stability NVNT n40 5190MHz Ant1




Freq. Stability NVNT n40 5230MHz Ant1






Freq. Stability NVNT ac20 5180MHz Ant1




Freq. Stability NVNT ac20 5200MHz Ant1






Freq. Stability NVNT ac20 5240MHz Ant1




Freq. Stability NVNT ac40 5190MHz Ant1






Freq. Stability NVNT ac40 5230MHz Ant1




Freq. Stability NVNT ac80 5210MHz Ant1






Freq. Stability NVNT ax20 5180MHz Ant1




Freq. Stability NVNT ax20 5200MHz Ant1






Freq. Stability NVNT ax20 5240MHz Ant1




Freq. Stability NVNT ax40 5190MHz Ant1






Freq. Stability NVNT ax40 5230MHz Ant1



Freq. Stability NVNT ax80 5210MHz Ant1





D.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	94.65	0.24	0.91
NVNT	a	5200	Ant1	94.65	0.24	0.91
NVNT	a	5240	Ant1	94.56	0.24	0.91
NVNT	n20	5180	Ant1	93.67	0.28	1.07
NVNT	n20	5200	Ant1	93.77	0.28	1.07
NVNT	n20	5240	Ant1	93.77	0.28	1.07
NVNT	n40	5190	Ant1	90.3	0.44	1.73
NVNT	n40	5230	Ant1	90.14	0.45	1.74
NVNT	ac20	5180	Ant1	93.72	0.28	1.06
NVNT	ac20	5200	Ant1	93.82	0.28	1.06
NVNT	ac20	5240	Ant1	93.72	0.28	1.06
NVNT	ac40	5190	Ant1	90.2	0.45	1.72
NVNT	ac40	5230	Ant1	90.2	0.45	1.72
NVNT	ac80	5210	Ant1	87	0.6	2.41
NVNT	ax20	5180	Ant1	93.72	0.28	1.06
NVNT	ax20	5200	Ant1	93.82	0.28	1.06
NVNT	ax20	5240	Ant1	93.82	0.28	1.06
NVNT	ax40	5190	Ant1	90.36	0.44	1.72
NVNT	ax40	5230	Ant1	90.2	0.45	1.72
NVNT	ax80	5210	Ant1	87	0.6	2.41




Shenzhen LCS Compliance Testing Laboratory Ltd.
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
 Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1






Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1






Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1






Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1






Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1






Duty Cycle NVNT ac20 5240MHz Ant1




Duty Cycle NVNT ac40 5190MHz Ant1






Duty Cycle NVNT ac40 5230MHz Ant1




Duty Cycle NVNT ac80 5210MHz Ant1






Duty Cycle NVNT ax20 5180MHz Ant1




Duty Cycle NVNT ax20 5200MHz Ant1






Duty Cycle NVNT ax20 5240MHz Ant1




Duty Cycle NVNT ax40 5190MHz Ant1





Duty Cycle NVNT ax40 5230MHz Ant1



Duty Cycle NVNT ax80 5210MHz Ant1

