



Thank you for purchasing your new Leg Messenger. To help you get the most out of your Leg Messenger, we've included this manual and additional information. We encourage you to read this manual carefully. It contains important information that will help you get the most out of your Leg Messenger. Please read this manual carefully before using your Leg Messenger.

Table Of Contents	
Product Introduction	14
Product Parts	14
Message Position	14
Installation	15
Buttons Operation	15-16
APP	15
Charger	15
Maintenance	15
Product Safety Information	15-16
Warnings	15
Specifications	15
Packing List	15
Warranty	15

Product Brief Introduction
The Leg Messenger can be used to receive messages in a variety of ways. It can be used to receive messages from a mobile phone, a tablet, or a computer. It can also be used to receive messages from a smartwatch or a fitness tracker. The Leg Messenger is a convenient way to stay connected to your messages without having to take your phone out of your pocket or bag.

Product Parts
The Leg Messenger consists of the following parts:
 - Leg Messenger
 - Charging Cable
 - User Manual
 - Protective Case

Message Position
The Leg Messenger has a message display on the front. The message display is located in the center of the device. The message display is used to display text messages, email notifications, and social media notifications. The message display is also used to display the time and battery level.

Installation
To use the Leg Messenger, you need to install it on your leg. The Leg Messenger is designed to be worn on the back of your leg. To install the Leg Messenger, you need to follow the following steps:
 1. Remove the Leg Messenger from its protective case.
 2. Wrap the Leg Messenger around your leg.
 3. Adjust the Leg Messenger so that it is comfortable to wear.

Buttons & Operations
The Leg Messenger has several buttons and operations. The buttons are used to navigate through the message display. The operations are used to interact with the message display. The buttons and operations are described in the following sections:
 - Partial Message Button
 - Full Message Button
 - Power Button
 - LED Indicator Light
 - Auto Message Button



APP
The Leg Messenger has a companion app that can be downloaded from the App Store or Google Play. The app is used to manage the Leg Messenger and to receive messages. The app is available in both English and Spanish.

Charger
The Leg Messenger is charged using the included charging cable. The charging cable is used to connect the Leg Messenger to a power source. The charging cable is used to charge the Leg Messenger when it is not being used.

APP
The Leg Messenger has a companion app that can be downloaded from the App Store or Google Play. The app is used to manage the Leg Messenger and to receive messages. The app is available in both English and Spanish.



Charger
The Leg Messenger is charged using the included charging cable. The charging cable is used to connect the Leg Messenger to a power source. The charging cable is used to charge the Leg Messenger when it is not being used.

Maintenance
The Leg Messenger should be cleaned regularly to keep it in good condition. The Leg Messenger should be cleaned with a soft, dry cloth. The Leg Messenger should not be cleaned with water or other liquids. The Leg Messenger should not be cleaned with abrasive materials.

Diagnosis
If the Leg Messenger is not working properly, there may be a problem. The following steps can be used to diagnose the problem:
 1. Check the battery level.
 2. Check the message position.
 3. Check the message display.

Important Safety Instructions
The Leg Messenger is a personal electronic device. It should be used in accordance with the following safety instructions:
 1. Do not use the Leg Messenger while driving or operating machinery.
 2. Do not use the Leg Messenger in areas where the use of mobile phones is prohibited.
 3. Do not use the Leg Messenger in areas where the use of mobile phones is restricted.

Specifications
The Leg Messenger has the following specifications:
 - Dimensions: 100mm x 50mm x 20mm
 - Weight: 100g
 - Battery Life: 10 hours
 - Charging Time: 2 hours

Packing List
The Leg Messenger is packed in the following items:
 - Leg Messenger
 - Charging Cable
 - User Manual
 - Protective Case

Warranty
The Leg Messenger is covered by a 1-year warranty. The warranty covers defects in materials and workmanship. The warranty does not cover damage caused by misuse or accidents.

Specifications
The Leg Messenger has the following specifications:
 - Dimensions: 100mm x 50mm x 20mm
 - Weight: 100g
 - Battery Life: 10 hours
 - Charging Time: 2 hours

Packing List
The Leg Messenger is packed in the following items:
 - Leg Messenger
 - Charging Cable
 - User Manual
 - Protective Case

Warranty
The Leg Messenger is covered by a 1-year warranty. The warranty covers defects in materials and workmanship. The warranty does not cover damage caused by misuse or accidents.