

REV. 版本	MARK 标记	ECN. NO. 变更单编码	DAT DESCRIPTION 修订内容	DATE 日期	CHANGE 变更者
-	⊗	-	-		

白噪机说明书_70x100

底

100mm

<p>70mm</p> <p>Precautions</p> <ol style="list-style-type: none"> Please do not disassemble or repair the device yourself, otherwise it will be deemed as abandoning the warranty service. Do not place the device near any heat source or under direct sunlight. Unplug the power adapter when you are not using it for a long time. Turn off the power before cleaning. <p>Parts</p>	<p>70mm</p> <p>LED and Button Rules</p> <ol style="list-style-type: none"> Volume up. Volume down. Short press to choose from cool to warm light appearance. ON/OFF: Short press to turn the light on/off. Long press 3s to turn both light and sound off. RGB: Short press to choose the next color (7 colors in total). Play or pause the sound. Short press to choose the next sound (11 sounds in total). Mode: Short press to choose the next favorite mode. Long press 5s to factory reset the device. 	<p>70mm</p> <p>⑨ Rotate: Rotate to adjust the light brightness. ⑩ Status LED Flashing Rapidly(twice/sec): Initialization/ Wi-Fi connecting mode/Reset/Firmware upgrading mode. Flashing slowly(once/sec): Configuration mode. Off: Successfully connected.</p> <p>⑪ Main Light</p> <p>Setup</p> <ol style="list-style-type: none"> Download the Meross app and choose the Cherub Baby Machine to get start. Connect the cable and power up the device. Please set near the main Wi-Fi.* 	<p>70mm</p> <p>*Proximity to main Wi-Fi is only required during the initial setup process. * The device only supports 2.4GHz networks.</p> <p>3. Open Meross app and follow the setup wizard for configuration. You can find specific support documents in Meross app. (Device Settings/ User Manual)</p> <p>Tips For App</p> <ol style="list-style-type: none"> Home Page. <ul style="list-style-type: none"> On/Off: Turn both light and sound on/off. ☞: Turn sound on/off. ☞: Turn light on/off. < > : Press to choose the prior/next favorite mode. ☰: Enter into Device Settings page. 	<p>70mm</p> <p>2. Device Page.</p> <ul style="list-style-type: none"> ☼: To choose different light color. ☺: To choose different sound. ♥: To choose and set favorite modes (combination of light and sound). ⌚: Timer to turn light off. ⏻: Turn on/off the device. ☰: Main interface adjusts brightness and volume. ☰: Enter into Device Settings page. ☆: To save current light and sound appearance as a favorite mode. <p>3. Routines Set the routines in Device Settings->Automation->Routines. You can automatically turn the cherub baby machine on or off at the expected time. For instance, you can turn it on at 9:00 PM everyday to help baby sleep on time.</p>	<p>70mm</p> <p>4. Device Settings</p> <p>General Settings Device Name: Change device name User manual: Check user manual</p> <p>Automation -> Routines: Add customized routine rules. Security -> Child lock: To disable physical buttons.</p> <p>Device Info Check the signal strength of your WiFi, model number, and MAC address, as well as firmware and hardware versions to make sure your device is up to date.</p> <p>Remove Device You can remove/reset the device from Meross app.</p> <p>4. Voice Control</p> <p>Please scan to see the voice control guide or go to Device Settings->Voice Control for more voice information.</p>
---	--	---	--	--	--

面

<p>SIMPLE DEVICE SIMPLIFY YOUR LIFE</p>	<p>Amazon Alexa</p> <p>works with amazon alexa</p> <ul style="list-style-type: none"> "Alexa, dim Cherub Baby Machine 30%." "Alexa, set the Cherub Baby Machine to red/warm white." "Alexa, mute device." "Alexa, set the sound to lullaby on Cherub Baby Machine." "Alexa, turn on light for the Cherub Baby Machine." <p>Google Assistant:</p> <p>works with the Google Assistant</p> <ul style="list-style-type: none"> "Hey Google, adjust Cherub Baby Machine to 65% brightness." "Hey Google, brighten Cherub Baby Machine." "Hey Google, make the Cherub Baby Machine magenta." "Hey Google, turn off light on the Cherub Baby Machine." 	<p>2. Can I control the Cherub Baby Machine from multiple smartphones?</p> <p>Yes. Download Meross app to your devices and sign in using the same Meross account.</p> <p>3. How many sounds I can choose? Whether I can add my own sound?</p> <p>We have 11 sounds build-in for user to choose. And device don't support adding customized sound.</p> <p>Warranty</p> <p>Meross products are covered by a 12 months limited warranty from the date of its original purchase. If any problems occur, please contact support@meross.com for help. We can only provide aftersales service for products that are sold by Meross or Meross authorized retailers and distributors.</p> <p>FCC Compliance Information Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>	<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>	<p>User Manual</p>
--	--	---	--	---------------------------

- 注:
- 1.157g双铜纸，正反面印刷，彩色印刷
 - 2.成品尺寸：100*70mm
 - 3.所有材质均符合RoHS标准



TITLE 名称	说明书			深圳市凯信光电有限公司 SHENZHEN HENSEL PHOTOELECTRON CO., LTD		
P/N 料号	1.05.04.00297939					
DRAW NO 图号	N/A	REV. 版本	A0	APP BY 核准	CHK BY 审核	DRW BY 制图
TOL. 公差	±0.5	UNITS 单位	mm	SCALE 比例	FREE	童丽红
3RD. ANGLE'S 第三角法			SHEET 页码	1/1		
				2020/03/26		